Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOKKOM B0FRFNNR73

MOKKOM Commercial Cold Press Juicer

Model: B0FRFNNR73

1. Introduction

Thank you for choosing the MOKKOM Commercial Cold Press Juicer. This appliance is designed for efficient juice extraction from a variety of fruits and vegetables, suitable for both home and commercial environments. Its slow masticating technology ensures high juice yield and nutrient retention. Please read this manual thoroughly before operation to ensure safe and optimal use.

2. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the juicer.
- Do not immerse the motor base in water or other liquids.
- Unplug from outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always ensure the juicer is properly assembled before turning it on.
- Do not put fingers or other objects into the feed chute while the appliance is operating. If food becomes lodged, use the tamper provided.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

3. Product Overview and Components

Familiarize yourself with the parts of your MOKKOM Cold Press Juicer before assembly and operation.



Image: All components of the MOKKOM Commercial Cold Press Juicer.

Key Components:

- **Motor Base:** Contains the motor and control panel.
- **Juicing Bowl:** Collects juice and separates pulp.
- **Auger:** The slow-rotating screw that crushes and presses produce.
- **Filters (Fine and Coarse):** Two interchangeable filters for different pulp preferences.
- **Hopper/Feed Chute:** The top opening where fruits and vegetables are fed. Features a 5.9-inch extra-large opening.
- **Pulp Outlet:** Where dry pulp is expelled.
- **Juice Outlet:** Where fresh juice is dispensed. Features a 15-degree tilted design for smooth flow.
- **Juice Cup:** For collecting extracted juice.
- **Pulp Cup:** For collecting expelled pulp.
- **Cleaning Brush:** For easy cleaning of parts.
- **Juice Sieve:** An additional filter for extra smooth juice.

4. Setup and Assembly

Follow these steps to correctly assemble your juicer before first use.

Image: Assembly Steps

1. **Step 1: Set up the Juicing Bowl.** Place the juicing bowl onto the motor base, aligning the arrows or indicators, and twist until it locks securely into place.
2. **Step 2: Insert the Auger and Filter.** Choose either the fine or coarse filter based on your preference. Insert the auger into the center of the chosen filter. Then, place the assembled filter and auger into the juicing bowl.
3. **Step 3: Attach the Hopper.** Place the hopper onto the top of the juicing bowl, aligning it correctly, and twist until it clicks into place. Ensure all parts are firmly secured before proceeding.

Place the juice cup and pulp cup under their respective outlets.

5. Operating Instructions

This juicer is designed for efficient and continuous operation.



Image: Juicer in operation with fresh produce.

Preparation:

- Wash all fruits and vegetables thoroughly.

- For most fruits and vegetables, pre-cutting is not necessary due to the 5.9-inch extra-large feeding chute. However, very large or fibrous items may benefit from being cut into smaller pieces to prevent strain on the motor.
- Remove hard pits from fruits like peaches or plums.

Juicing Process:

1. Ensure the juicer is properly assembled and the juice and pulp cups are in place.
2. Plug the power cord into a grounded electrical outlet.
3. Turn on the juicer using the power switch.
4. Place fruits and vegetables into the large feeding chute. The self-feeding hopper allows for continuous juicing without constant manual feeding.
5. The slow masticating process will extract juice, which will flow into the juice cup, while the dry pulp will be expelled into the pulp cup.
6. For optimal juice quality, use the fine filter for smooth, residue-free juice, or the coarse filter for juice with a bit of pulp. An additional juice sieve is included for extra fine filtration.
7. The juicer is designed for continuous juicing for up to 12 hours, thanks to its independent cooling system.
8. When finished, turn off the juicer and unplug it from the outlet.



Image: 5.9-inch Extra-Large Feeding Chute.



Image: Equipped with 2 Filters.

6. Maintenance and Cleaning

Regular cleaning ensures the longevity and optimal performance of your juicer. All removable parts are**hand wash only** and are **not dishwasher safe**.



Image: Cleaning Steps

1. **Step 1: Disassemble.** After unplugging the juicer, twist the hopper counter-clockwise and lift it off.
2. **Step 2: Remove Auger and Filter.** Lift the auger and filter assembly out of the juicing bowl.
3. **Step 3: Remove Juicing Bowl.** Twist the juicing bowl counter-clockwise and lift it off the motor base.
4. **Step 4: Rinse and Clean.** Rinse all removable parts (hopper, auger, filter, juicing bowl, juice cup, pulp cup) under running water. Use the provided cleaning brush to remove any pulp residue, especially from the filter mesh and pulp outlet.



Image: Professional Cleaning Brush in use.

Allow all parts to air dry completely before reassembling or storing the juicer.

7. Troubleshooting

If you encounter issues with your juicer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly.	Ensure the power cord is securely plugged in. Check that all parts (juicing bowl, filter, auger, hopper) are correctly aligned and locked into place.
Excessive vibration or noise.	Improper assembly; hard ingredients.	Disassemble and reassemble the juicer, ensuring all parts are securely fitted. Avoid juicing extremely hard items without proper preparation.
Low juice yield or wet pulp.	Filter clogged; too much produce at once.	Clean the filter thoroughly. Feed produce at a steady, slower pace. Ensure the correct filter (fine/coarse) is used for desired pulp level.
Juicer stops during operation.	Overload protection activated; jam.	Turn off and unplug the juicer. Remove any lodged food. Let the motor cool down for 15-30 minutes if overload protection was activated.
Pulp outlet is blocked.	Fibrous produce buildup.	Turn off and unplug. Disassemble and clear the blockage using the cleaning brush.

8. Specifications

Feature	Detail
Brand	MOKKOM
Model	B0FRFNNR73
Color	Silver
Product Dimensions (D x W x H)	7.91" x 5.71" x 20.35"
Material	Plastic
Maximum Power	250 Watts
Voltage	120 Volts
Capacity	2.7 Liters
Item Weight	3.2 Kilograms
Feed Chute Size	5.9 inches
Continuous Juicing	Up to 12 hours
Care Instructions	Hand Wash Only

9. Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official MOKKOM store online. You can find more information and contact details at the MOKKOM Brand Store.

© 2026 MOKKOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FRFNNR73

More documents and user manuals: **https://manuals.plus/**