SUNCROWN 17.6lbs

SUNCROWN Portable Twin Tub Semi-Automatic Washing Machine User Manual

Model: 17.6lbs (Grey)

Introduction

Thank you for choosing the SUNCROWN Portable Twin Tub Semi-Automatic Washing Machine. This manual provides essential information for the safe and efficient operation of your appliance. Please read it thoroughly before use and retain it for future reference.

Important Safety Instructions

- Read all instructions before using the appliance.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the machine with a damaged power cord or plug.
- Keep children away from the appliance during operation.
- Do not immerse the machine in water or other liquids.
- Always unplug the machine before cleaning or performing maintenance.
- Avoid washing waterproof materials or items that float easily, as this may cause imbalance.
- Do not open the spin tub lid while it is spinning. The automatic lid lock feature is designed for safety.

Product Overview

The SUNCROWN Portable Twin Tub Semi-Automatic Washing Machine is designed for compact living spaces, offering both washing and spinning functions. It features separate tubs for washing and spinning, allowing for efficient laundry cycles.

Key Features:

- **Twin Tub Design:** Separate wash and spin tubs for simultaneous operation.
- **High-Powered Performance:** 1300RPM motor, 250W washing power, 140W spinning power.

- **Adjustable Controls:** Separate timers for wash (up to 15 min) and spin (up to 5 min), with wash modes (Gentle, Normal, Drain).
- **Built-in Filter Net:** Traps lint and debris during washing.
- **Automatic Lid Lock:** Enhances safety by halting operation when the spin lid is opened.
- **Extended Drain Hose & Pump:** Facilitates easy water removal.



Figure 1: SUNCROWN Portable Twin Tub Washing Machine (Grey variant).

Setup Instructions

1. Unboxing and Inspection

Carefully remove the washing machine from its packaging. Inspect the unit for any signs of damage. The machine must be tested before leaving the factory, so some water stains may remain inside. This is a normal phenomenon.

Video 1: Unboxing and initial overview of the SUNCROWN Portable Washing Machine. This short video demonstrates the product's appearance and basic components upon unboxing.

2. Placement

Place the washing machine on a flat, stable surface. Its compact design allows it to fit in various locations such as bathrooms, dorm rooms, RVs, or camping setups. Ensure there is enough space for the drain hose and water inlet hose.



Figure 2: The portable washing machine is suitable for various small living environments, including motor homes, balconies, and homestays.

3. Connecting Hoses

- **Water Inlet Hose:** Connect the water inlet hose to a faucet and to the designated water inlet port on the washing machine.
- **Drain Hose:** Position the extended drain hose to direct wastewater into a sink or drain. Ensure the hose is not kinked or obstructed. For optimal draining, the machine may need to be slightly elevated.

4. Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the outlet meets the machine's power requirements.

Operating Instructions

1. Loading Laundry

Open the wash tub lid and load your clothes. Do not overload the machine; ensure clothes can move freely in the water. The washing tub has a capacity of 9.6 lbs (250W) and the spinning tub has a capacity of 6.4 lbs (140W).



Figure 3: Examples of recommended load sizes for various clothing items, such as 1 sweater, 2 jeans, 5 t-shirts, 20 underwear, or 1 quilt.

2. Adding Water and Detergent

Add the appropriate amount of water through the water inlet hose. Add laundry detergent directly into the wash tub with

the clothes.

3. Setting Wash Cycle

Use the control knobs on the top panel to select your desired settings:

- **Wash Timer:** Turn the knob to set the wash time (up to 15 minutes).
- **Wash Selector:** Choose between 'Gentle' for delicate fabrics, 'Normal' for regular loads, or 'Drain' to empty the wash tub.



Figure 4: The control panel features three rotary knobs for Wash Timer, Wash Selector (Gentle, Normal, Drain), and Spin Timer.

4. Starting the Wash

Close the wash tub lid. The machine will begin agitating the clothes according to the selected settings. The robust 1300RPM motor ensures powerful cleaning.

Video 2: Demonstration of a similar twin tub washing machine in operation, showing the washing cycle and controls. This video illustrates the process of filling the tub, adding clothes, and setting the wash timer.

5. Draining Water

Once the wash cycle is complete, turn the 'Wash Selector' knob to 'Drain'. The built-in drain pump will remove the dirty water through the drain hose.

6. Spinning Clothes

Transfer the washed clothes from the wash tub to the spin tub. Ensure the clothes are evenly distributed to prevent imbalance. Place the integrated spin cover over the clothes and close the spin tub lid.

- **Spin Timer:** Turn the knob to set the spin time (up to 5 minutes).

The spin cycle will remove excess water, significantly reducing drying time. The automatic lid lock will prevent the spin tub from operating if the lid is open.

Video 3: A demonstration of a similar small washing machine, highlighting the spin cycle and how clothes are placed in the spin tub. This video shows the effectiveness of the spin function in removing water from laundry.

Maintenance

1. Cleaning the Lint Filter

The wash tub includes a built-in filter net to trap lint and debris. Regularly remove and clean this filter to maintain optimal washing performance and prevent lint transfer to clothes.

2. General Cleaning

Wipe down the exterior of the machine with a soft, damp cloth. Do not use abrasive cleaners or solvents. Clean the interior of the tubs periodically to prevent residue buildup.

3. Storage

When not in use for extended periods, ensure the machine is drained completely and unplugged. Store it in a dry, well-ventilated area.

Troubleshooting

If the machine stops working, please check the following common issues before contacting support:

- **Machine not starting:** Ensure the power cord is securely plugged in and the timer knobs are set correctly.
- **Water not draining:** Check if the drain hose is positioned correctly (lower than the machine's base for gravity drain, or ensure the drain pump is active if using the 'Drain' setting). Ensure the hose is not kinked or blocked.
- **Excessive shaking during spin:** Redistribute clothes evenly in the spin tub. Ensure the machine is on a flat, stable surface.
- **Clothes not clean:** Ensure you are not overloading the machine and using the appropriate amount of detergent for the load size. Clean the lint filter regularly.

Specifications

Feature	Detail
Product Dimensions	13.38"D x 22"W x 25.2"H
Brand	SUNCROWN
Capacity (Total)	17.6 Pounds
Washing Tub Capacity	9.6 Pounds / 250W
Spinning Tub Capacity	6.4 Pounds / 140W
Special Feature	High Efficiency
Access Location	Top Load
Finish Type	Grey
Color	Grey
Cycle Options	Gentle, Normal, Drain
Material	Plastic
Controls Type	Push Button
Operation Mode	Semi Automatic
Installation Type	Freestanding



Figure 5: Detailed dimensions and capacities of the SUNCROWN Portable Washing Machine.



Figure 6: The machine operates at a noise level below 62 dB, ensuring tranquil operation.

Warranty and Support

For specific warranty information and customer support, please refer to the documentation included with your purchase or contact SUNCROWN customer service directly. Protection plans may be available for extended coverage.

© 2026 SUNCROWN. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question