Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cofun C2522

Cofun Premium Metal Handheld Vacuum Sealer Instruction Manual

Model: C2522

Introduction

This manual provides detailed instructions for the safe and efficient use of your Cofun Premium Metal Handheld Vacuum Sealer. Please read this manual thoroughly before operating the device and retain it for future reference.



Image: The Cofun Premium Metal Handheld Vacuum Sealer, a compact device designed for food preservation.

Included Components

The package includes the following items:

- Cofun Handheld Vacuum Sealer
- 30 reusable vacuum seal bags (15 large: 13.4" x 10.3", 15 medium: 8.7" x 8.3")
- 2 Sealing clips
- 1 Wine Vacuum Stopper
- Instruction manual (this document)



Image: A visual representation of the complete package contents, including the vacuum sealer, various sized reusable bags, sealing clips, and a wine stopper.

Setup

Charging the Device

Before first use, ensure the vacuum sealer is fully charged. The device features a Type-C charging port and a battery level display.

1. Connect the provided Type-C charging cable to the charging port on the vacuum sealer.
2. Plug the other end of the cable into a compatible USB power adapter (not included).
3. Monitor the battery level display to confirm charging. The display will show the current battery percentage.
4. A full charge provides enough power for multiple sealing sessions.



Image: Diagram highlighting the Type-C charging port, battery level display, key switch, detachable water tank, and silicone suction cup of the vacuum sealer.

Operating Instructions

Vacuum Sealing Food Bags

Follow these steps to vacuum seal food using the reusable bags:

1. **Prepare the Bag:** Place the food item inside a reusable vacuum bag. Ensure the food does not exceed the maximum fill line and that the area around the air valve is clean and dry.
2. **Seal the Bag:** Use the provided sealing clip to securely close the zipper seal of the bag. Ensure no air can escape from the zipper.
3. **Position the Sealer:** Align the silicone suction cup of the vacuum sealer directly over the circular air valve on the bag. Ensure a tight seal between the sealer and the bag valve.
4. **Start Vacuuming:** Press the power button on the vacuum sealer to begin the vacuuming process. The device will

automatically remove air from the bag.

5. **Completion:** The sealer will stop automatically once the desired vacuum level is reached. Remove the sealer from the bag.



Image: A four-step visual guide demonstrating how to align the silicone and tank holes, place food in the bag and seal, press the button to start, and observe the water tank level.

Using the Wine Vacuum Stopper

To preserve the freshness of opened wine bottles:

1. Insert the wine vacuum stopper firmly into the neck of the wine bottle.
2. Place the vacuum sealer's silicone suction cup over the top of the wine stopper.
3. Press the power button to activate the vacuum. The sealer will remove air from the bottle.
4. The sealer will stop automatically when the vacuum is complete.
5. The wine stopper creates an airtight seal, preserving the wine's flavor.



Image: The wine vacuum stopper in use on a wine bottle, illustrating its ability to keep wine fresh even when the bottle is stored on its side. Compatible with standard wine bottles.

Food Preservation Benefits

Using the Cofun vacuum sealer extends food freshness significantly compared to regular storage methods. This is ideal for meal prep, sous vide cooking, bulk purchases, and storing leftovers.



Image: A comparison chart showing how vacuum sealing extends the freshness of various foods like meat, seafood, vegetables, and nuts by several days or weeks.

Official Product Videos

Your browser does not support the video tag.

Video: Demonstrates the process of vacuum sealing for food preservation, highlighting the ease of use of the Cofun handheld vacuum sealer.

Your browser does not support the video tag.

Video: Illustrates effortless food preservation using the handheld vacuum sealer, showcasing its compact design and efficiency.

Maintenance

Cleaning the Detachable Water Tank

The vacuum sealer features a detachable water tank to collect any liquids or moisture drawn during the vacuuming process. Regular cleaning is essential to prevent motor damage and maintain hygiene.

1. Periodically check the visible water tank for accumulated liquid.
2. To detach, twist and pull the water tank from the main unit.
3. Empty any liquid and wash the tank with warm, soapy water. Rinse thoroughly and allow it to air dry completely before reattaching.
4. **Important:** Do not exceed the tank's maximum water level. Drain immediately if overfilled to protect the motor.



Image: The detachable water tank shown with a red liquid, indicating the maximum fill line. A warning advises against exceeding this level and to drain immediately if overfilled.



Image: The detachable water tank shown with clear liquid, indicating the maximum fill line. A warning advises against exceeding this level and to drain immediately if overfilled.

Cleaning the Main Unit

Wipe the exterior of the vacuum sealer with a soft, damp cloth. Do not immerse the main unit in water or any other liquid.

Reusable Vacuum Bags Care

The included BPA-free reusable vacuum bags are designed for durability and convenience:

- They are leak-proof and odorless.
- The bags are safe for use in the dishwasher, microwave, and freezer (ensure to release vacuum before microwaving).
- Wash bags thoroughly between uses to maintain hygiene and extend their lifespan.



Image: Details of the enhanced reusable vacuum bags, highlighting the double zipper package for a strong, leak-proof seal, the upgraded air valve for dual-seal strong sealing, and confirmation that they are BPA-free and safe for fridge, freezer, and microwave use (without vacuum).

Troubleshooting

If you encounter issues with your Cofun Handheld Vacuum Sealer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on or stops quickly.	Low battery; obstruction in suction cup; water tank overfilled.	Charge the device fully. Check for and remove any debris from the silicone suction cup. Ensure the detachable water tank is not overfilled and is properly drained.

Problem	Possible Cause	Solution
Bag does not vacuum properly or loses vacuum.	Bag not sealed correctly; air valve not clean/dry; suction cup not aligned; bag damaged.	Ensure the bag's zipper seal is completely closed. Clean and dry the area around the air valve. Realign the suction cup firmly over the valve. Inspect bags for tears or punctures; use a new bag if damaged.
Liquid is drawn into the vacuum sealer.	Food contains excessive liquid; bag overfilled.	Ensure the food does not exceed the maximum fill line. Pre-freeze very moist foods or use a paper towel to absorb excess liquid near the seal area. Immediately drain and clean the detachable water tank.
Wine stopper does not hold vacuum.	Stopper not inserted firmly; bottle rim not clean; sealer not aligned.	Push the wine stopper firmly into the bottle neck. Ensure the bottle rim is clean and dry. Align the vacuum sealer's suction cup precisely over the stopper.

Specifications

Feature	Detail
Brand	Cofun
Model Number	C2522
Material	Aluminum
Color	Silver
Operation Mode	Manual (button press)
Suction Power	-60kPa
Battery Capacity	1500mAh
Charging Port	Type-C
Included Bags	30 reusable (15 Large, 15 Medium)
Bag Compatibility	Dishwasher, microwave, freezer safe (BPA-free)

Warranty Information

Specific warranty details are not provided in the product information. Please refer to your purchase documentation or contact Cofun customer support for warranty terms and conditions.

Customer Support

For any questions, technical assistance, or support regarding your Cofun Premium Metal Handheld Vacuum Sealer, please contact Cofun customer service. Contact information may be available on the product packaging or the official Cofun website.
You can also visit the Cofun Store on Amazon for more information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FS1YWG96

More documents and user manuals: **https://manuals.plus/**