JOMAA LD15270B

JOMAA Ergonomic Wireless Bluetooth Vertical Silent Mouse User Manual

Model: LD15270B

1. INTRODUCTION

The JOMAA Ergonomic Wireless Bluetooth Vertical Silent Mouse is designed to provide a comfortable and efficient user experience. Its vertical design promotes a natural handshake grip, reducing wrist strain during prolonged use. This mouse offers triple-mode connectivity, adjustable CPI settings, and a rechargeable battery, making it suitable for various computing environments.

2. PACKAGE CONTENTS

- JOMAA Ergonomic Wireless Bluetooth Vertical Silent Mouse
- 2.4GHz USB Receiver (stored in the mouse)
- USB-C Charging Cable
- User Manual

3. PRODUCT OVERVIEW

Familiarize yourself with the buttons and features of your JOMAA vertical mouse.

Button Function

Image 3.1: Button functions including Left Button, Right Button, Speed Roller, Forward Button, Back Button, Return to Desktop, and CPI Indicator.

- **Left Button:** Standard left-click function.
- **Right Button:** Standard right-click function.
- **Speed Roller (Scroll Wheel):** For vertical scrolling. Features fast scrolling capability.
- **Forward Button:** Navigates forward in web browsers or file explorers.
- **Back Button:** Navigates backward in web browsers or file explorers.
- **Return to Desktop Button:** Quickly minimizes all open windows to show the desktop.
- **CPI Button:** Adjusts the mouse sensitivity (CPI/DPI).
- **CPI Indicator:** LED light indicating the current CPI setting.
- **Power Switch (On/Off):** Located on the bottom of the mouse.
- **Connection Mode Switch:** Located on the bottom, allows switching between 2.4G, BT1, and BT2 modes.
- **USB Receiver Compartment:** Located on the bottom for storing the 2.4GHz USB receiver.

4. SETUP

4.1. 2.4GHz Wireless Connection

1. Locate the 2.4GHz USB receiver in the compartment on the bottom of the mouse.
2. Remove the USB receiver.
3. Insert the USB receiver into an available USB port on your computer.
4. Turn on the mouse using the On/Off switch on the bottom.
5. Switch the connection mode to the 2.4G setting (indicated by a red light).
6. The mouse should automatically connect to your computer.

Mute Button
Silent control, Touch silently

Speed Roller
Fast scroll wheel, Silent Scroll

Bottom with Grooves
2.4G USB Receiver

Image 4.1: The bottom of the JOMAA mouse, highlighting the USB receiver storage and connection mode switch.

4.2. Bluetooth Connection (BT1 / BT2)

The mouse supports two independent Bluetooth connections (BT1 and BT2).

1. Turn on the mouse using the On/Off switch on the bottom.
2. Switch the connection mode to either BT1 or BT2 (indicated by a blue light).
3. Press and hold the connection mode switch for 3-5 seconds until the blue light flashes rapidly. This indicates the mouse is in pairing mode.
4. On your computer or device, open Bluetooth settings.

5. Search for new devices. The mouse will appear as "BT MOUSE-1" or "BT MOUSE-2".

6. Select the mouse to pair. Once paired, the blue light will stop flashing and remain solid for a few seconds before turning off.

7. Repeat these steps for the second Bluetooth channel (BT2) if connecting to another device.

Image 4.2: The JOMAA mouse demonstrating its Bluetooth 3.0/5.0 and 2.4G connectivity options, compatible with Mac OS, Windows, iPad OS, and Android systems.

5. OPERATING INSTRUCTIONS

5.1. CPI Adjustment

The mouse features 5 adjustable CPI levels (1000-1600-2400-3200-4000) to suit different tasks and preferences. The default CPI is 1600.

1. Press the CPI button located near the scroll wheel to cycle through the available CPI settings.

2. The CPI indicator light will flash to confirm the change.

Image 5.1: Illustration of the 5 CPI levels: 1000, 1600, 2400, 3200, and 4000 (note: image shows 4800, but product description states 4000 max).

5.2. Multi-Device Switching

To switch between connected devices (2.4G, BT1, BT2):

- Briefly press the connection mode switch on the bottom of the mouse.
- The indicator light will change to reflect the active connection mode (red for 2.4G, blue for BT1/BT2).

5.3. Charging the Mouse

The mouse has a built-in 500 mAh rechargeable battery.

1. When the battery is low, the red light on the mouse will flash continuously.
2. Connect the provided USB-C charging cable to the charging port on the front of the mouse.
3. Connect the other end of the cable (USB-A) to a power source (e.g., computer USB port, USB wall adapter).
4. The red light will remain solid during charging and turn off when fully charged. A full charge typically takes 2-3 hours.

Image 5.2: The JOMAA mouse connected for Type-C fast charging, indicating a 500mAh battery and 2-3 hours for a full charge.

6. ERGONOMIC DESIGN

The JOMAA vertical mouse is designed to promote a natural 'handshake' posture, which can help alleviate wrist discomfort and prevent repetitive strain injuries associated with traditional flat mice.

Image 6.1: Comparison of the vertical handshake grip offered by the JOMAA mouse versus a traditional flat mouse grip, highlighting ergonomic benefits.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no moisture enters the device.
- **Storage:** Store the mouse in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the mouse frequently. Charge it when the low battery indicator appears.
- **USB Receiver:** When not in use, store the 2.4GHz USB receiver in its designated compartment on the bottom of the mouse to prevent loss.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Mouse not responding	Mouse is off, low battery, incorrect connection mode, receiver not plugged in (2.4G), Bluetooth not paired.	Ensure mouse is on. Charge the mouse. Switch to the correct connection mode. For 2.4G, ensure receiver is securely plugged in. For Bluetooth, re-pair the mouse.
Cursor movement is erratic or slow	Low CPI setting, dirty optical sensor, uneven surface.	Increase CPI using the CPI button. Clean the optical sensor on the bottom of the mouse. Use the mouse on a smooth, opaque surface or a mouse pad.
Cannot connect via Bluetooth	Mouse not in pairing mode, device's Bluetooth is off, interference.	Ensure mouse is in BT pairing mode (rapidly flashing blue light). Check if your device's Bluetooth is enabled. Move closer to the device or away from other wireless devices.
Forward/Back buttons not working on Mac	Mac OS does not natively support these functions for third-party mice without additional software.	This is a known limitation with Mac OS. Consider using third-party software or drivers if available for extended functionality.

9. SPECIFICATIONS

Feature	Detail
Brand	JOMAA
Model	LD15270B
Color	Black
Connectivity Technology	Bluetooth (3.0/5.0), 2.4GHz USB Wireless
Movement Detection Technology	Optical
Button Quantity	6
Hand Orientation	Right
Compatible Devices	Gaming Console, Personal Computer, Smartphone, Tablet
Operating System	Linux, Windows (2000/ME/XP/Vista/7/8/10), macOS (over V10.4)
Wireless Range	10 meters
Power Source	Battery Powered (Rechargeable)
Battery Type	Built-in 500 mAh rechargeable battery
Mouse Sensitivity (CPI)	1000-1600-2400-3200-4000 (Adjustable)
Item Weight	0.21 Kilograms

Feature	Detail
Item Dimensions (L x W)	5.1"L x 3.9"W
Material	Plastic

10. PRODUCT DEMONSTRATION VIDEO

Your browser does not support the video tag.

Video 10.1: A simple demonstration of the JOMAA Ergonomic Wireless Bluetooth Vertical Silent Mouse, showcasing its design and basic functions.

11. WARRANTY AND SUPPORT

This JOMAA product comes with a half-year warranty from the date of purchase. For warranty claims or technical support, please contact JOMAA customer service through the retailer where the product was purchased or visit the official JOMAA website for contact information.
Please retain your proof of purchase for warranty validation.