Samsung Galaxy A07 4G (SM-A075/DS)

Samsung Galaxy A07 4G Smartphone User Manual

Model: SM-A075/DS

1. Introduction

This manual provides essential information for the safe and efficient use of your Samsung Galaxy A07 4G smartphone. Please read this manual thoroughly before operating your device to ensure proper functionality and to prevent damage. The Samsung Galaxy A07 4G features an immersive 6.7-inch display with a 90 Hz refresh rate for smooth interaction. It is designed with a slim 7.6 mm profile and includes an IP54 rating for dust and water splash resistance. The device is equipped with a 50 MP Pro-Grade camera and a 5000 mAh battery for extended use.

2. Package Contents

Verify that your product box contains the following items:

- Samsung Galaxy A07 4G Smartphone
- USB Cable
- SIM Ejection Pin (located within the documentation sleeve)
- Quick Start Guide and Warranty Information

Note: A charger is not included in the package and must be purchased separately.

3. Device Layout

Familiarize yourself with the physical components of your Samsung Galaxy A07 4G.



Image 1: Front and back view of the Samsung Galaxy A07 4G. The front shows the large display with a small notch for the front camera. The back features a dual camera module and the Samsung logo.



Image 2: Front view of the Samsung Galaxy A07 4G, highlighting the 6.7-inch display and the front-facing camera located at the top center.



Image 3: Right side view of the Samsung Galaxy A07 4G, showing the power button and volume rocker buttons.



Image 4: Left side view of the Samsung Galaxy A07 4G, indicating

the SIM card tray slot.



Image 5: Back view of the Samsung Galaxy A07 4G, showcasing the dual camera setup and the Samsung branding.

4. Setup

Follow these steps to set up your new Samsung Galaxy A07 4G:

1. **Insert SIM Card(s) and MicroSD Card:** Use the provided SIM ejection pin to open the SIM tray on the left side of the device. Insert your Nano-SIM card(s) and an optional MicroSD card (up to 1TB) into the designated slots. Ensure the tray is securely closed.
2. **Power On:** Press and hold the Power button (located on the right side) until the Samsung logo appears.
3. **Initial Configuration:** Follow the on-screen prompts to select your language, connect to a Wi-Fi network, accept terms and conditions, and set up your Google account.
4. **Data Transfer (Optional):** If you are upgrading from another device, follow the instructions to transfer your data using Samsung Smart Switch or Google's data transfer tools.
5. **Security Setup:** Configure your preferred security method, such as a PIN, pattern, password, or fingerprint.

5. Operating Instructions

5.1 Display and Navigation

- **Touchscreen Gestures:** Navigate the device using standard touch gestures such as tap, swipe, pinch-to-zoom, and long-press.
- **Home Screen:** Customize your home screen with widgets and app shortcuts. Swipe left or right to access additional screens.
- **Notifications Panel:** Swipe down from the top of the screen to access quick settings and view notifications.
- **Multitasking:** Tap the Recent Apps button (usually a square icon at the bottom of the screen) to view and switch between recently used applications.

5.2 Camera Usage

The Galaxy A07 4G features a 50 MP Pro-Grade main camera and an 8 MP front camera.

- **Launch Camera:** Tap the Camera app icon or double-press the Power button (if configured).
- **Switch Modes:** Swipe left or right on the viewfinder to select different camera modes (e.g., Photo, Video, Portrait).
- **Capture Photo/Video:** Tap the Shutter button to take a photo or the Record button to start/stop video recording.
- **Zoom:** Pinch in or out on the screen to adjust the zoom level.
- **Settings:** Access camera settings to adjust resolution, timer, flash, and other options.

5.3 Battery Management

Your device is equipped with a 5000 mAh battery.

- **Charging:** Connect the USB cable to the device's USB-C port and to a compatible charger.
- **Battery Saver:** Enable Battery Saver mode in Settings to extend battery life by limiting background activity and visual effects.
- **Optimizing Usage:** Close unused apps, reduce screen brightness, and disable unnecessary features (e.g., Bluetooth, GPS) when not in use to conserve battery.

---

6. Maintenance

Proper care ensures the longevity of your Samsung Galaxy A07 4G:

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Water and Dust Resistance:** The device has an IP54 rating, meaning it is protected against dust ingress and splashing water from any direction. It is not designed for submersion in water. Ensure all ports are dry before charging.
- **Software Updates:** Regularly check for and install software updates to ensure optimal performance and security.
- **Storage Management:** Periodically clear unnecessary files and apps to free up storage space and maintain performance.

---

7. Troubleshooting

Refer to the following table for common issues and their solutions:

Issue	Possible Solution

Issue	Possible Solution
Device does not power on	Ensure the battery is charged. Connect to a charger for at least 10 minutes, then try powering on again.
Screen is unresponsive	Restart the device by holding the Power button for several seconds. If unresponsive, force restart by holding Power and Volume Down buttons simultaneously for about 7-10 seconds.
Apps are crashing or freezing	Clear the cache of the problematic app (Settings > Apps > [App Name] > Storage > Clear cache). Update the app or reinstall it. Ensure sufficient free storage space.
Poor battery life	Adjust screen brightness, enable Battery Saver mode, close background apps, and disable unused features like GPS or Bluetooth.
Cannot connect to Wi-Fi/Mobile Data	Toggle Wi-Fi/Mobile Data off and on. Restart the device. Check router or network settings. Ensure SIM card is properly inserted and activated.

8. Specifications

Key technical specifications for the Samsung Galaxy A07 4G (SM-A075/DS):

Feature	Detail
Model Name	A07 4G (SM-A075/DS)
Display Size	6.7 Inches (171.3mm full rectangle / 167.3mm rounded corners)
Display Resolution	720 x 1600 (HD+)
Display Technology	PLS LCD
Processor	Octa-core (2x2.2 GHz Cortex-A76 & 6x2.0 GHz Cortex-A55)
RAM	4 GB
Internal Storage	128 GB
Expandable Storage	MicroSD up to 1TB
Rear Camera	50 MP, f/1.8 (wide), PDAF; 2 MP, f/2.4 (depth)
Front Camera	8 MP, f/2.0 (wide)
Battery Capacity	5000 Milliamp Hours (mAh)
Operating System	Android
Cellular Technology	4G LTE (Unlocked for All Carriers)
SIM Card Slot Count	Dual SIM
Connectivity	Wi-Fi 802.11a/b/g/n/ac 2.4GHz+5GHz, VHT80, Bluetooth, GPS, Glonass, Beidou, Galileo, QZSS
Ports	USB-C, 3.5mm Stereo Earjack

Feature	Detail
Dimensions	2 x 2 x 2 inches (approximate)
Item Weight	9.2 ounces
Protection	IP54 Dust and Water Protection

9. Warranty and Support

This Samsung Galaxy A07 4G (SM-A075/DS) is a Latin American Version and comes with a 1-year warranty valid in South, Central, Latin America, and the Caribbean. Please verify the model number on your phone (SM-A075/DS) to ensure local warranty coverage in these regions. If the model is different, local warranty may not apply.
For further assistance, please visit the official Samsung support website or contact their customer service in your region.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I reset my Samsung Galaxy A07 4G (SM-A075/DS) if I cannot remember my password to restart or unlock the phone?

If you have forgotten the password, PIN, or pattern for your Samsung Galaxy A07 4G (SM-A075/DS), you will likely need to perform a factory reset to regain access to the device. Please note that...

Read full answer