Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SJCAM C110+

SJCAM C110 Plus Action Camera User Manual

Model: C110+

1. Introduction

This manual provides essential instructions for the safe and effective use of your SJCAM C110 Plus Action Camera. Please read it thoroughly before operating the device and retain it for future reference.

2. Package Contents

Verify that all items are present in your package:

- SJCAM C110 Plus Action Camera
- 50-IN-1 Action Kit
- 64GB Micro SD Card
- Card Reader
- Card Wallet
- USB-C Adapter

3. Camera Overview

Familiarize yourself with the camera's components and controls.



Figure 1: SJCAM C110 Plus Action Camera and bundled accessories. This image displays the compact camera unit alongside various mounting options, a microSD card, and other included items.

Key Components:

- **Lens:** Front-facing camera lens.
- **Power/Mode Button:** Used to power on/off and switch modes.
- **Record/Shutter Button:** Initiates/stops recording or takes photos.
- **MicroSD Card Slot:** For memory card insertion.
- **USB-C Port:** For charging and data transfer.
- **Magnetic Back Clip:** For attaching to clothing or metal surfaces.
- **Microphones:** Dual microphones for audio capture.

4. Setup

4.1 Charging the Battery

Before first use, fully charge the camera battery.

1. Connect the included USB-C cable to the camera's USB-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color when charging is complete.

Note: The camera supports fast charging via USB Type-C. A full charge typically provides up to 120 minutes of 1080p recording.

4.2 Inserting/Removing MicroSD Card

A microSD card (up to 128GB, Class 10 or higher recommended) is required for recording.

1. **Inserting:** With the camera powered off, gently insert the microSD card into the card slot with the contacts facing the correct direction until it clicks into place.
2. **Removing:** Gently push the microSD card inward until it springs out, then pull it out.

Caution: Do not insert or remove the microSD card while the camera is powered on or recording, as this may cause data corruption.

4.3 Powering On/Off

- **Power On:** Press and hold the Power/Mode button for a few seconds until the indicator light illuminates.
- **Power Off:** Press and hold the Power/Mode button for a few seconds until the indicator light turns off.

5. Operating the Camera

5.1 Basic Recording (Video/Photo)

- **Video Recording:**
    a. Ensure the camera is in Video Mode.
    b. Press the Record/Shutter button once to start recording. The indicator light will flash.
    c. Press the Record/Shutter button again to stop recording. The indicator light will stop flashing.
- **Photo Capture:**
    a. Switch to Photo Mode by pressing the Power/Mode button repeatedly.
    b. Press the Record/Shutter button once to take a photo.

5.2 Mode Switching

Press the Power/Mode button repeatedly to cycle through available modes (e.g., Video, Photo, Playback, Settings).

5.3 Settings Menu Navigation

Access and navigate the settings menu to adjust video resolution, photo quality, white balance, exposure, and other parameters. Refer to the on-screen prompts or the SJCAM mobile app for detailed menu options.

5.4 Connecting to Mobile App

The SJCAM C110 Plus can connect to the official SJCAM mobile application for remote control, live preview, and file management.

1. Download the "SJCAM Zone" app from your device's app store.
2. Turn on the camera's Wi-Fi (if applicable, check camera settings).
3. On your mobile device, connect to the camera's Wi-Fi network (SSID and password usually displayed on camera screen or in manual).

4. Open the SJCAM Zone app and connect to your camera.

5.5 Mounting the Camera

The C110 Plus features a magnetic back clip for versatile mounting.

- Attach the camera directly to metallic surfaces.
- Use the magnetic clip to secure the camera to clothing, bags, or other compatible accessories from the 50-IN-1 Action Kit.

6. Maintenance

6.1 Cleaning

- Use a soft, lint-free cloth to clean the camera body.
- For the lens, use a specialized lens cleaning cloth and solution. Avoid harsh chemicals.
- Ensure the USB-C port and microSD card slot are free of dust and debris.

6.2 Storage

Store the camera in a cool, dry place away from direct sunlight and extreme temperatures. Remove the microSD card if storing for extended periods.

6.3 Firmware Updates

Periodically check the official SJCAM website for firmware updates. Updates can improve performance and add new features. Follow the instructions provided with the firmware download carefully.

7. Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Low battery; faulty battery; camera malfunction.	Charge the battery fully. Try a different USB-C cable/charger. If problem persists, contact support.
Cannot record video/take photos.	No microSD card; card full; card error; incorrect mode.	Insert a microSD card. Delete old files or use a new card. Format the card (backup data first). Ensure correct mode is selected.
Poor video/photo quality.	Dirty lens; low light; incorrect settings.	Clean the lens. Ensure adequate lighting. Adjust resolution, exposure, or other settings.
Camera freezes or becomes unresponsive.	Software glitch; full memory card.	Perform a soft reset (press and hold power button until it turns off, then restart). Remove and reinsert microSD card.

8. Specifications

Feature	Detail
Brand	SJCAM
Model Number	C110+

Feature	Detail
Video Capture Resolution	4K
Effective Still Resolution	20 MP
Image Stabilization	Gyro Stabilization
Water Resistance Level	IP65 Splashproof
Connectivity Technology	USB
Battery Average Life	120 minutes (1080p recording)
Storage	MicroSD (up to 128GB)
Video Capture Format	MP4
Supported Audio Format	AAC, MP3
Focus Type	Auto Focus
Lens Type	Wide Angle
Form Factor	Ultra Compact

9. Warranty and Support

For warranty information, technical support, or service inquiries, please visit the official SJCAM website or contact their customer service directly.
Official SJCAM Store: SJCAM Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FTHJYNL6

More documents and user manuals: **https://manuals.plus/**