Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Syntecno VC7211

Syntecno VC7211 Cordless Stick Vacuum Cleaner User Manual

Model: VC7211

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- This appliance is for household use only. Do not use outdoors or on wet surfaces.
- Do not allow children to operate the vacuum cleaner. Close supervision is necessary when used near children.
- Do not pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use without the dust cup and/or filters in place.
- Turn off the appliance before connecting or disconnecting the motorized brush, extension tube, or other accessories.
- Use only the charger supplied by the manufacturer to recharge the appliance.
- Store the vacuum cleaner indoors in a cool, dry place.

2. Product Components

Familiarize yourself with the parts of your Syntecno VC7211 Cordless Stick Vacuum Cleaner.



Figure 2.1: Product Components Overview

1. Motorized Brush Head
2. Main Body (Motor & Dustbin)
3. Extension Tube
4. Crevice Tool
5. 2-in-1 Wide Nozzle
6. Charging Adapter
7. Charging Station

3. Setup and Assembly

3.1 Initial Assembly

Follow these steps to assemble your vacuum cleaner:

1. Insert the extension tube into the main body until it clicks securely.
2. Attach the motorized brush head to the other end of the extension tube, ensuring it clicks into place.
3. For handheld use, attach the crevice tool or 2-in-1 wide nozzle directly to the main body.



Figure 3.1: Fully Assembled Vacuum Cleaner

3.2 Charging Station Installation

The vacuum cleaner comes with a wall-mountable charging station for convenient storage and charging.

- Choose a suitable location near a power outlet for mounting the charging station.
- Secure the charging station to the wall using appropriate screws and anchors (not included).
- Connect the charging adapter to the charging station and plug it into a power outlet.



Figure 3.2: Vacuum Cleaner on Wall-Mounted Charging Station

4. Operating Instructions

4.1 Charging the Battery

Before first use, fully charge the vacuum cleaner for 4-5 hours.

- Place the main body of the vacuum cleaner onto the charging station or connect the charging adapter directly to the battery port.
- The LED display will indicate charging status. A full charge provides up to 60 minutes of cleaning time (20 minutes at maximum suction).



Figure 4.1: Battery Pack and Runtime Indication

4.2 Power On/Off and Suction Modes

The vacuum cleaner features an LED touch screen for easy control.

- Press the power button on the main body to turn the vacuum cleaner on or off.
- Use the touch screen to select one of the three adjustable power modes (low, medium, high).
- The LED display shows the remaining battery life and current suction mode.



Figure 4.2: LED Touch Screen Display

4.3 Cleaning Surfaces

The Syntecno VC7211 is designed for effective cleaning on various surfaces.

- For hard floors and carpets, use the motorized brush head. The integrated LED light illuminates dust and debris in dark corners and under furniture.
- The V-shaped brush design helps reduce pet hair tangles.
- For crevices, corners, and upholstery, attach the appropriate accessory (crevice tool or 2-in-1 wide nozzle) directly to the main body or extension tube.



Figure 4.3: Motorized Brush Head Cleaning Carpet

5. Maintenance

5.1 Emptying the Dustbin

Empty the dustbin regularly to maintain optimal suction performance.

1. Ensure the vacuum cleaner is turned off.
2. Hold the main body over a trash can.
3. Press the dustbin release button to open the bottom flap and empty the contents.



Figure 5.1: Emptying the Dustbin

5.2 Cleaning Filters

Regularly clean the HEPA filter and other filters to prevent clogging and maintain suction power.

- Twist and pull to remove the filter assembly from the dustbin.
- Tap the filters gently to remove loose dirt. For a deeper clean, rinse the filters under cold running water.
- Allow filters to air dry completely for at least 24 hours before reassembling. Do not use a dryer or other heating device.

5.3 Cleaning the Brush Roll

Inspect and clean the brush roll periodically to remove tangled hair or debris.

- Turn off the vacuum cleaner and detach the motorized brush head.
- Use scissors or a brush to carefully cut and remove any hair or fibers wrapped around the brush roll.

- Ensure the brush roll spins freely before reattaching the head.

6. Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum does not turn on.	Battery is depleted.	Charge the battery fully.
Low suction power.	Dustbin is full. Filters are clogged. Brush roll is tangled. Obstruction in nozzle/tube.	Empty the dustbin. Clean or replace filters. Clean the brush roll. Remove any obstructions.
Brush roll not spinning.	Tangled debris. Brush head not properly attached.	Clean the brush roll. Reattach the brush head securely.
Short battery runtime.	Battery not fully charged. Using maximum power mode continuously.	Ensure battery is fully charged. Use lower power modes for longer runtime.

7. Specifications

Feature	Detail
Brand	Syntecno
Model Number	VC7211
Power	350 Watts
Max Suction Power	Up to 35,000 Pa
Battery Capacity	2500 mAh
Max Runtime	Up to 60 minutes (20 minutes at max power)
Charging Time	4-5 hours
Filter Type	HEPA Filter
Noise Level	≤75 dB
Special Features	Cordless, LED Touch Screen, Anti-tangle V-brush, LED Headlights, Wall-mount Charging Station
Recommended Surfaces	All floor types (carpets, tiles, laminate)

8. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Syntecno website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FTVM85Q1

More documents and user manuals: **https://manuals.plus/**