Stromberg Carlson Groove and Zing Speaker Bundle (B0FVNN4JHR)

Stromberg Groove and Zing Bluetooth Speaker Bundle User Manual

Model: Groove and Zing Speaker Bundle (B0FVNN4JHR)

Introduction

This user manual provides comprehensive instructions for the Stromberg Groove and Zing Bluetooth Speaker Bundle. It covers the setup, operation, maintenance, and troubleshooting for both the Groove 30W Portable Speaker and the Zing Mini 5W Waterproof Speaker. Please read this manual thoroughly before using your speakers to ensure optimal performance and longevity.

Product Overview

Stromberg Groove 30W Portable Speaker



The Stromberg Groove speaker delivers powerful 30W audio with deep bass and clear sound. It features an RGB lighting system for visual effects and offers up to 12 hours of continuous playtime. Designed for durability, it is suitable for both indoor and outdoor use, featuring IPX4 splash resistance. The Groove speaker supports Stromberg Connect technology for wireless stereo pairing.

- **Power Output:** 30W
- **Battery Life:** Up to 12 hours
- **Features:** RGB lighting, Stromberg Connect technology

- **Durability:** IPX4 Splash-resistant

Stromberg Zing Mini 5W Waterproof Speaker



The Stromberg Zing Mini speaker is a compact and lightweight audio solution, providing 5W of balanced, high-quality sound through its 1.75-inch tweeter. It offers up to 6 hours of playback and features both Bluetooth and AUX connectivity. The Zing speaker is waterproof, making it ideal for on-the-go music, travel, or outdoor activities. It also supports Stromberg Connect for stereo pairing.

- **Power Output:** 5W
- **Tweeter:** 1.75 inches
- **Battery Life:** Up to 6 hours
- **Connectivity:** Bluetooth, AUX
- **Durability:** Waterproof

Setup Instructions

1. Unpacking and Initial Charge

Carefully remove both speakers and all accessories from the packaging. Before first use, fully charge both the Groove and Zing speakers using the provided USB-C charging cables and a compatible USB power adapter (not included). The charging indicator will typically turn off or change color once fully charged.

2. Powering On/Off

- **To Power On:** Press and hold the Power button on each speaker until you hear an audible prompt or see the indicator light illuminate.
- **To Power Off:** Press and hold the Power button again until the speaker powers down.

3. Bluetooth Pairing (Individual Speaker)

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicator light will typically flash blue).
2. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "Stromberg Groove" or "Stromberg Zing" from the list.
4. Once connected, you will hear a confirmation sound, and the indicator light will turn solid blue.

4. Stromberg Connect (Wireless Stereo Pairing)



Stromberg Connect allows you to pair two compatible Stromberg speakers (e.g., two Groove speakers, or a Groove and a Zing) for an enhanced stereo audio experience. Follow these steps:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the Stromberg Connect button (often indicated by a chain link or stereo icon). The indicator light will flash.
3. On the second speaker, press the Stromberg Connect button.
4. The speakers will automatically search and connect to each other. Once connected, you will hear a confirmation sound, and the indicator lights will change to indicate a successful stereo connection.
5. Now, connect your device to the primary speaker via Bluetooth as described in step 3. Audio will play through both speakers in stereo.

Operating Instructions

1. Basic Audio Playback

- **Play/Pause:** Press the Play/Pause button (often a triangle or circle icon).
- **Volume Up/Down:** Press the '+' or '-' buttons.
- **Next Track:** Press and hold the '+' button (or a dedicated next track button).
- **Previous Track:** Press and hold the '-' button (or a dedicated previous track button).

2. AUX Input Usage



To play audio from a device without Bluetooth, use the 3.5mm AUX input. Connect one end of a 3.5mm audio cable (not included) to the AUX port on the speaker and the other end to your audio device's headphone jack. The speaker will automatically switch to AUX mode or may require a mode button press.

3. RGB Lighting Control (Groove Speaker Only)



The Groove speaker features an integrated RGB lighting system. Press the dedicated Light button (if available) to cycle through different lighting modes or to turn the lights off. Refer to the speaker's specific button layout for the exact control.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker surfaces. Do not use abrasive cleaners or solvents.
- **Water Resistance (Groove - IPX4):**The Groove speaker is splash-resistant. Avoid submerging it in water or exposing it to strong jets of water. Ensure charging port covers are securely closed when near water.
- **Waterproof (Zing):** The Zing speaker is waterproof. While it can withstand immersion, ensure the charging port cover is tightly sealed before exposing it to water.
- **Storage:** Store speakers in a cool, dry place away from direct sunlight and extreme temperatures. If storing for extended periods, charge the battery periodically to maintain its health.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
No sound from speaker.	Volume too low; device not connected; incorrect input mode.	Increase volume on both speaker and device. Ensure Bluetooth is connected or AUX cable is properly inserted and mode selected.
Bluetooth pairing fails.	Speaker not in pairing mode; device too far; interference.	Ensure speaker is in pairing mode. Move device closer. Turn off other Bluetooth devices. Forget speaker from device's Bluetooth list and re-pair.
Stromberg Connect pairing fails.	Speakers already connected to another device; not in pairing mode.	Ensure both speakers are disconnected from other devices. Follow Stromberg Connect pairing steps carefully.

Specifications

Stromberg Groove Speaker

- **Power Output:** 30W

- **Battery Life:** Up to 12 hours
- **Connectivity:** Bluetooth, AUX
- **Water Resistance:** IPX4 Splash-resistant
- **Special Features:** RGB Lighting, Stromberg Connect

Stromberg Zing Mini Speaker



- **Power Output:** 5W RMS
- **Tweeter Size:** 1.75 inches
- **Battery Life:** Up to 6 hours
- **Connectivity:** Bluetooth, AUX
- **Water Resistance:** Waterproof
- **Special Features:** Stromberg Connect

Note: Specifications are subject to change without notice.

Warranty and Support

Stromberg products are designed for quality and reliability. For information regarding warranty coverage, technical support, or service inquiries, please visit the official Stromberg website or contact their customer support directly. You can find more information and contact details at theStromberg Carlson Store on Amazon.

© 2024 Stromberg Carlson. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question