Colorcool M8

Colorcool M8 MP3 Player User Manual

Model: M8-32GB

1. Product Overview

The Colorcool M8 is a portable MP3 player designed for music and media playback on the go. It features Bluetooth 5.3 connectivity, a built-in HD speaker, and a full-touch screen for easy navigation. With 32GB of internal memory and support for Micro SD cards up to 512GB, it offers ample storage for your media library. The device also includes functions such as FM Radio, voice recording, e-book reader, video playback, alarm clock, calendar, and stopwatch.



Image 1.1: Front view of the Colorcool M8 MP3 Player, showcasing its compact design and touch screen interface.



Image 1.2: The Colorcool M8 MP3 Player shown in a pocket, highlighting its lightweight and portable nature (32g, 2.56×1.57×0.59 inches).

Your browser does not support the video tag.

Video 1.1: A brief overview of the Colorcool M8 MP3 Player, demonstrating its physical appearance and compact size from multiple angles.

2. Setup

2.1 Package Contents

Ensure all items are present in the package:

- 1 × Colorcool M8 MP3 Player
- 1 × USB Type-C Cable
- 1 × Wired Headset
- 1 × User's Manual (this document)

2.2 Device Layout



Image 2.1: Diagram illustrating the location of buttons and ports on the Colorcool M8 MP3 Player, including Power ON/OFF, Headphone Jack, Volume +/-, TF Card Slot, Previous, Next, Return, Reset, and USB Port.

2.3 Charging the Device

Before first use, fully charge the MP3 player. Connect the provided USB Type-C cable to the device's USB port and the other end to a compatible USB power adapter (not included) or a computer's USB port. A full charge typically takes approximately 1.5 hours and provides up to 20 hours of music playback.



Image 2.2: The MP3 player connected via its Type-C port for charging, indicating charging time and music playing time.

2.4 Inserting a Micro SD Card

The device has 32GB of internal memory. To expand storage, insert a Micro SD card (up to 512GB) into the TF Card Slot as shown in Image 2.1. Ensure the card is inserted correctly until it clicks into place.



Image 2.3: The MP3 player demonstrating its support for Micro SD card expansion up to 512GB, alongside its built-in 32GB storage.

2.5 Connecting Headphones

You can connect audio output via wired headphones or Bluetooth.

- **Wired Headphones:** Plug the 3.5mm jack of your wired headset into the Headphone Jack on the device.
- **Bluetooth Headphones/Speakers:**
  1. Ensure your Bluetooth headphones or speaker are in pairing mode.
  2. On the MP3 player, navigate to the**Bluetooth** menu.
  3. Select 'Search for devices' and choose your device from the list to pair.

Note: The MP3 player cannot pair with smartphones, PCs, or certain car Bluetooth systems.



Image 2.4: The MP3 player demonstrating Bluetooth 5.3 connectivity with wireless earbuds and a portable Bluetooth speaker.

3. Operating Instructions

3.1 Power On/Off

- **To Power On:** Press and hold the Power ON/OFF button (refer to Image 2.1) until the screen illuminates.
- **To Power Off:** Press and hold the Power ON/OFF button until the 'Power Off' option appears, then confirm.

3.2 Menu Navigation

The Colorcool M8 features a full-touch screen for intuitive navigation. Swipe left or right to browse through the main menu icons. Tap an icon to select an application or setting.



Image 3.1: The MP3 player's main menu displaying icons for its various functions, including Music, Bluetooth, FM Radio, Video, Voice Record, E-book, Calendar, Stopwatch, Alarm, and Picture.

3.3 Music Playback

Tap the 'Music' icon to access your music library. The player supports MP3, WMA, APE, FLAC, WAV, DRM, and ACELP audio formats. Use the on-screen controls or physical volume buttons to manage playback.

3.4 Transferring Music Files

Connect the MP3 player to your computer using the provided USB Type-C cable. The device should appear as a removable disk. You can then drag and drop music files directly into the player's internal storage or the inserted Micro SD card. Ensure files are in a supported format.

Note: Some users have reported issues transferring files directly via USB. If this occurs, try transferring files to a Micro SD card using a card reader, then insert the card into the MP3 player.

3.5 FM Radio

To use the FM Radio function, a wired headset must be connected as it acts as the antenna. Tap the 'FM Radio' icon, then use the on-screen controls to scan for stations or manually tune to a frequency.



Image 3.2: The MP3 player's FM Radio function in use, showing the frequency display and a user enjoying the radio with wired headphones.

3.6 Video Playback

The player supports AVI and AMV video formats. Tap the 'Video' icon to browse and play video files. Ensure video files

are converted to a compatible format and resolution for optimal playback on the 1.8-inch TFT color screen.

3.7 Voice Recording

Tap the 'Voice Record' icon to access the recording function. Use the on-screen controls to start, pause, and stop recordings. Recorded files are saved internally and can be managed through the 'Folder View' or 'Recordings' menu.

3.8 E-book Reader

The device supports TXT format e-books. Transfer your TXT files to the player and access them via the 'E-book' icon. Use the touch screen to turn pages.

3.9 Other Functions

The MP3 player also includes a Calendar, Stopwatch, and Alarm Clock. Access these functions via their respective icons on the main menu.

4. Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the MP3 player in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, even if not in use for extended periods.
- **Water Resistance:** This device is not waterproof. Avoid exposure to water or high humidity.

5. Troubleshooting

- **Device will not turn on:** Ensure the device is charged. If the battery is completely drained, it may take a few minutes of charging before it responds. Try performing a reset by pressing the 'Reset' button (refer to Image 2.1) with a thin object like a paperclip.
- **Cannot transfer files via USB:** Verify the USB cable connection. Ensure your computer recognizes the device as a removable disk. If issues persist, try transferring files to a Micro SD card using a separate card reader, then insert the card into the MP3 player.
- **Bluetooth pairing issues:** Ensure the MP3 player and the target Bluetooth device are both in pairing mode and within range. Remember, the MP3 player cannot pair with smartphones or PCs.
- **Poor FM Radio reception:** Ensure wired headphones are properly plugged into the headphone jack, as they serve as the antenna. Try adjusting the position of the headphone cable for better reception.
- **Touch screen unresponsive:** Try restarting the device. If the issue continues, perform a reset.
- **Battery drains quickly:** Reduce screen brightness, disable the built-in speaker if not needed, and close unused applications. Ensure the device is fully powered off when not in use, rather than just in sleep mode.

6. Specifications

Brand	Colorcool
Model Name	M8-32GB
Model Number	M8
Internal Memory	32 GB

Expandable Memory	Micro SD Card up to 512 GB
Connectivity Technology	Bluetooth 5.3, Aux (3.5mm), USB Type-C
Screen Size	1.8 Inches
Display Technology	TFT Colorscreen
Supported Audio Formats	MP3, WMA, APE, FLAC, WAV, DRM, ACELP
Supported Video Formats	AVI, AMV
Supported E-book Format	TXT
Special Features	Equalizer, FM Radio, Touch Screen, Video Playback, Voice Recorder, Built-in Speaker
Battery Life (Average)	20 Hours (music playback)
Item Weight	32 Grams
Color	Light Black

7. Warranty and Support

7.1 Warranty Information

The Colorcool M8 MP3 Player comes with a**3-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use. Please retain your proof of purchase for warranty claims.

7.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Colorcool customer support through the retailer where the product was purchased or visit the official Colorcool website for contact information.

© 2025 Colorcool. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question