Mikado MD-SBT32

Mikado MD-SBT32 Bluetooth Soundbar Speaker User Manual

1. INTRODUCTION

Thank you for choosing the Mikado MD-SBT32 Bluetooth Soundbar Speaker. This portable soundbar is designed to deliver high-quality audio with the convenience of Bluetooth 5.3 connectivity, versatile AUX input, and dynamic 7-mode RGB lighting. This manual provides essential information for setting up, operating, and maintaining your device to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Mikado MD-SBT32 soundbar.

Image 2.1: Top View with Controls. This image displays the top surface of the Mikado MD-SBT32 soundbar, highlighting the speaker grille and the integrated control buttons: Power, Volume Down, Play/Pause, and Volume Up. The 'mikado' brand logo is visible on the right side.

Image 2.2: Rear Ports. A detailed view of the rear panel of the soundbar, showing the Type-C port for charging and the 3.5mm AUX input jack. Accompanying cables are also shown for illustration.

Controls and Ports:

- **Power Button:** Press and hold to turn the speaker ON/OFF. Short press to change RGB light modes.

- **Volume Down (-):** Decrease volume.

- **Play/Pause Button:** Play or pause audio playback.

- **Volume Up (+):** Increase volume.

- **Type-C Port:** Used for charging the soundbar.

- **AUX Input:** For wired audio connection using a 3.5mm audio cable.

3. SETUP

3.1 Charging the Soundbar

1. Connect the provided Type-C charging cable to the Type-C port on the rear of the soundbar.
2. Connect the other end of the cable to a DC 5V 2A power adapter (not included) or a compatible USB port.
3. The charging indicator light will illuminate. A full charge takes approximately 4 hours.
4. Once fully charged, the indicator light will change or turn off, and the soundbar is ready for use.

Note: For optimal battery life, fully charge the device before first use.

3.2 Powering On/Off

- **To Power On:** Press and hold the Power button for a few seconds until the indicator light turns on and you hear a power-on prompt.

- **To Power Off:** Press and hold the Power button again for a few seconds until the indicator light turns off and you hear a power-off prompt.

4. OPERATING INSTRUCTIONS

4.1 Bluetooth Pairing

The Mikado MD-SBT32 uses Bluetooth 5.3 for stable wireless connection.

1. Ensure the soundbar is powered on and in Bluetooth pairing mode (indicated by a flashing blue light or an audible prompt).
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "MD-SBT32" from the list of found devices.
4. Once paired, the indicator light will become solid blue, and you will hear a connection confirmation sound.
5. You can now play audio wirelessly from your device through the soundbar.

4.2 AUX Mode

For wired audio playback, use the AUX input.

1. Connect one end of a 3.5mm audio cable (not included) to the AUX input port on the soundbar.

2. Connect the other end of the audio cable to the headphone jack or AUX output of your audio source device.

3. The soundbar should automatically switch to AUX mode, or you may need to short press the Power button to cycle through modes until AUX mode is activated.

4.3 RGB Lighting Control

The soundbar features 7 different RGB light modes to enhance your listening experience.

- To change the RGB light mode, short press the Power button. Each press will cycle through the available 7 modes.
- To turn off the RGB lighting, continue pressing the Power button until the lights are off. Press again to reactivate.

5. MAINTENANCE

Proper care ensures the longevity of your soundbar.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the soundbar. Do not use abrasive cleaners, waxes, or solvents.
- **Storage:** Store the soundbar in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To maintain battery health, avoid fully discharging the battery frequently. If not used for extended periods, charge the soundbar at least once every three months.
- **Water Exposure:** This device is not waterproof. Avoid exposure to water or excessive moisture.

6. TROUBLESHOOTING

If you encounter issues with your soundbar, refer to the following common solutions:

- **No Power:**
  - Ensure the soundbar is fully charged.
  - Verify the charging cable and power adapter are working correctly.

- **No Sound:**
  - Check the volume levels on both the soundbar and your connected device.
  - If using Bluetooth, ensure the device is properly paired and connected.
  - If using AUX, ensure the cable is securely connected to both the soundbar and the audio source, and the soundbar is in AUX mode.

- **Bluetooth Disconnection/Unable to Pair:**
  - Ensure the soundbar is within the effective Bluetooth range (typically 10 meters) of your device.
  - Turn off and on the Bluetooth function on your device and the soundbar.
  - Forget the "MD-SBT32" device from your device's Bluetooth settings and attempt to re-pair.
  - Ensure no other Bluetooth devices are interfering.

- **RGB Lights Not Working:**
  - Short press the Power button to cycle through the RGB modes.
  - Ensure the soundbar has sufficient battery charge.

7. SPECIFICATIONS

Feature	Specification
Model	MD-SBT32
Bluetooth Version	5.3
Material	Plastic + Iron Mesh
Speaker Dimensions (W*D*H)	346mm * 54.75mm * 79.2mm
Output Power	16W (8W * 2)
Battery Capacity	2000mAh
Speaker Impedance	4 Ohm
Power Input	DC 5V 2A
Functions	Bluetooth, RGB, AUX
Input Ports	AUX, Type-C
Charging Time	Approximately 4 Hours
Maximum Working Time	Approximately 3 Hours
Cable Length	1.5 Meters
Net Weight	551g
RGB Light Modes	7 Modes
Product Dimensions (D x W x H)	10cm x 49cm x 10cm

8. WARRANTY AND SUPPORT

The Mikado MD-SBT32 Soundbar Speaker comes with a **24-month warranty** from the date of purchase. This warranty covers manufacturing defects and material faults under normal use.

The warranty does not cover:

- Damage caused by improper use, negligence, or accidents.
- Damage from unauthorized repairs or modifications.
- Normal wear and tear.

For warranty claims or technical support, please contact your retailer or the official Mikado customer service with your proof of purchase. Please have your model number (MD-SBT32) ready when contacting support.