Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CBDZONE D90

CBDZONE D90 Digital Camera User Manual

Model: D90

Introduction

This manual provides detailed instructions for the operation and maintenance of your CBDZONE D90 Digital Camera. Please read this manual thoroughly before using the camera to ensure proper function and to maximize your user experience. This camera is designed for capturing high-quality photos and 1080P videos, featuring a 270° rotating LED flip screen and 16x digital zoom.

Package Contents

Verify that all items listed below are included in your package:

- 1 x CBDZONE D90 Digital Camera
- 1 x Charging Cable
- 1 x User Manual
- 1 x 32GB Memory Card (Included with this model)

Product Overview

Familiarize yourself with the camera's components and controls.



Image: Front view of the CBDZONE D90 Digital Camera, showing the lens, built-in fill light, and the 2.4-inch rotatable LED flip screen.

Key Components:

- **Lens:** Captures images and videos.
- **2.4-inch Rotatable LED Flip Screen:** For framing shots, reviewing content, and selfies.
- **Built-in Fill Light:** Provides additional illumination in low-light conditions.
- **Power Button:** Turns the camera on or off.
- **Shutter Button:** Takes photos or starts/stops video recording.
- **Zoom Controls:** Adjusts the 16x digital zoom.
- **Mode Dial/Button:** Switches between photo, video, and playback modes.
- **USB Port:** For charging and data transfer.
- **Memory Card Slot:** For inserting the SD card.
- **Tripod Mount:** 1/4-inch thread for attaching to a tripod (not included).

Setup

1. Charging the Battery

1. Connect the camera to a power source using the provided USB charging cable.
2. The charging indicator light will illuminate.
3. Once fully charged, the indicator light will change or turn off.

2. Inserting the Memory Card

The camera supports standard SD cards up to 32GB. A 32GB memory card is included with your purchase.

1. Locate the memory card slot on the camera.
2. Insert the SD card with the metal contacts facing the correct direction (refer to the diagram near the slot if available) until it clicks into place.
3. To remove, gently push the card until it springs out.

3. Powering On/Off

- **To Power On:** Press and hold the Power button for a few seconds. The screen will illuminate.
- **To Power Off:** Press and hold the Power button again until the screen turns off.

Operating Instructions

1. Basic Operation

- **Mode Selection:** Use the Mode button to switch between Photo, Video, and Playback modes.
- **Screen Rotation:** The 2.4-inch LED flip screen can be rotated 270° for various viewing angles, including self-portraits.

2. Taking Photos

1. Switch the camera to Photo mode.
2. Frame your shot using the flip screen.
3. Adjust zoom using the zoom controls (up to 16x digital zoom).
4. Press the Shutter button halfway to focus (if applicable), then fully press to capture the image.

3. Recording Videos

1. Switch the camera to Video mode.
2. Frame your video using the flip screen.
3. Press the Shutter button to start recording. A recording indicator will appear on the screen.
4. Press the Shutter button again to stop recording.
5. The camera supports 1080P video resolution.

4. Using the Fill Light

The built-in fill light can be activated to provide additional illumination in dark environments.

- Locate the fill light button (refer to camera diagram if available).
- Press the button to turn the fill light on or off.

5. Advanced Functions

- **Selfies:** Utilize the 270° rotating screen to frame self-portraits.

- **Electronic Anti-Shake:** Helps stabilize images and videos during capture.
- **Loop Recording:** Records video in segments, overwriting the oldest files when the memory card is full.
- **Time Watermarking:** Adds a date and time stamp to your photos and videos.
- **External Microphone Support:** Connect an external microphone (not included) for enhanced audio quality.
- **Recording Pause:** Allows pausing and resuming video recording without creating multiple files.
- **Recording While Charging:** The camera supports operation while connected to a power source.

Maintenance

Cleaning the Camera

- Use a soft, dry cloth to clean the camera body.
- For the lens and screen, use a specialized lens cleaning cloth and solution. Avoid abrasive materials.
- Do not use organic solvents or strong chemicals.

Storage

- Store the camera in a cool, dry place away from direct sunlight and extreme temperatures.
- Remove the battery if the camera will not be used for an extended period.

Troubleshooting

Problem	Possible Cause	Solution
Camera does not power on.	Battery is low or depleted. Battery not inserted correctly.	Charge the battery. Ensure the battery is inserted with correct polarity.
Cannot take photos/record videos.	Memory card full or not inserted. Incorrect mode selected.	Insert a memory card or delete files. Ensure camera is in Photo/Video mode.
Images are blurry.	Lens is dirty. Insufficient light. Camera shake.	Clean the lens. Use the fill light or shoot in brighter conditions. Hold the camera steady or use a tripod.
Camera freezes or becomes unresponsive.	Software glitch.	Remove and reinsert the battery to reset the camera.

Specifications

Brand	CBDZONE
Model Name	D90 (Sanpylz5cn2ufweg-14)
Photo Sensor Technology	CMOS
Effective Still Resolution	16 MP
Video Resolution	1080p
Digital Zoom	16 x
Screen Size	2.4 Inches (Rotatable LED Flip Screen)
Image Stabilization	Digital

Supported Media Type	SD Card (up to 32GB)
Connectivity Technology	USB
Supported File Format	JPEG (Image), AVI (Video), MP3 (Audio)
Special Features	Adjustable, Built-in Fill Light, Self-Timer, Loop Recording, Time Watermarking, External Microphone Support, Recording Pause, Recording While Charging
Power Source	Battery (Not Included, but rechargeable via USB)
Color	BLACK

Warranty and Support

Warranty Information

This CBDZONE D90 Digital Camera comes with a manufacturer's warranty for 90 days from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact CBDZONE customer support. Refer to the contact information provided on the product packaging or the official CBDZONE website.

Online Support: www.cbdzone.com/support (Example Link)

Email: support@cbdzone.com (Example Email)

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FWXQBWWQ

More documents and user manuals: **https://manuals.plus/**