Karini H57X W18.1X D15

Karini 10-14 Gun Safe Instruction Manual

Model: H57"X W18.1"X D15"

1. Introduction

This manual provides essential instructions for the safe and proper assembly, operation, and maintenance of your Karini 10-14 Gun Safe. Please read this manual thoroughly before installation and use to ensure optimal security and functionality. Keep this manual for future reference.



Image 1.1: The Karini 10-14 Gun Safe, showcasing its exterior design with an electronic keypad and a separate lockable top compartment.

2. Safety Information

- Always store firearms unloaded and locked within the safe.
- Store ammunition in the separate, lockable top compartment to prevent unauthorized access.
- Keep keys and electronic passcodes in a secure location, inaccessible to children and unauthorized individuals.
- Mount the safe securely to a wall or floor using the provided expansion bolts to prevent tipping or removal.
- Regularly check the safe's locking mechanism and structural integrity.



Image 2.1: A visual representation highlighting the importance of child safety by securing firearms in the Karini gun safe.

3. Package Contents

Verify that all components are present before beginning assembly:

- Door Frame (x1)
- Side Panel (x2)
- Back Panel (x1)
- Cavity Plate (x3)
- Bottom Plate (x1)
- Septum (x1)
- Roof Plate (x1)
- Hole Plug
- Partition Buckle

- Self-Tapping Screws
- Metal Plate
- Expansion Screws (x4)
- Gun Bracket (x3)
- Gun Rack (x3)
- Gloves (x1 pair)
- Screwdriver (x1)
- Battery Box (External Power Box) (x1)
- Keys (x2 sets)
- Instruction Manual (this document)

4. Setup and Assembly

Assembly typically takes less than 20 minutes. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Assemble Side and Back Panels:** Connect the side panels to the back panel using the provided screws. Ensure proper alignment.
3. **Attach Door Frame:** Secure the door frame to the assembled panels.
4. **Install Roof and Bottom Plates:** Place and secure the roof plate and bottom plate into their respective positions.
5. **Insert Septum:** Install the septum to create the separate top storage compartment.
6. **Install Cavity Plates:** Place the cavity plates inside the main compartment.
7. **Attach Gun Brackets and Racks:** Secure the gun brackets and foam gun racks to the cavity plates at your desired height.
8. **Secure to Wall/Floor:** For maximum security, use the four expansion bolts to firmly attach the safe to a solid wall or floor.

Your browser does not support the video tag.

Video 4.1: Detailed assembly instructions for the Karini Gun Safe, demonstrating each step of the installation process.



Image 4.2: A diagram illustrating the external dimensions and internal layout of the Karini 10-14 Gun Safe.

5. Operating Instructions

5.1 First-Time Opening and Battery Installation

1. Locate the keyhole cover on the electronic keypad. Slide it to the left to reveal the keyhole.
2. Insert one of the provided keys into the keyhole and rotate it counter-clockwise.
3. Turn the keypad clockwise to open the gun cabinet door.
4. Inside the door, locate the battery compartment. Insert 4 AA alkaline batteries, ensuring correct polarity.
5. Close the battery compartment cover.

5.2 Setting Your Password

The original factory password is "1234".

1. With the door open, press the red "Setting Button" located on the inside of the door (near the battery compartment).

A green light will illuminate, and the safe will beep.

2. On the keypad, enter your desired 3-8 digit password.
3. Press the "#" key. A long beep indicates that the setting is successful.
4. Test your new password with the door open before closing it.

5.3 Unlocking Methods

The Karini Gun Safe offers three ways to unlock:

- **Digital Password Unlock:** Enter your set password on the electronic keypad and turn the handle.
- **Key Unlock:** Use the provided key in the keyhole, rotate, and turn the handle.
- **Emergency Power Unlock:** If the internal batteries are depleted, connect the external power box to the port on the keypad. Enter your password, and then turn the handle. Replace the internal batteries as soon as possible.



Image 5.1: Visual guide to the three unlocking methods: digital password, physical key, and emergency external power.

Your browser does not support the video tag.

Video 5.2: Demonstration of the three unlocking methods for the Karini Gun Safe, including electronic keypad, key, and emergency power supply.

5.4 Mute Function

- **To Turn On Mute:** Press the "#" key to awaken the keypad. Once the green light illuminates, enter "33#". The safe will enter silent mode.
- **To Turn Off Mute:** Press the "#" key to awaken the keypad. Once the green light illuminates, enter "66#". The safe will return to normal sound mode.

6. Features and Components

- **Premium Materials:** Constructed from thickened cold-rolled steel for robust anti-theft protection.
- **Reinforced Locking Bolts:** Features 4 reinforced active locking bolts to resist prying.
- **Separate Storage:** A lockable top compartment for pistols, ammunition, or valuables, separate from the main rifle storage.
- **Removable Shelves/Gun Racks:** Adjustable foam gun racks accommodate various firearm sizes (e.g., M1903, M14, Remington M870, MK12, M40A3).
- **180° Door Opening:** The door opens fully to 180 degrees for easy access to firearms.
- **LED Sensor Light:** A built-in LED light activates when the door is opened, providing visibility in low-light conditions.
- **Audible Alarm System:** An alarm activates after multiple incorrect password attempts.



Image 6.1: An open view of the Karini gun safe's interior, illustrating its capacity for rifles and pistols, along with the separate top storage.



Image 6.2: A visual emphasizing the premium materials and robust anti-theft performance of the Karini gun safe.

Your browser does not support the video tag.

Video 6.3: An overview of the Karini Gun Safe's features, including its interior layout, electronic lock, and LED lighting.

7. Maintenance

- **Cleaning:** Wipe the exterior with a soft, damp cloth. Avoid abrasive cleaners.
- **Battery Replacement:** Replace the 4 AA batteries in the electronic lock annually, or when the low battery indicator appears. Use only alkaline batteries.
- **Key Storage:** Store backup keys in a secure location outside the safe.

8. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Electronic lock not responding	Dead batteries	Use the emergency power box or the physical key to open the safe and replace the internal batteries.
Forgot password	Password forgotten	Use the physical key to open the safe. Reset the password following Section 5.2.
Safe is locked out (alarm sounds)	Multiple incorrect password attempts	The system will lock for 5 minutes. Wait for the lockout period to end, then try again with the correct password or use the physical key.
Door does not close properly	Obstruction or misalignment	Check for any items blocking the door or locking bolts. Ensure the safe is on a level surface.

9. Specifications

Feature	Specification
Brand	Karini
Product Dimensions	15"D x 18.1"W x 57"H
Lock Type	Electronic Combination Lock, Key
Color	Black
Capacity	2.6 Cubic Feet (holds 10-14 rifles/pistols)
Material	Metal (Thickened Cold-Rolled Steel)
Special Feature	Alarm System, LED Sensor Light, 180° Door
Mounting Type	Floor Mount (with expansion bolts)
Included Components	External Power Box, Screwdriver, Gloves
Item Weight	76.2 Pounds

10. Warranty and Support

For warranty information or technical support, please refer to the product packaging or contact Karini customer service through the retailer where the product was purchased. Keep your purchase receipt as proof of purchase.

© 2025 Karini. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question