**TEFTYMON P100**

# TEFTYMON 10 Inch Digital Picture Frame Instruction Manual

Model: P100

## Introduction

Thank you for choosing the TEFTYMON 10 Inch Digital Picture Frame. This device is designed to display your cherished photos and videos with clarity and ease. Featuring a high-quality IPS screen, 1080P video playback, and a user-friendly interface, it offers a versatile way to enjoy your digital memories. This manual will guide you through the setup, operation, and maintenance of your new digital picture frame.

## Setup Guide

### 1. Unpacking and Components

Carefully remove all components from the packaging. Ensure the following items are present:

- TEFTYMON 10 Inch Digital Picture Frame
- Power Adapter
- Remote Control
- User Manual (this document)

### 2. Power Connection

1. Connect the power adapter to the DC IN port on the back of the digital picture frame.
2. Plug the power adapter into a standard electrical outlet. The frame will typically power on automatically.



Image: The TEFTYMON 10 Inch Digital Picture Frame displaying a family photo, illustrating its primary function.

## 3. Inserting Storage Media (SD Card / USB Drive)

The frame supports SD cards and USB drives for media storage.

1. Locate the SD card slot or USB port on the side or back of the frame.
2. Insert your SD card or USB drive containing photos and videos into the appropriate slot. Ensure it is inserted correctly.
3. The frame will automatically detect the inserted media and may begin playing a slideshow.




Image: A diagram illustrating the connection of an SD card and a USB drive to the digital picture frame.

### 4. Initial Settings

Upon first use, you may need to configure basic settings such as language, time, and date. Use the remote control or the buttons on the frame to navigate the on-screen menu.

## Operating Instructions

### 1. Navigating the Menu

Use the remote control to access and navigate the frame's menu. The main menu typically includes options for Photos, Videos, Music, Calendar, and Settings.




Image: A hand holding the remote control, demonstrating its use with the digital picture frame.

### 2. Photo and Video Playback

- **Photos:** Select the "Photos" option from the main menu. You can browse individual photos or start a slideshow. The frame supports various image formats and displays them in high resolution.
- **Videos:** Select the "Videos" option to play 1080P videos. Ensure your video files are in a compatible format.




Image: The digital picture frame showcasing its IPS, Full HD (FHD), and 16:9 aspect ratio capabilities while playing a video.

## 3. Slideshow Settings

Customize your photo slideshow experience:

- **Slideshow Effects:** Choose from 14 different transition effects to enhance your photo display.
- **Slideshow Speed:** Adjust the display duration of each photo with 9 available speed settings.




Image: The digital picture frame showing calendar and alarm clock functions, surrounded by various photo slideshow examples.

## 4. Calendar and Alarm Clock

The frame includes a built-in calendar and alarm clock function. Access these features through the main menu to set reminders or view the date.




Image: The digital picture frame displaying a family photo, positioned alongside a physical calendar and alarm clock, highlighting its time-related features.

## 5. Multi-Angle Placement

The frame is designed for flexible placement, supporting both horizontal and vertical orientations on a surface, or wall-mounted. Adjust the integrated stand for optimal viewing angles.



Image: The digital picture frame displayed in multiple orientations, including horizontal, vertical, and wall-mounted, demonstrating its versatile placement options.

## Maintenance

- **Cleaning the Screen:** Use a soft, lint-free cloth to gently wipe the screen. For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution. Avoid harsh chemicals.
- **Cleaning the Frame:** Wipe the frame's exterior with a dry, soft cloth.
- **Storage:** When not in use for extended periods, store the frame in a cool, dry place away from direct sunlight and extreme temperatures.
- **Power Off:** Always power off the device correctly before unplugging it.

## Troubleshooting

### Common Issues and Solutions:

**Frame does not power on:**
- Ensure the power adapter is securely connected to both the frame and a working electrical outlet.
- Check if the power outlet is functional by plugging in another device.

**Remote control is not responding:**
- Check and replace the batteries in the remote control.
- Ensure there are no obstructions between the remote control and the frame's IR receiver.
- Point the remote directly at the frame.

**Photos or videos are not displaying:**
- Verify that the SD card or USB drive is inserted correctly and fully into its slot.
- Ensure the photo and video files are in compatible formats (e.g., JPEG for photos, MP4 for videos). Some mobile phone formats may require conversion.
- Check if the storage media is corrupted or empty. Try using a different SD card or USB drive.
- The frame supports up to 32GB memory storage capacity. Ensure your media is within this limit.

**Images appear distorted or have incorrect colors:**
- Adjust the brightness and contrast settings in the frame's menu.
- Ensure the image files themselves are not corrupted or low resolution.

**No sound from videos:**
- Check the volume settings on the frame.
- Ensure the video file contains an audio track and is not muted.

## Specifications

| Feature | Detail |
|---|---|
| Brand | TEFTYMON |
| Model Number | P100 (AGM-US-P100) |
| Screen Size | 10.1 inches |
| Resolution | 1080p (Full HD) |
| Aspect Ratio | 16:9 |
| Display Type | IPS |
| Viewing Angle | 178° Wide |
| Memory Storage Capacity | 32 GB (via SD card/USB) |
| Connectivity Technology | USB |
| Power Source | Corded Electric |

| | |
|---|---|
| Color | Black |
| Item Dimensions (L x W) | 10"L x 6"W |

## Warranty and Support

### Warranty Information

This TEFTYMON Digital Picture Frame comes with a**2-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.
The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

### Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty inquiries, please contact TEFTYMON customer support. Refer to the contact information provided on the product packaging or the official TEFTYMON website.


## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question