Samsung X230

Samsung Galaxy Tab A11+ Plus 2026 Wi-Fi Tablet User Manual

Model: X230

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Samsung Galaxy Tab A11+ Plus 2026 Wi-Fi Tablet. Please read this manual thoroughly to ensure proper use and to maximize the device's capabilities.

The Samsung Galaxy Tab A11+ Plus is designed for versatile use, featuring an 11-inch 90Hz display, an Octa-Core (4nm) processor, 6GB RAM, 128GB internal storage, and quad speakers with Dolby Atmos. It operates on Android 16 and supports Wi-Fi connectivity.

2. Getting Started

2.1. What's in the Box

Verify that your package contains the following items:

- Samsung Galaxy Tab A11+ Plus Tablet
- USB Type-C Cable
- 20W UL Fast Charger Cube
- SIM Ejector Tool (for microSD card tray access)
- Quick Start Guide (not included in this digital manual)



Image: Back of the Galaxy Tab A11+ Plus tablet (1), a USB Type-C charging cable (2), and a SIM ejector tool (3).

2.2. Device Layout

Image: Rear view of two Galaxy Tab A11+ Plus tablets, showcasing their sleek design.

Image: Dimensions of the tablet, approximately 16.8 cm (6.6 inches) wide, 25.7 cm (10.1 inches) long, and 0.6 cm (0.27 inches) thick.

2.3. Initial Charging

Before first use, fully charge your tablet using the provided USB Type-C cable and 20W UL Fast Charger Cube. Connect the cable to the tablet's USB-C port and the charger to a power outlet.

2.4. Power On/Off

- To power on: Press and hold the Power button until the Samsung logo appears.
- To power off: Press and hold the Power button, then select 'Power off' on the screen.

2.5. Initial Setup

Upon first power-on, follow the on-screen instructions to complete the initial setup wizard. This includes selecting your language, connecting to a Wi-Fi network, and signing in with your Google account.

3. Operating Your Tablet

3.1. Touchscreen Navigation

The tablet features a responsive touchscreen. Use the following gestures:

- **Tap:** Select an item or open an app.
- **Touch and hold:** Access contextual menus or move items.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.

3.2. Wi-Fi Connectivity

As a Wi-Fi only device, a stable internet connection is crucial. To connect to Wi-Fi:

1. Go to **Settings** > **Connections** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list.
4. Enter the password if prompted, then tap **Connect**.

3.3. Apps and Multitasking

The tablet runs Android 16 with One UI 8, allowing for efficient app management and multitasking.

- **Opening Apps:** Tap the app icon on the Home screen or in the Apps drawer.
- **Switching Apps:** Tap the Recent Apps button (usually a square icon) to view and switch between open applications.
- **Split Screen:** For multitasking, open the Recent Apps screen, tap the app icon at the top of an app's card, and select 'Open in split screen view'.



Image: The tablet displaying multiple applications in a split-screen view, illustrating its multitasking feature.

3.4. Audio and Visual Experience

The 11-inch TFT LCD display with a 90Hz refresh rate provides a smooth visual experience. The tablet is equipped with 4 speakers and Dolby Atmos for immersive audio.



Image: The tablet showcasing its immersive audio experience with Dolby Atmos.

3.5. Camera Usage

The tablet features an 8MP rear camera with autofocus and a 5MP front camera. Both support 1080p video recording.

- Open the **Camera** app.
- Tap the **Shutter** button to take a photo.
- Switch between photo and video modes as needed.

3.6. Storage Management

Your tablet comes with 128GB of internal storage. You can expand this using a microSD card.



Image: The tablet highlighting its storage capabilities, including support for microSD cards up to 2TB.

3.7. Samsung Kids App

The preloaded Samsung Kids app provides a secure digital environment for children. Access it from the Quick Panel. Parental controls allow you to manage content and screen time.



Image: The tablet running the Samsung Kids app, offering a safe and engaging environment for children.

4. Maintenance

4.1. Cleaning Your Tablet

To clean your tablet, use a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner designed for electronics. Avoid harsh chemicals or abrasive materials.

4.2. Software Updates

Keep your tablet's software up to date to ensure optimal performance and security. Updates for Android 16 and One UI 8 will be provided periodically.

- Go to **Settings** > **Software update**.
- Tap **Download and install**.

4.3. Battery Care

The tablet is equipped with a 7040mAh battery. To prolong battery life:

- Avoid extreme temperatures.
- Do not let the battery drain completely before recharging regularly.
- Use the provided 20W fast charger for efficient charging.

Image: The tablet highlighting its long battery life and fast charging capabilities.

5. Troubleshooting

If you encounter issues with your tablet, try the following solutions:

5.1. Device Not Powering On

- Ensure the battery is charged. Connect the tablet to the charger for at least 10 minutes before attempting to power on.
- Press and hold the Power button for 10-15 seconds to perform a forced restart.

5.2. Wi-Fi Connection Issues

- Restart your Wi-Fi router and the tablet.
- Forget the network in Wi-Fi settings and reconnect.
- Ensure you are within range of the Wi-Fi signal.

5.3. Apps Crashing or Freezing

- Close and reopen the app.
- Clear the app's cache and data in **Settings** > **Apps** > [App Name] > **Storage**.
- Update the app from the Google Play Store.

5.4. Entering Safe Mode

If your tablet continuously enters Safe Mode, it might indicate an issue with a recently installed app. To exit Safe Mode, restart your device. If it persists, try uninstalling recently added applications one by one to identify the problematic app.

5.5. Factory Reset

As a last resort, you can perform a factory reset. This will erase all data on your tablet, so back up important

information first.

1. Go to **Settings** > **General management** > **Reset**.
2. Select **Factory data reset** and follow the on-screen prompts.

6. Specifications

Below are the technical specifications for the Samsung Galaxy Tab A11+ Plus 2026 (Model X230):

Image: The tablet illustrating its improved CPU and GPU performance.

Feature	Specification
Model Name	Galaxy Tab A11+
Model Number	X230 (SM-X230NZAAMXO)
Operating System	Android 16 (One UI 8)
Processor	Mediatek Dimensity 7300 (4 nm) Octa-core
RAM	6 GB
Internal Storage	128 GB
Expandable Storage	microSD (up to 2TB)
Screen Size	11.0 inches
Display Type	TFT LCD
Resolution	1920 x 1200 (WUXGA)
Refresh Rate	90Hz
Rear Camera	8 MP, AF
Front Camera	5 MP
Video Recording	1080p FHD
Audio	4 Stereo Speakers with Dolby Atmos
Battery Capacity	7040 mAh
Charging	20W Fast Charging (USB Type-C 2.0)
Connectivity	Wi-Fi (802.11b/g/n), Bluetooth 5.1
Dimensions (L x W x T)	10.12" x 6.64" x 0.27" (25.7 cm x 16.8 cm x 0.6 cm)
Weight	1.5 Pounds (approx. 680g)

7. Warranty and Support

7.1. Warranty Information

This is an International Model and does not include a Domestic Warranty.
The device is covered by the Seller's Return Policy. Please refer to your purchase documentation or contact the seller for details regarding their return policy and any applicable support.

7.2. Customer Support

For further assistance, technical support, or service inquiries, please contact the retailer or seller from whom you purchased the device. You may also visit the official Samsung support website for general product information and resources, though specific warranty claims for this international model should be directed to your seller.

© 2026 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question