Moosum MO-SMCB05US-SS

Moosum 20-Cup Rice Cooker Instruction Manual

Model: MO-SMCB05US-SS

Introduction

Thank you for choosing the Moosum 20-Cup Rice Cooker. This appliance is designed to provide versatile and healthy cooking options for your kitchen. Featuring an 8-in-1 functionality and a durable stainless steel inner pot and steamer, it simplifies meal preparation. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use the appliance for other than intended use.
- This appliance is for household use only.

Product Components

The Moosum Rice Cooker comes with the following components:

- Main Rice Cooker Unit
- Stainless Steel Inner Pot
- Stainless Steel Steamer Basket
- Rice Spoon
- Soup Ladle
- Rice Measuring Cup
- Removable Inner Cover



Image: Moosum Rice Cooker components and dimensions. The image displays the main unit, a stainless steel inner pot, a stainless steel steamer basket, a measuring cup, and a spoon, with dimensions indicating the cooker's height and width.

Setup and First Use

Unpacking

Carefully remove all packaging materials and the rice cooker from the box. Retain packaging for future storage or transport if needed.

Initial Cleaning

1. Wash the stainless steel inner pot, stainless steel steamer basket, rice spoon, soup ladle, and measuring cup with warm, soapy water. Rinse thoroughly and dry completely.
2. Wipe the exterior of the main rice cooker unit with a damp cloth. Do not immerse the main unit in water.
3. Ensure all parts are dry before assembly and use.

Placement

Place the rice cooker on a stable, level, heat-resistant surface, away from water and heat sources. Ensure there is adequate ventilation around the unit.



Image: Stainless Steel Inner Pot and Steamer. This image shows the stainless steel inner pot and steamer basket, emphasizing their construction from 304 stainless steel, being free of PFAS & PFOA, non-toxic fumes, and durability.

Operating Instructions

General Operation

1. Measure the desired amount of rice using the provided measuring cup. Rinse the rice thoroughly until the water runs clear.
2. Place the rinsed rice into the stainless steel inner pot. Add water according to the rice type and desired consistency. Refer to the cooking guide below.
3. Place the inner pot into the main rice cooker unit. Close the lid securely.
4. Plug the power cord into a grounded electrical outlet.
5. Select the desired cooking function using the control panel. The cooker features 8 functions: Rice, Fry, Milk porridge, Yogurt, Pasta, Cake, Soup, and Steam.
6. Press the 'Start' button to begin cooking. The indicator light for the selected function will illuminate.
7. Once cooking is complete, the cooker will automatically switch to 'Keep Warm' mode.
8. Unplug the appliance after use and allow it to cool before cleaning.

Rice Cooking Guide

Use the provided measuring cup (1 cup = 3/4 U.S. Cup) for accurate measurements.

Uncooked Rice	Volume	Water Line (Inner Pot)	Approx. Cook Time	Cooked Yield
White Rice	4 cup	Line 4	16 min	8 cups
White Rice	6 cup	Line 6	19 min	12 cups
White Rice	8 cup	Line 8	22 min	16 cups
White Rice	10 cup	Line 10	24 min	20 cups



Image: Large Capacity and Rice Cooking Guide. This image provides a detailed table for cooking white rice, specifying the amount of uncooked rice, corresponding water line in the inner pot, approximate cooking time, and the resulting cooked yield. It also shows the rice cooker and several bowls of cooked rice.

8 Smart Functions

The Moosum Rice Cooker offers 8 versatile cooking functions:

- **Rice:** For perfectly cooked rice.
- **Fry:** For sautéing or light frying.
- **Milk Porridge:** For creamy milk-based porridges.
- **Yogurt:** For preparing homemade yogurt.
- **Pasta:** For cooking various types of pasta.
- **Cake:** For baking simple cakes.
- **Soup:** For preparing soups and stews.
- **Steam:** For steaming vegetables, fish, or other foods using the steamer basket.

After cooking, the appliance automatically switches to a 'Keep Warm' function, maintaining the food's temperature for

over 24 hours.



Image: 8 Smart Functions. This image illustrates the versatility of the Moosum Rice Cooker by showcasing different dishes prepared using its eight functions: rice, yogurt, fried food, milk porridge, pasta, cake, soup, and steamed vegetables.

Maintenance and Cleaning

Proper maintenance ensures the longevity and optimal performance of your rice cooker.

Cleaning the Inner Pot and Steamer

The stainless steel inner pot and steamer basket are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge. Rinse thoroughly and dry completely.

Cleaning the Removable Inner Cover

The inner cover can be removed for easy cleaning. Wash it with warm, soapy water, rinse, and dry before reattaching.

Cleaning the Main Unit

Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or scourers. Never immerse the main unit in water or any other liquid.



Image: Dishwasher Safe Components. This image shows the stainless steel inner pot and steamer basket inside a dishwasher, indicating that these components are safe for machine washing.

Troubleshooting

If you encounter any issues with your Moosum Rice Cooker, please refer to the following common problems and solutions:

- **Cooker does not turn on:** Ensure the power cord is securely plugged into both the cooker and a working electrical outlet. Check your household circuit breaker.
- **Rice is too dry/hard:** You may need to add slightly more water for your specific rice type or preference. Ensure the lid is properly sealed during cooking.

- **Rice is too wet/mushy:** You may need to reduce the amount of water. Ensure the rice is rinsed properly before cooking.
- **Rice sticks to the bottom:** Ensure the inner pot is clean and dry before adding rice and water. Some rice types are more prone to sticking; a thin layer of cooking oil can sometimes help.
- **Steam escaping from lid:** Check that the lid is properly closed and sealed. Ensure the removable inner cover is correctly installed.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Detail
Brand	Moosum
Model Name	MO-SMCB05US-SS
Capacity	10-cup uncooked (20-cup cooked) / 5 Quarts
Product Dimensions	11.06"D x 10.55"W x 11.57"H
Material	Stainless Steel (Inner Pot, Steamer, Lid)
Color	Silver
Wattage	1200 watts
Voltage	120 Volts
Item Weight	10.58 Pounds
Special Feature	8-in-1 Functionality, Auto Keep Warm, Removable Inner Cover
Product Care Instructions	Do not shake vigorously; Inner pot and steamer are dishwasher safe.

Warranty and Support

For warranty information or customer support, please refer to the product packaging or contact Moosum customer service directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question