LKKNC 5016SV

LKKNC 90KPa Portable Vacuum Sealer Machine - Model 5016SV Instruction Manual

Brand: LKKNC | Model: 5016SV

Introduction

Welcome to your new LKKNC 90KPa Portable Vacuum Sealer Machine. This manual provides essential information for safe and efficient operation, maintenance, and troubleshooting. This versatile appliance is designed to extend the freshness of your food by removing air and sealing it in specialized bags or containers.

Important Safety Instructions

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure the appliance is connected to a grounded electrical outlet with the correct voltage (120 Volts).
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep hands clear of the sealing strip during operation as it becomes hot.
- Do not operate the appliance with a damaged cord or plug, or if it malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Supervise children to ensure they do not play with the appliance.

What's Included

Your LKKNC Vacuum Sealer Machine package includes the following items:

- 1 x LKKNC Vacuum Sealer Machine
- 1 x Vacuum Bag Roll (11" x 10')
- 5 x Small Pre-cut Bags (6" x 8")
- 10 x Large Pre-cut Bags (8" x 11")
- 1 x Air Suction Hose

- 1 x External Interface
- 1 x Instruction Manual (this document)

Product Overview

Familiarize yourself with the main parts and controls of your vacuum sealer.



Image: A silver and black LKKNC vacuum sealer machine on a kitchen counter, surrounded by fresh produce and a vacuum-sealed steak, illustrating its primary function.

Image: An exploded diagram of the vacuum sealer showing its internal components, including the control panel, built-in cutter, silicone seal strip, and vacuum chamber, highlighting its design features.

Setup

Initial Preparation

1. Unpack the vacuum sealer and all accessories from the packaging.
2. Place the unit on a flat, stable, and dry surface.
3. Plug the power cord into a grounded electrical outlet. The display will illuminate.

Installing and Using the Bag Roll and Cutter

The machine features a built-in compartment for a bag roll and a sliding cutter to create custom-sized bags.

1. Press the 'Push Here to Open' button on the side to open the lid.

2. Place the vacuum bag roll into the designated compartment inside the machine.
3. Pull out the desired length of bag material.
4. Use the two-way sliding cutter to cut the bag to your preferred size. Ensure one end of the cut bag is sealed before use. If not, use the 'Seal' function (see Instant Seal Function).



Image: A person demonstrating how to install the vacuum bag roll into the machine's internal compartment and use the built-in sliding cutter to create custom-sized bags.

Video: This video demonstrates the unboxing of the vacuum sealer, including the included accessories like pre-cut bags and the external vacuum hose. It also shows how to use the built-in bag cutter to create custom-sized bags from the roll, and the process of vacuum sealing various food items.

Operating Instructions

Basic Vacuum Sealing (Dry/Moist Foods)

1. **Prepare Food:** Place the food item into a vacuum sealer bag. Ensure there is at least 3 inches of space between the food and the open end of the bag. The open end must be clean and dry.
2. **Open Lid:** Press the 'Push Here to Open' button on the side to open the lid.
3. **Position Bag:** Place the open end of the bag flat into the vacuum chamber, ensuring it is within the rubber gasket.
4. **Close and Lock Lid:** Close the lid firmly until both sides click into place. The digital display should show "88" to indicate the lid is securely locked. If it shows "OP", the lid is not locked.
5. **Select Food Type:** Press the "Dry" button for dry food items or the "Moist" button for moist food items.
6. **Start Sealing:** Press the "Seal" button to initiate the vacuum and sealing process. The machine will automatically remove air and then seal the bag.
7. **Remove Bag:** Once the process is complete, the display will show "OP". Press the 'Push Here to Open' button to release the lid and remove your sealed bag.



Image: The LKKNC vacuum sealer actively sealing a bag containing food, with the control panel illuminated, demonstrating the automatic sealing process.

Pulse Vacuum for Delicate Items

This function allows for manual control over the vacuum process, ideal for delicate foods that might be crushed by full vacuum.

1. Follow steps 1-4 from Basic Vacuum Sealing.
2. Press the "Pulse Vacuum" button. The machine will begin to vacuum in short bursts.
3. Monitor the vacuum process. Once the desired vacuum level is reached (before crushing delicate items), press the "Seal" button to seal the bag.
4. Once complete, the display will show "OP". Press the release button to open the lid and remove the sealed bag.

Canister Vacuum

Use the external air suction hose to vacuum seal compatible canisters or containers.

1. Connect one end of the air suction hose to the accessory port on the vacuum sealer.
2. Connect the other end of the hose to the port on your vacuum-sealable canister.
3. Ensure the canister lid is properly closed and sealed.
4. Press the "Canister" button on the vacuum sealer. The machine will begin to extract air from the canister.
5. The machine will automatically stop when the vacuum is complete.



Image: A three-step visual guide demonstrating how to use the external hose to vacuum seal food in a canister, showing the connection points and operation.

Instant Seal Function

This function allows you to seal bags without vacuuming, useful for creating custom bags from a roll or sealing delicate items that do not require vacuuming.

1. Place the open end of the bag onto the sealing strip.
2. Close the lid firmly until both sides click into place.
3. Press the "Seal" button. The machine will only seal the bag without extracting air.
4. Once complete, the display will show "OP". Press the release button to open the lid and remove the sealed bag.

Maintenance and Cleaning

Cleaning Your Vacuum Sealer

The LKKNC Vacuum Sealer features a modular detachable base and lid design for easy cleaning.

1. Ensure the appliance is unplugged from the electrical outlet before cleaning.
2. Press the 'Push Here to Open' button to open the lid. The base and lid can be fully separated.
3. The built-in reservoir (drip tray) detaches effortlessly. Remove it and rinse it under running water to clean any trapped residue or grime.
4. Wipe the exterior of the machine with a damp cloth. Do not immerse the main unit in water.
5. Ensure all parts are completely dry before reassembling and storing the appliance.



Image: A person removing and rinsing the detachable drip tray under running water, demonstrating the ease of cleaning the vacuum sealer's components.

Troubleshooting

If you encounter issues with your LKKNC Vacuum Sealer, refer to the following common problems and solutions:

- **Machine not turning on:** Check that the power cord is securely plugged into a working electrical outlet.
- **Machine not vacuuming properly:**
  - Ensure the lid is fully locked. The digital display should show "88". If it shows "OP", press down firmly on

both sides of the lid until it locks.
    - Verify that the open end of the bag is correctly positioned within the vacuum chamber and rubber gasket.
    - Inspect the rubber gaskets for any debris, food particles, or damage that might prevent a proper seal. Clean if necessary.
- **Bag not sealing:**
    - Ensure the sealing strip is clean and dry.
    - Check for wrinkles or folds in the bag material along the sealing area. Smooth out any wrinkles before closing the lid.
- **Air leaking from sealed bag:**
    - Ensure you are using compatible vacuum sealer bags designed for this appliance.
    - Inspect the sealed bag for any punctures, tears, or incomplete seals.

Product Specifications

Feature	Specification
Brand	LKKNC
Model	5016SV
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Silver
Product Dimensions	15.95"L x 6.7"W x 3.82"H
Item Weight	4.85 Pounds
Operation Mode	Automatic
Wattage	220 watts
Voltage	120 Volts
UPC	740625069982

Warranty and Support

Warranty Information

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions regarding coverage, duration, and claims procedures.

Customer Support

For technical assistance, product inquiries, or service requests, please contact LKKNC customer support. Contact information can typically be found on the product packaging or the official LKKNC website.

© 2025 LKKNC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question