AKLUER B0FYML5R4V

Akluer Walking Pad Treadmill with Adjustable Desk Instruction Manual

Model: B0FYML5R4V

Important Safety Instructions

Please read this entire manual carefully before operating the Akluer Walking Pad Treadmill with Adjustable Desk. Retain this manual for future reference. Failure to follow these instructions may result in injury or damage to the product.

- Always place the treadmill on a flat, stable surface.
- Keep children and pets away from the treadmill during operation.
- Ensure the safety key is properly attached to your clothing before starting the treadmill. In case of emergency, the safety key will stop the machine.
- Do not use the treadmill if you weigh more than 330 lbs (150 kg).
- Wear appropriate athletic footwear during use.
- Do not operate the treadmill if it has a damaged cord or plug, or if it is not working properly.
- Unplug the treadmill from the power outlet when not in use, before cleaning, or before performing any maintenance.
- Consult a physician before starting any exercise program.

Product Overview

The Akluer Walking Pad Treadmill with Adjustable Desk is designed for home and office use, offering a convenient way to integrate walking into your daily routine. It features a compact design, quiet operation, and an integrated adjustable desk for multitasking.



This image displays the Akluer Walking Pad Treadmill with its integrated adjustable desk. A person is shown walking on the treadmill, demonstrating its use in a home or office setting. The desk height is adjustable, as indicated by the graphic on the right, allowing for comfortable use while walking.

Key Features:

- **Integrated Adjustable Desk:** Features a built-in controller, charging socket, iPad stand, and cup holder.
- **Compact Design:** Easy to set up and store, ideal for maximizing fitness space.

- **Dual Control Options:** Operate via a desktop control box or the included remote control.
- **Safety Controller:** Equipped with a safety key for immediate machine stop.
- **Quiet 2.5HP Motor:** Supports users up to 330 lbs with speeds from 0.6-6.2 MPH, operating below 45dB.
- **Advanced Running Belt:** 16.5-inch × 41.3-inch belt with a 5-layer anti-slip surface, 6 silicone shock absorbers, and reinforced cushioning pads for joint protection.

Setup and Assembly

The Akluer Walking Pad Treadmill is designed for quick and simple assembly, typically completed within 10 minutes.

Unpacking:

1. Carefully remove all components from the packaging.
2. Check the contents against the packing list to ensure all parts are present.
3. Place the main treadmill unit on a clear, flat surface.

Assembly Steps:

1. Attach the adjustable desk frame to the main treadmill unit using the provided hardware. Ensure all screws are tightened securely.
2. Mount the desktop surface onto the desk frame.
3. Connect any necessary cables as indicated in the quick start guide (refer to included documentation for detailed diagrams).
4. Ensure the treadmill is stable and all connections are firm before proceeding.

Adjusting the Desk Height:

The desk height can be adjusted up to 13 inches. Locate the adjustment knobs or levers on the desk frame. Loosen them, adjust the desk to your desired height, and then securely tighten the knobs/levers to lock the desk in place.

Operating Instructions

Powering On/Off:

- Plug the power cord into a grounded electrical outlet.
- Locate the main power switch, usually at the front of the treadmill, and switch it to the 'ON' position.
- To power off, switch the main power switch to 'OFF' and unplug the unit.

Using the Safety Key:

Before each use, attach the safety key clip to your clothing. Insert the magnetic end of the safety key into the designated slot on the treadmill console. The treadmill will not operate without the safety key in place. Pulling the safety key out will immediately stop the treadmill.

Controlling the Treadmill:

The treadmill offers two control methods:

- **Desktop Control Box:** Located on the adjustable desk, this panel allows you to start/stop the treadmill, adjust speed, and pause your workout without bending over.
- **Remote Control:** Use the provided remote control to conveniently power on/off, adjust speed, and pause the

treadmill from a distance. Ensure the remote has fresh batteries.

Starting a Workout:

1. Stand on the side rails of the treadmill.
2. Attach the safety key.
3. Press the 'Start' button on the desktop control box or remote. The treadmill will typically begin with a low speed after a short countdown.
4. Carefully step onto the running belt and gradually increase the speed to your desired pace using the '+' or '-' buttons.

Ending a Workout:

- Press the 'Stop' or 'Pause' button on the control box or remote.
- Alternatively, pull the safety key to immediately stop the treadmill.
- Once the belt has come to a complete stop, step off the treadmill.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your Akluer Walking Pad Treadmill.

Cleaning:

- Always unplug the treadmill before cleaning.
- Wipe down the console, desk, and exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- Periodically vacuum under the treadmill to prevent dust buildup.

Lubrication:

The Akluer Walking Pad Treadmill features a pre-lubricated belt. Under normal use, additional lubrication may not be required frequently. However, if you notice increased friction or noise, consult the specific lubrication instructions provided in the quick start guide or contact customer support.

Belt Adjustment:

If the running belt becomes off-center or slips, it may require adjustment. Refer to the detailed instructions in the quick start guide for proper belt centering and tensioning procedures. Incorrect adjustment can damage the belt or motor.

Storage:

When not in use, store the treadmill in a clean, dry environment. Its compact design allows for easy storage in smaller spaces.

Troubleshooting

If you encounter issues with your treadmill, refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Treadmill does not start	Power cord unplugged; Main switch off; Safety key not in place; Circuit breaker tripped.	Ensure power cord is securely plugged in; Turn main switch ON; Insert safety key fully; Check household circuit breaker.
Running belt slips or hesitates	Belt too loose; Belt needs lubrication; User weight exceeds capacity.	Adjust belt tension (refer to manual); Lubricate belt if necessary; Ensure user weight is within limits.
Unusual noise during operation	Loose parts; Belt friction; Motor issue.	Check and tighten all visible bolts and screws; Lubricate belt; If noise persists, contact customer support.
Remote control not working	Dead batteries; Obstruction between remote and receiver.	Replace remote control batteries; Ensure clear line of sight to the treadmill's receiver.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Feature	Specification
Brand	AKLUER
Model	B0FYML5R4V
Color	Black-Desk
Product Dimensions (D x W x H)	49.2" x 23.6" x 4.72"
Item Weight	70.6 Pounds
Material	Alloy Steel
Maximum Speed	6.2 Miles per Hour
Maximum Horsepower	2.5 Horsepower
Weight Capacity	330 lbs
Noise Level	Below 45dB
Running Belt Dimensions	16.5" x 41.3"
Special Features	Compact Design, Shock Absorbent, USB Charging Port, Water Bottle Holder
Target Audience	Adult

Warranty and Support

AKLUER is committed to providing high-quality products and customer satisfaction. This product comes with a **12-month**

satisfactory service guarantee.

If you have any questions, concerns, or require assistance with your Akluer Walking Pad Treadmill, please do not hesitate to contact our customer support team. Please have your model number (B0FYML5R4V) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question