Moosum B0FZ8J12MX

Moosum 36-Inch 5-Burner Electric Cooktop with Built-in Griddle

Model: B0FZ8J12MX

1. Introduction

This manual provides essential information for the safe and efficient operation of your new Moosum 36-Inch 5-Burner Electric Cooktop. Please read all instructions carefully before installation and use. Keep this manual for future reference.

Important Safety Information

- Ensure the cooktop is installed by a qualified electrician, as it requires a 220-240V hardwired connection (plug not included).
- Do not touch hot surfaces. Use handles or knobs.
- Never leave the cooktop unattended during operation.
- Keep children away from the cooktop during use and when it is cooling down.
- Do not use the cooktop as a storage surface.

2. Product Features

- **Professional-Grade Heating:** 5 burners with 9 precise power levels for rapid and even heat distribution, suitable for frying, sautéing, boiling, and simmering. Includes an integrated griddle for expanded cooking versatility.
- **Universal Cookware Compatibility:** Works with all types of cookware, including stainless steel, cast iron, and ceramic.
- **Durable Ceramic Glass Top:** Features a scratch-resistant ceramic glass surface that cools rapidly and is easy to clean.
- **Enhanced Safety:** Equipped with a child lock to prevent accidental activation, auto shut-off, and overheating protection for safe operation, ideal for households with children or pets.
- **Smart Cooking Functions:** Built-in 99-minute timer with a keep-warm function, perfect for meal prepping, holiday dinners, or slow-cooking.
- **Versatile Design:** 36-inch sleek profile designed to fit standard countertops. Burner power distribution: 2x 1200W, 1x 1800W, 1x 2000W, 1x 2300W, allowing multiple dishes to be cooked simultaneously.



Figure 2.1: Overview of Moosum 36-Inch Electric Cooktop features.

3. Specifications

Feature	Description
Brand	Moosum
Model Number (ASIN)	B0FZ8J12MX
Installation Type	Built-in / Freestanding
Burner Type	Electric (Radiant)
Number of Burners	5
Power Levels	9 Precise Settings
Wattage	2300 watts (individual burner max), up to 9000W total
Voltage	220-240V
Control Type	Digital Touch
Special Features	Melt Setting, Safety Lock, 99-Minute Timer, Keep-Warm Function, Overheating Protection
Surface Material	Ceramic Glass
Included Components	Cooktop unit, Integrated griddle

4. Installation

Proper installation is crucial for the safe and optimal performance of your electric cooktop. It is highly recommended that installation be performed by a qualified and licensed electrician.

Pre-Installation Checklist:

- Verify that the electrical supply meets the cooktop's requirements (220-240V).
- Ensure the countertop cutout dimensions match the cooktop's specifications.
- Confirm that all necessary wiring and circuit breakers are in place and meet local electrical codes.

Wiring Instructions:

The cooktop requires a hardwired connection. Refer to the diagram below for proper wiring. Connect the red, black, and yellow/green wires from the cooktop to the corresponding wires from your home power supply (L1, L2, and Ground bar) via a double pole breaker.



Figure 4.1: Cooktop dimensions and wiring diagram.

Cutout Dimensions:

- Overall Cooktop Dimensions: Approximately 36 inches (900mm) wide x 20.47 inches (520mm) deep.
- Built-in Depth: Approximately 1.73 inches (48mm).
- Cutout Width: Approximately 34.25 inches (870mm).
- Cutout Depth: Approximately 19.29 inches (490mm).

5. Operation

The Moosum Electric Cooktop features intuitive digital touch controls for easy operation.

Powering On/Off:

- Press the **ON/OFF** button to activate or deactivate the cooktop.

Selecting a Cooking Zone and Adjusting Power:

- Touch the desired cooking zone indicator.
- Use the **+** and **-** buttons to select one of the 9 power levels. The central burner offers variable power settings (1000W, 2000W, 3000W) for different cooking needs.

Timer Function:

- Activate the timer by pressing the **Timer** button.
- Adjust the time up to 99 minutes using the **+** and **-** controls. The cooktop will automatically shut off once the set time expires.

Child Safety Lock:

- To engage the child lock, press and hold the **Lock** button for a few seconds until the indicator lights up. This prevents accidental changes to settings or activation of burners.
- To unlock, press and hold the **Lock** button again.

Pause Function:

- Press the **Pause** button to temporarily halt all active cooking zones. Press again to resume.



Figure 5.1: Digital touch controls and safety features.

Your browser does not support the video tag.

Video 5.1: Demonstration of AMZCHEF electric cooktop features, including power settings and controls.

Your browser does not support the video tag.

Video 5.2: Jessier 30-Inch Electric Stove Top showcasing burner sizes, timer, and child lock settings.

Your browser does not support the video tag.

Video 5.3: OmniEase Electric Cooktop 36 Inch demonstrating ultra-fast heating, 9-level precise control, 99-minute timer, and child lock.

Your browser does not support the video tag.

Video 5.4: ThermoMate 36 Inch Electric Cooktop highlighting 9000W power, 5 burners, knob control, and hot surface indicator.

Your browser does not support the video tag.

Video 5.5: Empava 36 Inch Electric Ceramic Cooktop 36REC14 showing cooking various dishes and touch controls.

6. Care and Maintenance

To maintain the appearance and performance of your cooktop, follow these cleaning guidelines:

- **Daily Cleaning:** Wipe the ceramic glass surface with a soft cloth and a mild cleaner after each use. Ensure the surface has cooled down before cleaning.
- **Stubborn Stains:** For burnt-on food or stubborn stains, use a ceramic cooktop cleaner and a non-abrasive pad. Follow the cleaner's instructions.
- **Avoid Abrasives:** Do not use abrasive sponges, scouring pads, or harsh chemical cleaners, as these can scratch or damage the glass surface.
- **Control Panel:** Wipe the touch control panel with a damp cloth. Avoid excessive moisture.



Figure 6.1: Cleaning the ceramic glass surface.

7. Troubleshooting

If you encounter issues with your cooktop, refer to the following common troubleshooting tips:

- **Cooktop Not Powering On:** Check the circuit breaker to ensure it hasn't tripped. Verify that the cooktop is properly hardwired.
- **Burner Not Heating:** Ensure the correct cooking zone is selected and the power level is set. Check if the child lock is engaged.
- **Error Codes:** If an error code appears on the display, consult the full product manual (if provided separately) or contact customer support for specific guidance.
- **Overheating Protection Activated:** If the cooktop automatically shuts off, it may be due to overheating. Allow the unit to cool down before attempting to use it again.

For persistent issues or complex problems, contact Moosum customer support.

8. Warranty and Support

The Moosum 36-Inch 5-Burner Electric Cooktop is covered by a **one-year warranty** from the date of purchase. This warranty covers manufacturing defects and malfunctions under normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Moosum customer service through the retailer where the product was purchased or visit the official Moosum website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question