cosydora R402KD

Cosydora R402KD Ultra Lightweight Foldable Rollator Walker Instruction Manual

Introduction

This manual provides essential information for the safe and effective use of your Cosydora R402KD Ultra Lightweight Foldable Rollator Walker. Designed for individuals seeking enhanced mobility and independence, this rollator features a reinforced aluminum frame, dual adjustable height settings, 8-inch all-terrain wheels, and a comfortable padded seat with a backrest. Please read these instructions thoroughly before assembly and first use to ensure proper function and user safety.

Setup

Unboxing and Initial Assembly

Carefully remove all components from the packaging. The rollator is designed for tool-free assembly. Ensure all parts are present and undamaged before proceeding.

Folding and Unfolding

To unfold the rollator, push down on the folding bracket located under the seat until the frame is fully extended and locked into place. To fold, lift the seat strap with one hand, allowing the rollator to collapse to a compact 9.5-inch width.



Figure 1: The rollator features a one-hand fold mechanism, collapsing to a compact size for convenient transport and storage in a vehicle.

Attaching Wheels and Handles

The front and rear wheels are inserted into their corresponding numbered slots on the frame. Secure them using the provided triangular knobs. Similarly, insert the handtubes into the upper frame and tighten them with the triangular knobs. Ensure both handle tubes are set to the same height for balanced support.

Video 1: This video demonstrates the step-by-step assembly process of the Cosydora Rollator Walker, including attaching wheels, handles, and backrest.

Text description: A person demonstrates assembling the rollator by attaching the numbered wheel components and securing them with knobs. The video also shows the installation of the handtubes and backrest.

Adjusting Height

The rollator features dual adjustable height for both the handles and the seat. Adjust the handle height (32.5"–38") to ensure a slight bend in your elbows when standing upright, promoting proper posture. Adjust the seat height (20"–22") so

your feet rest flat on the ground when seated. Use the adjustment pins and knobs to secure your preferred height settings.



Figure 2: The rollator's handle height can be adjusted from 32.5 to 38 inches, and the seat height from 20 to 22 inches, accommodating users from 4'7" to 6'6".

Attaching Accessories

Attach the backrest by sliding it into the designated slots on the handle tubes. Ensure the 'Cosydora' logo faces the correct direction. The detachable under-seat storage bag can be secured with its straps, and the cup holder clips onto the frame.



Figure 3: Key features include ergonomic hand grips, reflective strips on the wheels for visibility, an 11 lbs capacity storage bag, and integrated cable management for a neat appearance.

Operating

Walking with the Rollator

Place your hands on the ergonomic hand grips. Push the rollator forward, maintaining a comfortable distance. The 8-inch all-terrain wheels with 360° swivel fronts provide smooth movement over various surfaces, including grass, gravel, and carpet.



Figure 4: The 8-inch PVC wheels are designed for all-terrain use, offering better stability and control over rough ground, with anti-vibration, silent movement, and non-slip properties.

Braking System

The rollator is equipped with a triple-mode braking system. To slow down, pull the brake levers upwards. To engage the parking brake (lock the wheels for sitting), push the brake levers downwards until they click into place. To release the parking brake, pull the levers upwards again.



Figure 5: The braking system allows users to pull the levers for resistance (safer for downhill) and push them down to lock the wheels, preventing movement when sitting.

Using the Seat

Before sitting, ensure the parking brakes are engaged and the rollator is stable. The extra-wide 13.8" x 12" padded seat and thickened, breathable backrest provide a comfortable resting station. The under-seat storage bag can hold up to 11 lbs of personal belongings.



Figure 6: The Cosydora rollator features a 120-degree breathable comfort backrest with airflow mesh, offering superior back support compared to basic designs.



Figure 7: The upgraded extra-comfort seat is 3cm thick, waterproof, and ergonomically designed for soft support, providing comfort for over 120 minutes of sitting.

Maintenance

Cleaning

Clean the rollator frame with a damp cloth and mild soap. Avoid abrasive cleaners. The padded seat and backrest can be wiped clean. The storage bag is detachable for easier cleaning.

Inspections

Regularly check all screws, knobs, and fasteners to ensure they are tight. Inspect the wheels for wear and tear, and ensure they rotate freely. Test the brakes periodically to confirm they engage and disengage properly. Check brake cables for any fraying or damage.



Figure 8: The image illustrates the process of adjusting the tightness of the brakes, ensuring optimal stopping power and safety.

Troubleshooting

Wheels Not Rolling Smoothly

Check for debris or hair caught in the wheel axles. Clean as necessary. Ensure all wheel attachment knobs are securely tightened but not overtightened, which could restrict movement.

Brakes Not Engaging/Disengaging Properly

Inspect the brake cables for any kinks or damage. Ensure the brake pads are making proper contact with the wheels. Adjust the brake cable tension if needed (refer to Figure 8). If issues persist, contact customer support.

Rollator Feels Unstable

Verify that the rollator is fully unfolded and locked into place. Check that all height adjustment knobs for the handles and wheels are securely fastened. Ensure the handle and seat heights are set evenly on both sides.

Specifications

- **Product Dimensions:** 27.6 x 23.6 x 32.5 inches
- **Item Weight:** 13.67 Pounds (6.2 Kilograms)
- **Material Type:** Aluminum
- **Walker Type:** Rollator Walker
- **Maximum Height:** 38 Inches
- **Minimum Height:** 32.5 Inches
- **Weight Capacity Maximum:** 350 Pounds
- **Color:** Navy Blue
- **Is Foldable:** Yes
- **Model Name:** NB - R402KD
- **UPC:** 792105045207

Warranty & Support

The Cosydora R402KD Rollator Walker comes with a**24-month warranty**. If you encounter any issues or require assistance, please contact Cosydora Direct customer service. The product is also eligible for a **30-day return/replacement policy**. For technical support or inquiries, you may reach out via email at service.cosydora@gmail.com.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How can I obtain replacement hardware for the Cosydora R402KD Rollator Walker?

To obtain replacement hardware for your Cosydora R402KD Rollator Walker, you should contact the manufacturer's customer support directly. According to the product manual, the rollator is covered by a 24-month warranty and a 30-day...

Read full answer