Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JAPOUCA K8001A

JAPOUCA K8001A Portable Karaoke Machine User Manual

Model: K8001A | Brand: JAPOUCA

1. Introduction

This manual provides detailed instructions for the safe and effective operation of your JAPOUCA K8001A Portable Karaoke Machine. Please read this manual thoroughly before using the product and retain it for future reference.

2. Package Contents

Verify that all items listed below are included in your package. If any items are missing or damaged, please contact customer support.

- JAPOUCA K8001A Portable Karaoke Machine
- 2 x Wireless Microphones
- Power Adapter
- User Manual

3. Product Features

The JAPOUCA K8001A is a versatile portable karaoke machine designed for various audio applications. Key features include:

- **Bluetooth 5.3 Connectivity:** For stable and low-latency wireless audio streaming.
- **Powerful Audio Output:** Dual 8-inch woofers and dual 2.5-inch tweeters for rich, balanced sound.
- **Dual Wireless Microphones:** Two independent microphones for vocal performances.
- **Long Battery Life:** 18000mAh built-in battery providing up to 24 hours of continuous playback.
- **Intuitive Controls:** 15 shortcut buttons, 4 independent volume knobs (Echo, Guitar, Mic Vol, Volume), and 6 I/O ports.
- **Dynamic LED Lighting:** 9 selectable LED lighting modes to enhance the atmosphere.
- **TWS Function:** True Wireless Stereo for connecting two K8001A units for a stereo sound experience.

- **Multiple Input Options:** Supports TF Card, USB, and AUX inputs.
- **Recording Function:** Ability to record audio directly to a connected storage device.
- **DSP Technology:** Digital Signal Processing for enhanced sound quality and effects.



Image 3.1: Overview of the control panel, highlighting the 4 adjustment knobs for Echo, Guitar, Mic Volume, and Master Volume, along with 6 interface ports (Guitar, Mic, AUX, USB, TF, Output), 15 operation shortcut keys, and the LED display.



Image 3.2: Diagram illustrating the internal speaker components, including dual 8-inch woofers and dual 2.5-inch tweeters, powered by a DSP chip for enhanced sound.

4. Setup

4.1 Initial Charging

Before first use, fully charge the karaoke machine. Connect the provided power adapter to the AC input port on the back of the unit and plug it into a standard wall outlet. The LED display will indicate charging status.



Image 4.1: The karaoke machine connected to AC power for charging, also showing the 5V output port for charging external devices like smartphones.

4.2 Powering On/Off

Press and hold the power button located on the control panel for approximately 3 seconds to turn the unit on or off.

4.3 Microphone Setup

The wireless microphones are pre-paired with the karaoke machine. Simply insert batteries (not included) into each

microphone and power them on. They should automatically connect to the main unit.



Image 4.2: Illustration of the two wireless microphones, highlighting their 82ft wireless range and advanced anti-howl chip for clear audio.

5. Operating Instructions

5.1 Bluetooth Pairing

1. Turn on the karaoke machine. It will automatically enter Bluetooth pairing mode, indicated by a flashing 'BT' on the LED display.
2. Enable Bluetooth on your smartphone, tablet, or other audio device.
3. Search for 'K8001A' in the list of available devices and select it to pair.
4. Once paired, the 'BT' indicator will stop flashing, and a confirmation sound will be heard.

5.2 Using Wireless Microphones

After powering on the microphones, adjust their volume using the 'MIC VOL+' and 'MIC VOL-' knobs on the control panel. The 'ECHO+' and 'ECHO-' knobs control the echo effect for vocals.

5.3 LED Lighting Modes

Press the 'LIGHT' shortcut key on the control panel to cycle through the 9 available LED lighting modes. Press and hold the 'LIGHT' button to turn the lights off.



Image 5.1: The speaker showcasing its dynamic LED lighting, with multiple color and pattern options.

5.4 TWS (True Wireless Stereo) Function

To connect two K8001A units for a stereo experience:

1. Ensure both K8001A units are powered on and not connected to any Bluetooth device.
2. On one unit (this will be the primary unit), press and hold the 'TWS' button until you hear a confirmation tone.
3. The primary unit will search for the secondary unit. Once connected, you will hear another confirmation tone.

4. Now, connect your Bluetooth device to the primary K8001A unit as described in section 5.1. Audio will play in stereo through both speakers.



Image 5.2: Two K8001A speakers set up for TWS, demonstrating an immersive audio experience for a group enjoying an outdoor projection.

5.5 Input Modes (USB, TF Card, AUX)

Insert a USB drive or TF card into the respective port. The unit will automatically switch to the corresponding mode and begin playing audio files. For AUX input, connect an audio device using a 3.5mm audio cable to the AUX port. Use the

'MODE' button to switch between input sources.

5.6 Recording Function

To record your performance, ensure a USB drive or TF card is inserted. Press the 'REC' button to start recording. Press it again to stop recording. Recorded files will be saved to the storage device.

5.7 EQ Adjustment

Press the 'EQ' button to cycle through various equalizer presets. Use the 'BASS+' / 'BASS-' and 'TREBLE+' / 'TREBLE-' knobs to fine-tune the bass and treble levels manually.

6. Maintenance

6.1 Cleaning

Wipe the exterior of the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents. Ensure all ports are free of dust and debris.

6.2 Storage

When not in use for extended periods, store the karaoke machine in a cool, dry place away from direct sunlight and extreme temperatures. Fully charge the battery before storing and recharge every 3-6 months to maintain battery health.

7. Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted; Power adapter not connected.	Charge the unit using the provided power adapter; Ensure power adapter is securely connected to both the unit and a working outlet.
No sound	Volume too low; Incorrect input mode; Device not paired (Bluetooth).	Increase master volume and source device volume; Press 'MODE' to select correct input; Re-pair Bluetooth device.
Microphone not working	Microphone off; Batteries depleted; Microphone volume too low.	Turn on microphone; Replace microphone batteries; Increase 'MIC VOL' knob.
Bluetooth connection unstable	Device too far; Obstructions; Interference.	Move device closer to the speaker; Remove obstructions; Avoid other wireless devices.
TWS not connecting	One or both units already paired; Incorrect TWS pairing procedure.	Ensure both units are unpaired from other devices; Follow TWS pairing steps in section 5.4 carefully.

8. Specifications

Feature	Specification
Model Name	K8001A

Feature	Specification
Speaker Type	Speaker Systems (Dual 8-inch Woofers, Dual 2.5-inch Tweeters)
Connectivity Technology	Bluetooth 5.3, USB, TF Card, AUX
Speaker Maximum Output Power	180 Watts
Battery Capacity	18000mAh (up to 24 hours playback)
Product Dimensions	12.87"D x 12.9"W x 28.9"H
Item Weight	28.1 pounds
Color	Black
Manufacturer	JAPOUCA

9. Safety Information

- Do not expose the unit to water or excessive moisture.
- Avoid placing the unit near heat sources or in direct sunlight.
- Do not attempt to disassemble or repair the unit yourself. Contact qualified service personnel.
- Use only the provided power adapter for charging.
- Keep out of reach of children.
- Do not block ventilation openings.

10. Warranty and Support

JAPOUCA products come with a standard manufacturer's warranty. For detailed warranty information, product support, or service inquiries, please refer to the warranty card included in your package or visit the official JAPOUCA website. Please have your model number (K8001A) and purchase date ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZVBPZC6

More documents and user manuals: **https://manuals.plus/**