Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VUOPAX B48A

VUOPAX 180W Portable Bluetooth Speaker B48A User Manual

Model: B48A

Important Safety Instructions

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the speaker to extreme temperatures or direct sunlight for extended periods.
- Do not disassemble, repair, or modify the speaker. This may void the warranty and pose a safety risk.
- Ensure the charging port cover is securely closed when using the speaker near water to maintain its IP65 waterproof rating.
- Use only the provided power cable for charging.
- Keep the speaker away from medical devices, as it contains magnets.
- Dispose of the battery according to local regulations. Do not dispose of it in fire.

Package Contents

Verify that all items are present in the package:

- VUOPAX 180W Portable Bluetooth Speaker (B48A)
- Power Cable
- User Manual (this document)



Image: The VUOPAX 180W Portable Bluetooth Speaker shown with its power cable, representing the typical package contents.

Product Overview

Controls and Ports

Familiarize yourself with the speaker's controls and connection ports:

1. **Power Button:** Press and hold to turn the speaker ON or OFF. Short press to check battery status.
2. **Mode Button (M):** Short press to switch between Bluetooth, USB, TF card, and AUX input modes.
3. **Play/Pause Button (►▮▮):** Short press to play or pause audio. In Bluetooth mode, press and hold to activate voice assistant.
4. **Volume Down / Previous Track (-):** Short press to decrease volume. Press and hold to go to the previous track.
5. **Volume Up / Next Track (+):** Short press to increase volume. Press and hold to go to the next track.
6. **Bass Boost Button:** Short press to activate or deactivate the bass boost feature.
7. **USB Port:** For USB flash drive playback.
8. **TF Card Slot:** For TF (MicroSD) card playback.
9. **AUX Input (3.5mm):** For connecting external audio devices via an audio cable.
10. **Charging Port (DC IN):** Connect the power cable here to charge the speaker.



Image: A detailed view of the speaker's top panel, highlighting the control buttons and rear panel with various input ports (USB, TF, AUX, Charging).

Setup

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power cable to the speaker's DC IN charging port and plug the other end into a power outlet. The charging indicator light will show the charging status and turn off when fully charged.

2. Powering On/Off

- **To Power ON:** Press and hold the Power Button for approximately 3 seconds until you hear an audible prompt.
- **To Power OFF:** Press and hold the Power Button for approximately 3 seconds until you hear an audible prompt.

3. Bluetooth Pairing

1. Ensure the speaker is powered ON and in Bluetooth mode. If not, short press the Mode Button (M) until you hear the Bluetooth pairing prompt. The Bluetooth indicator light will flash rapidly.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "VUOPAX B48A" from the list of devices.

4. Once connected, the speaker will emit an audible confirmation, and the Bluetooth indicator light will remain solid.

Operating Instructions

1. Playing Audio via Bluetooth

After successful pairing, open your preferred music application on your device and start playback. You can control volume and track selection using the speaker's buttons or your device.

2. Using USB/TF Card Input

1. Insert a USB flash drive or TF (MicroSD) card containing MP3 audio files into the respective port.
2. The speaker will automatically switch to USB or TF card mode and begin playback. If not, short press the Mode Button (M) to select the correct input.
3. Use the Volume Up/Down and Play/Pause buttons to control playback.

3. Using AUX Input

1. Connect one end of a 3.5mm audio cable (not included) to the speaker's AUX input port.
2. Connect the other end of the audio cable to the headphone jack of your external audio device.
3. Short press the Mode Button (M) until the speaker enters AUX mode.
4. Control playback and volume from your connected audio device.

4. Adjusting Volume and Bass Boost

- **Volume:** Short press the '+' button to increase volume, and the '-' button to decrease volume.
- **Bass Boost:** Short press the Bass Boost button to toggle the enhanced bass effect ON or OFF.

Maintenance

Proper care ensures the longevity of your VUOPAX speaker:

- **Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight when not in use for extended periods.
- **Battery Care:** To preserve battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use.
- **Water Resistance:** Always ensure the charging port cover is sealed tightly to maintain IP65 water resistance. Do not submerge the speaker in water.

Troubleshooting

If you encounter issues, refer to the following common problems and solutions:

Problem	Possible Solution
Speaker does not power on.	Ensure the speaker is charged. Connect the power cable and try again.

Problem	Possible Solution
Cannot pair with Bluetooth device.	Make sure the speaker is in Bluetooth pairing mode (flashing indicator). Turn off and on Bluetooth on your device. Move closer to the speaker.
No sound from speaker.	Check the volume level on both the speaker and your connected device. Ensure the correct input mode (Bluetooth, USB, TF, AUX) is selected.
Sound is distorted.	Reduce the volume on both the speaker and your device. Ensure the audio source is of good quality. Move closer to the speaker if using Bluetooth.
USB/TF card not playing.	Ensure the card/drive contains supported audio formats (e.g., MP3). Check if the card/drive is inserted correctly. Press the Mode button to select the correct input.

Specifications

Feature	Specification
Model Name	B48A
Brand	VUOPAX
Speaker Type	Portable Speaker
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	120 Watts (RMS), 180 Watts (Peak)
Frequency Response	30 Hz
Audio Output Mode	Stereo
Waterproof Rating	IP65
Product Dimensions	15"D x 6"W x 7.4"H
Included Components	Power Cable
Battery	1 Nonstandard Battery (required)

Warranty and Support

This VUOPAX product is covered by a limited warranty. For detailed warranty terms and conditions, please refer to the warranty card included with your purchase or contact customer support.
For technical support, troubleshooting assistance, or warranty claims, please contact VUOPAX customer service through the retailer where the product was purchased or visit the official VUOPAX website for contact information.

© 2025 VUOPAX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G1FGFFG4

More documents and user manuals: **https://manuals.plus/**