Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Binecer B0G1MFYLP1

Binecer Portable Steam Sauna Box User Manual

Model: B0G1MFYLP1

Introduction

Thank you for choosing the Binecer Portable Steam Sauna Box. This manual provides essential information for the safe and effective use of your new sauna. Please read all instructions carefully before assembly and operation, and retain this manual for future reference.
The Binecer Portable Steam Sauna Box is designed for personal relaxation and steam therapy at home. It features a 3L 1200W high-power steamer, adjustable temperature settings, and a spacious, five-sided tent design for comfortable use.

Important Safety Information

WARNING: To reduce the risk of burns, electrocution, fire, or injury to persons, read the following important safety instructions.

- Always ensure the steamer is placed on a stable, flat surface.
- Do not operate the sauna without water in the steamer. The steamer features anti-dry burning protection, but proper water levels are crucial.
- Avoid direct contact with the steam nozzle, especially at high temperatures, to prevent burns.
- Ensure the ABS pot cover is securely clamped and rotated clockwise to lock before operation to prevent steam leakage and ensure safety.
- Keep children and pets away from the sauna during operation.
- Do not use the sauna if you are pregnant, have heart conditions, high blood pressure, or any other medical condition without consulting a physician.
- Discontinue use immediately if you feel dizzy, nauseous, or uncomfortable.
- Unplug the steamer from the power outlet when not in use and before cleaning.
- Do not immerse the steamer unit in water or other liquids.
- Use only the provided power cord and ensure it is not damaged.



Image: The steamer unit highlighting safety features like anti-dry burning, automatic power off, and a secure lid. This image illustrates the multi-protection design of the steamer for safe operation.

Package Contents

Please check the package to ensure all components are present and undamaged:

- Sauna Tent (Pentagonal shape)
- 3L 1200W Steamer Unit
- Folding Chair
- Remote Control
- Absorbent Pad
- Medicine Box (for herbs/essential oils)
- Connecting Pipes
- Stainless Steel Support Tubes (numbered for easy assembly)
- User Manual (this document)

Assembly Instructions

The Binecer Portable Steam Sauna Box is designed for quick and easy assembly, typically within 5 minutes. Follow these steps:

1. **Unpack Components:** Carefully remove all items from the packaging.
2. **Assemble Frame:** Connect the numbered stainless steel support tubes according to the diagram. Ensure all connections are secure.
3. **Attach Tent:** Drape the sauna tent over the assembled frame. Ensure the tent is properly aligned and secured to the frame.
4. **Position Steamer:** Place the steamer unit on a flat, stable surface near the sauna tent. Connect the steam hose from the steamer to the designated inlet on the sauna tent.
5. **Set up Chair:** Unfold the provided folding chair and place it inside the sauna tent.
6. **Absorbent Pad:** Place the absorbent pad on the floor inside the sauna tent to manage any condensation.



Image: Visual guide for assembling the sauna tent frame and attaching the fabric. This image shows the step-by-step process of setting up the portable sauna.



Image: The assembled five-sided sauna tent with a person standing next to it, illustrating its spacious design and dimensions (71 inches height). This image helps visualize the size and comfort of the sauna.

Operating Instructions

1. **Fill Steamer:** Open the steamer lid and fill the 3L stainless steel liner with clean water up to the MAX fill line. Do not overfill. For herbal or essential oil sauna, place desired materials in the medicine box provided.
2. **Secure Lid:** Close the steamer lid firmly, pressing down and rotating clockwise to lock it securely.
3. **Power On:** Plug the steamer into a suitable power outlet. The steamer will typically display its current status.
4. **Preheat:** Turn on the steamer using the control panel or the remote control. Allow the steamer to preheat for approximately 8 minutes for optimal steam generation and a better sauna experience.
5. **Adjust Settings:**
    - **Timer:** Set the desired sauna duration from 1 to 60 minutes.
    - **Temperature:** Select one of the 15 temperature speeds, ranging from 0 to 130°F (0-54°C). Adjust according to your comfort level.

6. **Enter Sauna:** Once steam is adequately generated, enter the sauna tent and sit on the folding chair. Close the two-way zippers to retain heat.
7. **During Use:** You can adjust settings using the remote control from inside the tent. The small window allows for visibility and can be opened for ventilation if needed.
8. **After Use:** When your session is complete or the timer runs out, the steamer will automatically shut off. Unplug the steamer and allow it to cool before handling.



Image: Diagram showing the 15 heating speeds and 1-60 minute timer function of the steamer, indicating rapid heating to maximum temperature. This image illustrates the control options for temperature and duration.



Image: A person inside the sauna tent, demonstrating the use of the remote control and highlighting features like double-sided zippers and external/internal pockets for convenience. This image shows practical in-tent features.

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and hygienic operation of your sauna.

- **Steamer Cleaning:** After each use, allow the steamer to cool completely. Empty any remaining water. Wipe the interior of the stainless steel liner with a soft, damp cloth. For mineral buildup, use a descaling solution suitable for kettles or a vinegar solution, then rinse thoroughly. Do not immerse the electrical unit in water.
- **Tent Cleaning:** The absorbent pad should be removed and cleaned after each use. The tent fabric can be wiped down with a damp cloth and mild detergent if necessary. Ensure the tent is completely dry before folding and storing to prevent mold or mildew.
- **Storage:** When not in use, disassemble the sauna tent and fold it neatly. Store all components in a dry, cool place away from direct sunlight.



Image: Cross-section view of the sauna tent fabric, illustrating its three-layer insulation (waterproof Oxford cloth, thickened thermal insulation cotton, and inner lining) for heat preservation and easy cleaning. This image highlights the material quality for durability and hygiene.

Troubleshooting

Problem	Possible Cause	Solution
Steamer not producing steam.	No water in the tank, insufficient water, lid not secured, power not connected.	Fill water to MAX line. Ensure lid is locked. Check power connection. Allow 8 minutes for preheating.
Sauna tent not heating effectively.	Zippers not fully closed, low temperature setting, tent not fully assembled.	Ensure all zippers are closed. Increase temperature setting. Verify tent is properly attached to the frame.
Remote control not working.	Batteries dead, remote out of range, obstruction.	Replace batteries. Ensure remote is pointed towards the steamer's sensor. Remove any obstructions.
Water leaking from steamer.	Lid not secured, overfilled water tank.	Ensure lid is firmly locked. Do not fill water above the MAX line.

Specifications

- **Model:** B0G1MFYLP1
- **Steamer Power:** 1200W
- **Steamer Capacity:** 3 Liters
- **Heating Speeds:** 15 levels (0-130°F / 0-54°C)
- **Timer Range:** 1-60 minutes
- **Tent Dimensions (Approx.):** 35.4" L x 35.4" W x 71" H (90cm L x 90cm W x 180cm H)
- **Material:** Thickened quilted fabrics, stainless steel frame, 304 stainless steel steamer liner
- **Safety Features:** Anti-dry burning, automatic power off, explosion-proof isolation net, anti-leakage design.

Warranty and Customer Support

For warranty information or technical assistance, please contact Binecer customer support. Details can typically be found on the product packaging or the official Binecer website.

You can also visit the Binecer Store on Amazon for more product information and support resources.

© 2023 Binecer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G1MFYLP1

More documents and user manuals: **https://manuals.plus/**