saschedross 6V AC/DC Adapter

saschedross 6V AC/DC Adapter User Manual

For Metrokane Rabbit 647771 & 6200 Electric Wine Bottle Openers

Introduction

This manual provides essential instructions for the safe and effective use of your saschedross 6V AC/DC Adapter. This adapter is specifically designed to charge Metrokane Rabbit 647771 and 6200 electric wine bottle openers, replacing lost or damaged power cords for these classic models. Please read this manual thoroughly before use and retain it for future reference.

Setup

Follow these steps to properly set up your AC/DC adapter for charging.

1. **Inspect the Adapter:** Before connecting, ensure the adapter and its cable are free from any visible damage.
2. **Connect to Power Outlet:** Plug the AC prongs of the adapter into a standard 100-240VAC wall outlet. The adapter supports worldwide input voltage.
3. **Connect to Device:** Insert the barrel connector end of the adapter cable into the charging port of your Metrokane Rabbit 647771 or 6200 electric wine bottle opener. Ensure a secure connection.



Image: The saschedross 6V AC/DC adapter, illustrating its compact dimensions from multiple angles. The adapter measures approximately 2.7 inches in height, 1.2 inches in width, and 1.6 inches in depth.

Operating

Once connected, the adapter will begin charging your device.

- **Charging Indication:** Refer to your Metrokane Rabbit wine opener's manual for specific charging indicators (e.g., LED lights) that confirm it is receiving power.
- **Charging Time:** Charging duration will depend on the battery level of your wine opener. Avoid overcharging by disconnecting the adapter once the device is fully charged, as indicated by your wine opener.
- **Power Cord Length:** The adapter features a 6.5-foot power cord, offering flexibility in placement during charging.



Image: The saschedross 6V AC/DC adapter shown with its integrated power cord, highlighting the generous 6.5-foot length for convenient use.

Maintenance

Proper care ensures the longevity and safe operation of your adapter.

- **Cleaning:** Disconnect the adapter from both the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or immerse the adapter in water.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Safety:** Do not attempt to open or repair the adapter. Keep it away from children and pets.



Image: The saschedross 6V AC/DC adapter being placed into a pocket, illustrating its compact size and ease of portability.

Troubleshooting

If you encounter issues, refer to the following common solutions.

- **Device Not Charging:**
  - Ensure the adapter is securely plugged into a working wall outlet.

- Verify the barrel connector is fully inserted into the device's charging port.
- Check for any visible damage to the adapter or cable. If damaged, discontinue use.
- Test the wall outlet with another device to confirm it is functional.

- **Adapter Feels Warm:**

  It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot, disconnect it immediately and contact support.

- **Intermittent Charging:**

  Ensure all connections are firm. Avoid bending or stressing the cable at the connector points.

Specifications

Feature	Detail
Brand	saschedross
Input Voltage	100-240VAC
Input Frequency	50-60Hz
Output Voltage	6V (implied by product title)
Output Current	80mA (implied by product title)
Connector Type	Barrel
Cable Length	6.5 feet
Compatible Devices	Metrokane Rabbit 647771, Metrokane Rabbit 6200 Electric Wine Bottle Openers
Special Features	Over-current, Over-Voltage & Over-heat protection

Warranty and Support

Specific warranty information for this product is not provided in the available documentation. For any issues or further assistance, please contact the retailer or manufacturer directly.

© 2026 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question