Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

COSTWAY FC32499FR

COSTWAY 6V Electric Ride-On Car for Kids - User Manual

Model: FC32499FR

1. Important Safety Instructions

Please read this entire manual before assembling or using the COSTWAY 6V Electric Ride-On Car. Failure to follow these safety instructions may result in serious injury or death.

- **Adult Supervision Required:** This product is intended for children aged 18 months and older. Constant adult supervision is mandatory during operation.
- **Weight Limit:** Do not exceed the maximum weight capacity of 20 kg (44 lbs).
- **Protective Gear:** Always ensure the child wears appropriate safety gear, such as a helmet, knee pads, and elbow pads.
- **Safe Operating Areas:** Use the vehicle only on flat, level surfaces. Avoid slopes, stairs, public roads, swimming pools, or areas with traffic.



Image: Stable 4-Wheel Structure. This image illustrates the robust 4-wheel design of the vehicle, emphasizing its wear-resistant and puncture-resistant qualities. It also shows examples of suitable operating surfaces: asphalt, concrete, stone, and hardwood.

- **Avoid Hazards:** Keep children away from water, fire, and other potential hazards.
- **Battery Safety:** Only use the provided charger. Do not allow children to handle the battery or charger. Keep the battery away from heat and open flames.
- **Assembly:** Adult assembly is required. Ensure all parts are correctly installed and secured before use.
- **No Modifications:** Do not modify the electrical system or any other part of the vehicle.
- **Stop Before Adjusting:** Always ensure the vehicle is stopped before making any adjustments or allowing the child to get in or out.

2. Package Contents

Please check that all items are included in the package before assembly. If any parts are missing or damaged, contact customer service.

- 1 x COSTWAY 6V Electric Ride-On Car
- 1 x Battery Charger

- 1 x User Manual
- Necessary assembly components (e.g., wheels, steering wheel, axles, screws)

3. Assembly Instructions

Adult assembly is required. Please follow these general steps. Refer to the included assembly diagram for detailed instructions.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface.
2. **Install Wheels:** Attach the wheels to the axles, ensuring they are securely fastened with the provided washers and caps/nuts.
3. **Connect Battery:** Locate the battery compartment. Connect the battery terminals (red to red, black to black) if they are not already connected.
4. **Install Steering Wheel:** Attach the steering wheel to the steering column, ensuring it clicks into place or is secured with a screw. Connect any wiring for horn/sound functions if applicable.
5. **Attach Accessories:** Install any other accessories like mirrors, windshield, or decorative stickers.
6. **Final Check:** Before first use, ensure all screws are tightened, connections are secure, and the vehicle is stable.

4. Charging the Battery

The battery must be fully charged before the first use. A full charge typically takes 8-12 hours. Do not charge for more than 18 hours.



Image: Practical Charging. This image highlights the charging port located on the side of the vehicle, along with icons indicating a 6V battery, 25W motor, and 1-2 hours of playtime per charge. The car is shown on a road with a rural background.

1. **Locate Charging Port:** The charging port is typically located on the side or rear of the vehicle.
2. **Connect Charger:** Plug the charger into a standard wall outlet, then connect the charger's plug into the vehicle's charging port.
3. **Monitor Charging:** The charger may have an indicator light to show charging status (refer to charger manual if available).
4. **Disconnect:** Once fully charged, disconnect the charger from the vehicle and then from the wall outlet.

Important: Recharge the battery after each use. If the vehicle is not used for an extended period, charge the battery at least once a month to prolong its lifespan.

5. Operating Instructions

Familiarize your child with the controls in a safe, open area under constant adult supervision.

5.1 Starting and Stopping



Image: Endless Driving Fun. This image shows a child happily driving the electric car. An inset highlights the simple control panel with a "One-Button Start" and "Forward/Reverse" switch, indicating a speed of 2.6 km/h.

- **Power On:** Press the "One-Button Start" switch (often marked with a power symbol) to turn the vehicle on.
- **Power Off:** Press the same button again or use a dedicated power off switch to turn the vehicle off.

5.2 Driving

- **Forward/Reverse:** Use the forward/reverse switch (often located near the start button) to select the desired direction.
- **Acceleration:** Press the foot pedal to move the vehicle. Release the pedal to brake.
- **Steering:** Use the steering wheel to control the direction of the vehicle.

5.3 Lights, Horn, and Engine Sounds



Image: Realistic Steering Wheel. This image focuses on the steering wheel, highlighting the horn button and the engine sound button. It also notes that the steering wheel requires 2 AA batteries (not included) for these functions.

- **LED Lights:** The vehicle is equipped with LED lights that illuminate when the car is powered on or when a dedicated light switch is activated (if present).
- **Horn:** Press the horn button on the steering wheel to sound the horn. (Requires 2 AA batteries, not included, for steering wheel functions).
- **Engine Sound:** Press the engine sound button on the steering wheel to activate engine noises. (Requires 2 AA batteries, not included, for steering wheel functions).

5.4 Storage Features



Image: Superior Quality Details. This composite image showcases several features: a side storage cup for small items, a rear storage box with a lid, and pivoting rearview mirrors. Other details like adorable stickers, bright LED lights, and the foot pedal are also shown.

- **Side Storage Cup:** Use the integrated cup holder on the side for drinks or small toys.
- **Rear Storage Box:** The vehicle features a rear compartment for storing larger toys or essentials.
- **Pivoting Mirrors:** The rearview mirrors can be adjusted for realistic play.

6. Maintenance

- **Cleaning:** Clean the vehicle with a soft, damp cloth. Do not use abrasive cleaners or solvents. Avoid spraying water directly onto electrical components.
- **Battery Care:**
  - Always recharge the battery after each use.
  - If not used for a long time, charge the battery at least once a month.
  - Do not overcharge the battery (max 18 hours).

    - Store the battery in a cool, dry place.
- **Storage:** Store the vehicle indoors in a dry place when not in use. Protect it from direct sunlight and extreme temperatures.
- **Inspections:** Regularly check all screws, nuts, and connections to ensure they are tight and secure. Inspect wheels for wear and tear.

7. Troubleshooting

Problem	Possible Cause	Solution
Vehicle does not move	Battery is low or dead. Battery connection is loose. Overload protection activated. Foot pedal is faulty.	Recharge the battery. Check and secure battery connections. Reduce load; wait a few minutes for reset. Contact customer service.
Vehicle moves slowly	Battery is undercharged. Vehicle is overloaded. Operating on rough terrain.	Fully recharge the battery. Reduce weight on the vehicle. Operate on flat, smooth surfaces.
Lights/Horn/Sound not working	Steering wheel batteries are dead or missing. Loose wiring.	Install/replace 2 AA batteries in the steering wheel. Check wiring connections (adult only).

8. Specifications



Image: Dimensions. This image provides a visual representation of the car's dimensions: 66 cm (length), 42 cm (width), and 40 cm (height). It also specifies the seat dimensions (32 cm length, 22 cm width), recommended age (18+ months), and seat load capacity (20 kg).

Model Number	FC32499FR
Material	Plastic
Overall Dimensions (L x W x H)	66 x 42 x 40 cm (26 x 16.5 x 15.7 inches)
Seat Dimensions (L x W)	32 x 22 cm (12.6 x 8.7 inches)
Motor	25 W
Battery	6 V
Charger Output	DC 6 V
Run Time	1 - 2 hours (depending on use)

Speed	2.6 km/h (1.6 mph)
Recommended Age	18 months +
Max Seat Load	20 kg (44 lbs)
Net Weight	5 kg (11 lbs)

9. Warranty and Support

For warranty information, please refer to the purchase documentation or contact the retailer where the product was purchased. For technical support, missing parts, or any other inquiries, please contact COSTWAY customer service through their official website or the contact information provided with your purchase.

You can visit the COSTWAY store for more information:COSTWAY Official Store

© 2023 COSTWAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G25Y9BDF

More documents and user manuals: **https://manuals.plus/**