**Colorcool A3-Pro**

# Colorcool A3-Pro Portable MP3 Player User Manual

## Introduction

This manual provides comprehensive instructions for the Colorcool A3-Pro Portable MP3 Player. Please read this guide carefully to ensure proper use and optimal performance of your device. This MP3 player is designed for portable audio playback, featuring Bluetooth 5.3 connectivity, a touch screen interface, voice recording, FM radio, and expandable storage.

## What's in the Box

- Colorcool A3-Pro Portable MP3 Player
- USB Type-C Cable
- Wired Headset
- User Manual

## Product Overview

Familiarize yourself with the device's components and controls.




Diagram showing the buttons and ports on the Colorcool A3-Pro MP3 Player, including power, volume, return, headphone jack, USB-C charging port, loudspeaker, TF card slot, and clip.

- **1.8" TFT Touch Screen:** Main display for navigation and interaction.
- **Headphone Jack:** 3.5mm port for wired headphones.
- **Power On/Off Button:** Located on the side, press and hold to power on or off.
- **Volume + / - Buttons:** Adjust audio volume.
- **Return Button:** Navigate back in menus.
- **USB-C Charging Port:** For charging and data transfer.
- **Loudspeaker:** Built-in speaker for audio playback without headphones.
- **TF Card Slot:** For inserting a Micro SD card to expand storage.
- **Built-in Clip:** Allows for easy attachment to clothing or bags.

## Setup

## 1. Charging the Device

Before first use, fully charge the MP3 player. Connect the included USB Type-C cable to the device's charging port and the other end to a USB power adapter (not included) or a computer's USB port. The battery indicator on the screen will show charging status.

## 2. Inserting a Micro SD Card

The device has 32GB of internal memory and supports Micro SD cards up to 512GB for expanded storage. To insert a card, locate the TF card slot on the side of the player. Gently push the Micro SD card into the slot until it clicks into place. To remove, push the card again until it springs out.




The Colorcool A3-Pro MP3 Player features a Micro SD card slot for expandable storage up to 512GB, alongside its USB-C charging port.

## 3. Transferring Music and Files

Connect the MP3 player to your computer using the USB Type-C cable. The device will appear as a removable disk. You can then drag and drop audio files (MP3, WMA, APE, FLAC, WAV, etc.), video files (AVI, AMV), or TXT e-book files directly into the appropriate folders on the player's internal memory or the inserted Micro SD card.

## Operating Instructions

### 1. Power On/Off

- **To Power On:** Press and hold the Power button on the side until the screen lights up.
- **To Power Off:** Press and hold the Power button until the power-off option appears on the screen, then confirm.

### 2. Touch Screen Navigation

The MP3 player features a full-touch screen for easy navigation. Swipe left or right to browse through menu options. Tap an icon to select a function. Use the physical 'Return' button or on-screen back arrow to go back to the previous screen.

### 3. Music Playback




The Colorcool A3-Pro MP3 Player offers multiple functions accessible via its touch screen, including Music, Bluetooth, Recording, and FM Radio.

- **Accessing Music:** From the main menu, tap the 'Music' icon. You can browse by 'All Songs', 'Artists', 'Albums', 'Playlists', etc.

- **Supported Formats:** MP3, WMA, APE, FLAC, WAV, DRM, ACELP.
- **Playback Modes:** While playing music, tap the screen to reveal playback options. You can select 'Repeat 1' (repeat current song), 'Repeat All' (repeat all songs in the list), or 'Shuffle' (play songs in random order).
- **Built-in Speaker:** The device has a built-in speaker. You can enable or disable the speaker in the settings menu.

## 4. Bluetooth Connection

The MP3 player features Bluetooth 5.3 for wireless audio streaming.




The Colorcool A3-Pro MP3 Player supports wireless Bluetooth connection to earbuds and portable speakers for convenient audio playback.

- **Pairing:** Go to the 'Bluetooth' menu. Turn on Bluetooth. The player will search for nearby Bluetooth devices. Select your Bluetooth headphones or speaker from the list to pair.
- **Note:** This device cannot pair with smartphones via Bluetooth.

## 5. FM Radio

To use the FM Radio, connect the wired headset as it acts as the antenna. Navigate to the 'FM Radio' icon from the main menu. You can auto-scan for stations or manually tune.

## 6. Voice Recording

Select the 'Recording' icon. You can record audio using the built-in microphone or via line-in. Recordings are saved in a dedicated folder.

## 7. E-Book

The device supports e-books in TXT format only. Transfer TXT files to the player and access them via the 'E-Book' icon.

## 8. Other Functions

The MP3 player includes additional utilities:




The Colorcool A3-Pro MP3 Player includes a stopwatch function, useful for tracking activities like running.

- **Alarm Clock:** Set alarms for reminders.
- **Calendar:** View the current date.
- **Stopwatch:** Use for timing activities.

## Maintenance

### 1. Cleaning

Wipe the device with a soft, dry cloth. Avoid using liquid cleaners or abrasive materials, which can damage the screen or casing.

### 2. Battery Care

To prolong battery life, avoid fully discharging the device frequently. Charge the battery regularly, even if the device is not in use for extended periods. Store the device in a cool, dry place.

## Troubleshooting

- **Device does not power on:** Ensure the battery is charged. Connect to a power source and try again.
- **Cannot connect via Bluetooth:** Ensure Bluetooth is enabled on both the MP3 player and the target device (headphones/speaker). Make sure the target device is in pairing mode. Remember, the MP3 player cannot pair with a smartphone.
- **Music files are not playing:** Verify that the music files are in a supported format (MP3, WMA, APE, FLAC, WAV, etc.). Ensure files are correctly transferred to the device's music folder.
- **Screen visibility issues in direct sunlight:** The screen may be difficult to view in bright, direct sunlight. Move to a shaded area for better visibility.
- **Music files disappear or are corrupted:** Regularly back up your music files to a computer to prevent data loss. If this issue occurs, re-transfer your music files.
- **Touch screen is unresponsive or slow:** Restart the device. Ensure the screen is clean and dry.
- **Clip detaches easily:** Ensure the clip is securely attached. For active use, consider additional securing methods if needed.

## Specifications

| | |
|---|---|
| **Brand** | Colorcool |
| **Model Name** | A3-Pro |
| **Connectivity Technology** | Aux, Bluetooth 5.3, USB |
| **Memory Storage Capacity** | 32 GB (expandable up to 512GB via Micro SD card) |
| **Screen Size** | 1.8 inches |
| **Display Technology** | LCD |
| **Supported Audio Formats** | MP3, WMA, APE, FLAC, WAV, DRM, ACELP |
| **Supported Video Formats** | AVI, AMV |
| **Supported E-Book Format** | TXT |
| **Special Features** | Built-In Clip, Built-In Speaker, Equalizer, FM Radio, Touch Screen, Voice Recording |
| **Battery Average Life** | 20 hours |

## Official Product Video

Your browser does not support the video tag.

Official product video demonstrating the features and usage of the Colorcool A3-Pro MP3 Player, including its clip design and various functions.

## Warranty and Support

For warranty information and customer support, please refer to the contact details provided with your purchase

documentation or visit the official Colorcool website. Keep your purchase receipt as proof of purchase for warranty claims.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question