Mivi Nex 200

Mivi Nex 200 Soundbar Instruction Manual

Model: Nex 200 (SWFTS36)

1. Introduction

Thank you for choosing the Mivi Nex 200 Soundbar. This 2.1 channel audio system, featuring 200 Watts of power and a dedicated subwoofer, is designed to enhance your audio experience for movies, music, and general entertainment. This manual provides essential information for setting up, operating, and maintaining your soundbar system.



Image 1.1: Overview of Mivi Nex 200 Soundbar key features.

2. Safety Information

- Read all instructions carefully before use.
- Do not expose the soundbar or subwoofer to rain, moisture, or extreme temperatures.

- Ensure proper ventilation around the units to prevent overheating.
- Do not block any ventilation openings.
- Use only the power adapter supplied with the device.
- Keep the device away from strong magnetic fields.
- Do not attempt to disassemble or repair the unit yourself. Refer all servicing to qualified personnel.

3. Package Contents

Verify that all items are present in the package:

- 1 x Mivi Nex 200 Soundbar
- 1 x Subwoofer
- 1 x Remote Control
- 1 x Power Adapter
- 1 x User Manual (this document)

4. Product Overview

4.1 System Components

The Mivi Nex 200 system consists of a soundbar and a wired subwoofer, designed to deliver a comprehensive 2.1 channel audio experience.



Image 4.1: Mivi Nex 200 Soundbar and Subwoofer.

4.2 Rear Panel Connections

The rear panel of the soundbar provides various input and output ports for connecting to different audio sources and the subwoofer.



Image 4.2: Rear panel connections of the Mivi Nex 200 Soundbar.

- **SW Output:** Connects to the wired subwoofer.
- **DC 24V:** Power input port.
- **AUX:** 3.5mm auxiliary input for analog audio devices.
- **HDMI TV (ARC):** HDMI Audio Return Channel for connecting to compatible TVs.
- **USB:** For playing audio files from a USB drive.
- **Coaxial:** Digital audio input.

4.3 Remote Control

The included remote control allows for convenient operation of the soundbar, including power, input selection, volume, and EQ modes.



Image 4.3: Mivi Nex 200 Soundbar Remote Control.

5. Setup

5.1 Placement

- Place the soundbar centrally below your television.
- Position the subwoofer on the floor, preferably in a corner or near a wall for optimal bass response. Ensure it is within reach of the soundbar's SW Output cable.
- Ensure adequate space around both units for ventilation.

5.2 Connecting the Subwoofer

Connect the wired subwoofer to the soundbar using the provided cable. Insert one end into the 'SW Output' port on the soundbar's rear panel and the other end into the corresponding input on the subwoofer.

5.3 Connecting to Audio Sources

The Mivi Nex 200 Soundbar offers multiple connectivity options:

Image 5.1: Multi-device connectivity options.

1. **HDMI ARC:** Connect an HDMI cable from the 'HDMI TV (ARC)' port on the soundbar to the HDMI ARC port on your television. This allows audio from your TV to play through the soundbar and enables TV remote control for soundbar volume.
2. **Optical:** Connect an optical cable (not included) from the soundbar's optical input to your TV or other audio device's optical output.
3. **Coaxial:** Connect a coaxial cable (not included) from the soundbar's coaxial input to your TV or other audio device's coaxial output.
4. **AUX:** Use a 3.5mm audio cable (not included) to connect the soundbar's 'AUX' port to the headphone jack or audio

output of your device (e.g., smartphone, MP3 player).

5. **USB:** Insert a USB flash drive containing MP3 audio files into the 'USB' port. The soundbar will automatically switch to USB mode and begin playback.
6. **Bluetooth:** For wireless connection, refer to the 'Bluetooth Pairing' section under Operating Instructions.

5.4 Power Connection

Connect the power adapter to the 'DC 24V' port on the soundbar, then plug the adapter into a wall outlet. The soundbar will enter standby mode.

6. Operating Instructions

6.1 Power On/Off

Press the **Power** button on the remote control or the soundbar to turn the unit on or off.

6.2 Input Selection

Press the **Input** button on the remote control repeatedly to cycle through available input modes: Bluetooth, HDMI ARC, Optical, Coaxial, AUX, and USB.

6.3 Volume Control

Use the **VOL+** and **VOL-** buttons on the remote control to adjust the master volume. Press the **MUTE** button to temporarily silence the audio.

6.4 EQ Modes

The soundbar features multiple Equalizer (EQ) modes to optimize audio for different content types. Press the corresponding buttons on the remote control to select:

- **MUSIC:** Optimized for music playback.
- **MOVIE:** Enhanced for cinematic audio experiences.
- **NEWS:** Clearer vocal reproduction for news and dialogue.
- **3D:** Creates a wider, more immersive soundstage.

Additionally, use **BASS+** and **BASS-** buttons to adjust the subwoofer's bass level independently.

6.5 Bluetooth Pairing

1. Turn on the soundbar and select Bluetooth mode using the **Input** button. The LED indicator will flash, indicating pairing mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "Mivi Nex 200" from the list. Once connected, the LED indicator will stop flashing and remain solid.
4. You can now play audio from your device through the soundbar.

7. Maintenance

- Clean the soundbar and subwoofer with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- Keep the ventilation openings clear of dust and debris.
- Store the unit in a cool, dry place when not in use for extended periods.

8. Troubleshooting

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not active	Ensure power cable is securely connected. Check power outlet with another device.
No sound	Incorrect input selected; Volume too low; Cables not connected properly	Select the correct input source. Increase volume. Check all audio cables are securely connected.
Bluetooth pairing fails	Soundbar not in pairing mode; Device too far; Interference	Ensure soundbar is in Bluetooth pairing mode. Move device closer. Avoid other wireless devices during pairing.
Remote control not working	Batteries depleted; Obstruction between remote and soundbar	Replace remote control batteries. Ensure a clear line of sight to the soundbar's sensor.
Subwoofer not producing bass	Subwoofer cable loose; Bass level set too low	Check the subwoofer connection cable. Increase bass level using the remote control.

9. Specifications

Feature	Detail
Model Name	Mivi Nex 200 Soundbar
Model Number	SWFTS36
Speaker Type	Surround Sound
Channel Configuration	2.1 Channel
Total Output Power	200 Watts
Connectivity Technology	Bluetooth v5.3, HDMI ARC, Optical, Coaxial, AUX, USB
Wireless Communication	Bluetooth
Bluetooth Version	5.3
Subwoofer Connectivity	Wired
Control Method	Remote
Product Dimensions	69D x 45W x 23H Centimeters
Item Weight	8.6 Kilograms
Power Source	Corded Electric
Special Features	Hi Res Audio, USB Port
Mounting Type	Wall Mount

10. Warranty and Support

The Mivi Nex 200 Soundbar comes with a Limited Warranty. For detailed warranty terms and conditions, please refer to the warranty card included in your package or visit the official Mivi website.

For technical support, service, or inquiries, please contact Mivi customer service through their official channels. Manufacturer contact information:

Manufacturer: Mivi
Plot No, 29, Rd Number 76, Jubilee Hills, Hyderabad, Telangana 500033

© 2026 Mivi. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question