Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TABU 4101512/4100431

TABU Compact Washer and Dryer Combo User Manual

Model: 4101512/4100431

Introduction

Thank you for choosing the TABU Compact Washer and Dryer Combo. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your appliance. Please read this manual thoroughly before using the product and retain it for future reference.



Image: The TABU Compact Washer and Dryer Combo, featuring a brown and black washing machine and a compact dryer unit.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury to persons when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not wash or dry articles that have been previously cleaned in, washed in, soaked in, or spotted with gasoline, dry-cleaning solvents, or other flammable or explosive substances, as they emit vapors that could ignite or explode.
- Do not allow children to play on or in the appliance. Close supervision of children is necessary when the appliance is used near children.
- Before the appliance is removed from service or discarded, remove the door to the washing compartment.
- Do not reach into the appliance if the tub or drum is moving.
- Do not install or store this appliance where it will be exposed to the weather.
- Do not tamper with controls.

- Do not repair or replace any part of the appliance or attempt any servicing unless specifically recommended in the user-maintenance instructions or in published user-repair instructions that you understand and have the skills to carry out.
- Do not use fabric softeners or products to eliminate static unless recommended by the manufacturer of the fabric softener or product.
- Do not use heat to dry articles containing foam rubber or similarly textured rubber-like materials.
- Clean the lint screen before or after every load.
- Do not allow lint to accumulate around the dryer.
- Do not operate the dryer with a loose or missing lint screen.
- Do not obstruct the flow of ventilating air.
- Do not install the dryer with flexible plastic venting material.
- Do not place items exposed to cooking oils in your dryer. Items contaminated with cooking oils may contribute to a chemical reaction that could cause a load to catch fire.
- Always follow the fabric care instructions supplied by the garment manufacturer.
- Do not use this appliance for purposes other than its intended use.
- Always disconnect the appliance from the power supply before cleaning or performing any maintenance.

Setup and Installation

1. Unpacking and Placement

Carefully remove the appliance from its packaging. Ensure all packing materials are removed. Place the washer and dryer on a stable, level surface. The washer dimensions are approximately 18.31"D x 18.7"W x 32.3"H. The dryer dimensions are approximately 19.49"D x 23.43"W x 17.13"H.



Image: The TABU washing machine positioned in a bathroom next to a sink and a laundry basket.



Image: The TABU compact dryer placed on a shelf in a laundry area, demonstrating its compact size.

2. Installing the Bottom Cover (Washer)

Attach the snap-on bottom cover to the base of the washing machine. Align the buckles and press them in one by one until secure.

Your browser does not support the video tag.

Video: Installation guide for the Zynkez Full-automatic Washing Machine, showing how to install the snap-on bottom cover and adjust the leveling legs.

3. Leveling the Machine

Adjust the leveling legs at the bottom of the washing machine to ensure it is stable and level. This prevents excessive vibration during operation.

4. Water Inlet Connection (Washer)

Remove the original faucet aerator. Connect the provided adapter to the faucet, then press the adapter downward to

secure it. Attach the inlet pipe to the adapter and connect the other end to the water inlet on the washing machine.

Your browser does not support the video tag.

Video: Installation guide for the Zynkez Full-automatic Washing Machine, demonstrating how to connect the water inlet pipe to a faucet using an adapter.

5. Drainage Hose Connection (Washer)

Connect the gray drainage hose to the washing machine. The other end of the hose should be placed in a sink or a suitable drainage area to discharge dirty water.



Image: Detailed view of the TABU washing machine, highlighting the transparent glass top cover, stainless steel inner tub, longer drain hose, water inlet, LED control panel, and built-in filter.

6. Power Connection

Plug the appliance into a standard 110V electrical outlet.

7. Dryer Vent Installation (Dryer)

Attach the 90-degree elbow to the dryer's exhaust port. Secure the clamp on the dryer vent hose and attach it to the elbow. Tighten the clamp to ensure a secure connection. The flexible exhaust hose can be extended or collapsed as needed. If using indoors, ensure proper ventilation, possibly through a window using a portable AC vent kit.

Your browser does not support the video tag.

Video: Preview of the Zynkez Portable Clothes Dryer, showing the installation of the exhaust hose and demonstrating its flexibility.

Operating Instructions

Washing Machine Operation

1. **Load Laundry:** Open the transparent glass top cover and place up to 18 lbs of clothes into the stainless steel inner tub.
2. **Add Detergent:** Add the appropriate amount of detergent according to the load size and detergent instructions.
3. **Power On:** Press the **ON/OFF** button to power on the machine.
4. **Select Water Level:** Use the **Water Level Program** button to choose from 8 available water levels (1-8).
5. **Select Washing Program:** Use the **Procedure** button to select one of the 10 washing programs (Normal, Quick, Strong, Heavy, Soft, Jeans, Baby Care, Spin Only, Auto Clean, Tub Clean).
6. **Start Cycle:** Press the **Start/Pause** button to begin the washing cycle. The LED display will show the remaining time.
7. **Automatic Balance Adjustment:** The machine features an automatic balance detection mechanism to correct tub imbalance and reduce vibration.
8. **Child Lock:** To activate the child lock, press and hold the **Water Level Program** button for 3 seconds.



Image: Close-up of the TABU washing machine's smart control panel with LED display, showing options for water level, programs, and time settings.

Dryer Operation

1. **Load Laundry:** Open the dryer door and place up to 10 lbs of wet clothes into the stainless steel drum.
2. **Select Drying Mode:** Use the control knob to select one of the 4 drying modes:
    - **Auto:** Automatically adjusts drying time based on humidity.
    - **Delicates Dry:** For small clothes or delicate fabrics.
    - **Air Dry:** Uses cool air to freshen clothes.
    - **Timer Setting:** Manually set drying time (30/60/90 minutes).
3. **Start Drying:** Turn the knob to the desired setting to start the drying cycle.
4. **High Temperature Disinfection:** The dryer can reach temperatures of 149°F for disinfection and sterilization.



Image: Close-up of the TABU compact dryer's control knob, showing various timer and drying options.



Image: Illustration of the TABU compact dryer's high temperature disinfection feature, showing heat radiating from the drum.

MAINTENANCE

1. Cleaning the Lint Filter (Dryer)

Regularly clean the detachable outlet filter in the dryer to maintain optimal drying performance and prevent lint buildup. Clean before or after every load.

Your browser does not support the video tag.

Video: Preview of the Zynkez Portable Clothes Dryer, showing the stainless steel drum and detachable outlet filter.

2. Cleaning the Washer Tub

Use the "Tub Clean" program (HH) periodically to clean the stainless steel inner tub of the washing machine. This helps prevent odor and residue buildup.

3. General Cleaning

Wipe down the exterior of both units with a soft, damp cloth. Do not use abrasive cleaners or solvents.

Troubleshooting

Problem	Possible Cause	Solution
Washer not starting	Not plugged in; lid not closed; power outage.	Check power connection; ensure lid is fully closed; check circuit breaker.
Excessive vibration (Washer)	Uneven load; machine not level.	Redistribute laundry evenly; adjust leveling legs.
Water not draining (Washer)	Drain hose kinked or blocked.	Check drain hose for obstructions or kinks.
Clothes not drying completely (Dryer)	Lint filter clogged; overloaded; improper setting.	Clean lint filter; reduce load size; select appropriate drying mode.
Dryer not heating	Heat setting too low; power issue.	Ensure correct heat setting is selected; check power connection.

Specifications

- **Brand:** TABU
- **Model Number:** 4101512/4100431
- **Washer Capacity:** 18 Pounds (approx. 2.6 Cu.Ft)
- **Dryer Capacity:** 2.6 Cu.Ft (up to 10 lbs of clothes)
- **Washer Dimensions (D x W x H):** 18.31" x 18.7" x 32.3"
- **Dryer Dimensions (D x W x H):** 19.49" x 23.43" x 17.13"
- **Item Weight:** 51 pounds
- **Washing Programs:** 10 (Normal, Quick, Strong, Heavy, Soft, Jeans, Baby Care, Spin Only, Auto Clean, Tub Clean)
- **Water Levels:** 8
- **Drying Modes:** 4 (Auto, Delicates Dry, Air Dry, Timer Setting)
- **Dryer Heat:** Up to 149°F (for disinfection)
- **Power:** 110V (standard outlet)
- **Inner Tub Material:** Stainless Steel
- **Color:** Brown&Black

- **UPC:** 764143650453

Warranty Information

For information regarding product warranty, please refer to the warranty card included with your purchase or contact TABU customer support directly. Protection plans are also available for purchase, offering extended coverage.

- **Protection Plan Example:** Complete Protect: One plan covers all eligible past and future purchases (e.g., $16.99/month).

Customer Support

If you encounter any issues or have questions about your TABU Compact Washer and Dryer Combo, please contact our customer support team. You can find contact information on the official TABU website or through your purchase platform. Visit the TABU Store for more information and support resources.

© 2025 TABU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G3KLV8PY

More documents and user manuals: **https://manuals.plus/**