Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EROMMY PXDNHM028

EROMMY 70-inch Fluted TV Stand Instruction Manual

Model: PXDNHM028

Introduction Safety
Information Components Setup Operation Maintenance Troubleshooting Specifications Support

1. Introduction

Thank you for choosing the EROMMY 70-inch Fluted TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions carefully before beginning assembly and retain them for future reference.
This modern TV console features a faux marble top, curved design, and tambour sliding doors, offering both style and functional storage for TVs up to 80 inches.

2. Safety Information

- **Weight Capacity:** Do not overload the TV stand. The tabletop has a maximum weight capacity of 400 lbs. Individual shelves have a maximum weight capacity of 22 lbs. Exceeding these limits may result in damage or injury.
- **Sharp Edges:** Be cautious of sharp edges during assembly and handling.
- **Assembly:** Securely fasten all components during assembly. Improper assembly can lead to instability and tip-over risks.
- **Stability:** Ensure the TV stand is placed on a level surface. Use the adjustable feet to compensate for uneven floors.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the TV stand.
- **Tools:** Use appropriate tools for assembly as specified in the assembly guide.

3. Included Components

Before assembly, verify that all parts are present and undamaged. Refer to the separate assembly guide for a detailed list of hardware and panels. Typically, your package includes:

- Main TV stand panels (top, bottom, side, back panels)
- Tambour sliding doors
- Adjustable shelves
- 6 Iron Legs (with protective pads)

- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly instructions manual



Figure 3.1: Overview of the TV stand's storage compartments and components.

4. Setup and Assembly

Assembly is required for this product. Please follow the detailed step-by-step instructions provided in the separate assembly guide included in your package. Ensure you have sufficient space and the necessary tools before starting.

4.1 Preparation

- Clear a spacious, clean area for assembly.
- Lay out all components and hardware, matching them against the parts list in the assembly guide.
- Gather necessary tools (e.g., screwdriver, hammer).

4.2 Assembly Steps (General Overview)

1. Attach the metal legs to the bottom panel of the TV stand. Two of the legs are height-adjustable; install these where needed to ensure stability.
2. Assemble the main frame of the TV stand using the provided hardware.
3. Install the adjustable shelves into the designated cabinet sections.
4. Insert the tambour sliding doors into their tracks.
5. Attach any remaining decorative elements or handles.
6. Once assembled, carefully move the TV stand to its desired location.



Figure 4.1: Elevated metal legs with adjustable feet for stability.



Figure 4.2: Details of cable management holes and tambour door.

5. Operation

The EROMMY TV Stand is designed for versatile use and organization of your entertainment devices and media.

5.1 Placing Your Television

- The tabletop is suitable for TVs up to 80 inches.
- Ensure the TV's base fits securely within the dimensions of the tabletop (68.9 inches L x 15.8 inches W).
- Center the TV on the stand to distribute weight evenly.

5.2 Storage and Organization

- **Tambour Sliding Doors:** The two tambour doors on either side slide smoothly to conceal or reveal storage compartments.
- **Adjustable Shelves:** The cabinets behind the tambour doors feature adjustable shelves. You can reposition these

shelves to accommodate items of various heights.

- **Central Open Shelf:** Use the central open shelf for frequently accessed devices like soundbars, gaming consoles, or media players.
- **Cable Management:** Utilize the built-in cable management holes located at the back of the central and side compartments to route and organize power cords and AV cables, maintaining a tidy appearance.



Figure 5.1: Product dimensions and weight limits for TV and shelves.



Figure 5.2: Design features including the faux marble top and fluted doors.

6. Care and Maintenance

Proper care will help maintain the appearance and longevity of your EROMMY TV stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Immediately wipe up any spills to prevent staining, especially on the faux marble top.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the stand away from excessive moisture or direct sunlight to prevent warping or fading.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Moving:** When moving the TV stand, always lift it rather than dragging it to prevent damage to the legs and frame.

7. Troubleshooting

If you encounter any issues with your TV stand, refer to the following common solutions:

- **Stand is Wobbly:**
  Solution: Ensure the stand is on a level surface. Adjust the height-adjustable feet on the iron legs until the stand is stable. Check that all assembly screws are securely tightened.
- **Tambour Doors Not Sliding Smoothly:**
  Solution: Check the tracks for any obstructions or debris. Ensure the doors are properly seated in their grooves. A light application of silicone spray (not oil-based lubricants) on the tracks may improve movement.
- **Parts Missing or Damaged:**
  Solution: If you find any parts missing or damaged upon unboxing, do not proceed with assembly. Contact EROMMY customer support immediately for assistance.
- **Difficulty During Assembly:**
  Solution: Review the assembly instructions carefully. Ensure you are using the correct hardware for each step. If issues persist, contact customer support.

8. Specifications

Feature	Detail
Model Number	PXDNHM028
Brand	EROMMY
Color	Natural Oak
Material Type	Engineered Wood
Overall Dimensions (L x W x H)	68.9 inches x 15.8 inches x 24 inches
Item Weight	66 Pounds
Style	Modern
TV Support	Up to 80 inches
Tabletop Load Capacity	400 lbs
Shelf Load Capacity	22 lbs (each)
Assembly Required	Yes

9. Customer Support

For any questions, concerns, or assistance with your EROMMY TV stand, please contact our customer support team. We are dedicated to ensuring your complete satisfaction.

- **Online Support:** Visit the official EROMMY website for FAQs and support resources.
- **Contact Email:** Refer to your purchase documentation for direct contact email.
- **Phone Support:** Refer to your purchase documentation for direct phone support.

Please have your model number (PXDNHM028) and purchase date ready when contacting support.

© 2024 EROMMY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G3P4BJCL

More documents and user manuals: **https://manuals.plus/**