Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Brother J1360

Brother Work Smart J1360 Wireless Printer User Manual

Essential Guide for Setup, Operation, and Maintenance

Introduction Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides comprehensive instructions for the Brother Work Smart J1360 Wireless Printer. It covers installation, configuration, maintenance, and troubleshooting to ensure optimal performance. This guide is designed for both new users and those seeking to enhance their understanding of the printer's advanced features.
You will find detailed instructions for printing, scanning, copying, network setup, ink management, and diagnostic techniques. Each section simplifies complex processes, guiding you through daily tasks and revealing hidden maintenance features.

2. Setup

2.1 Unpacking and Initial Hardware Setup

Carefully remove the printer from its packaging. Remove all protective tapes and packing materials from the exterior and interior of the printer. Connect the power cord to the printer and then to an electrical outlet.

2.2 Ink Cartridge Installation (LC501 Inks)

1. Open the ink cartridge cover.
2. Unpack each LC501 ink cartridge.
3. Insert each cartridge into its corresponding slot, ensuring it clicks into place.
4. Close the ink cartridge cover. The printer will initiate an ink charging process.

2.3 Software Installation and Wi-Fi Setup

Insert the installation CD-ROM into your computer's drive or download the latest drivers and software from the official Brother support website. Follow the on-screen instructions to install the necessary software. During the setup process, you will be prompted to configure the wireless connection. Select your Wi-Fi network and enter the password.

3. Operating the Printer

3.1 Basic Printing

To print a document, open the file on your computer, select "Print" from the application's menu, and choose the Brother J1360 printer. Adjust print settings such as paper size, orientation, and quality as needed.

3.2 Duplex Printing (Two-Sided)

For automatic two-sided printing, ensure your printer drivers are up to date. In the print dialog box, navigate to the printer properties or preferences. Look for an option related to "Duplex Printing" or "Two-Sided Printing" and enable it. Select the desired binding edge (long-edge or short-edge).

3.3 Scanning Documents

Place the document face down on the scanner glass or face up in the Automatic Document Feeder (ADF). Open the Brother ControlCenter software on your computer, select "Scan," and choose your desired scan settings (e.g., document type, resolution, destination). Click "Scan" to begin.

3.4 Copying Documents

Place the document on the scanner glass or in the ADF. On the printer's display panel, select "Copy." You can adjust settings such as number of copies, quality, and zoom. Press "Start" to initiate the copying process.

3.5 Display Controls

The printer features an intuitive display panel. Use the arrow keys to navigate through menus and options. The "OK" button confirms selections, and the "Back" button returns to the previous screen. The display provides status updates, error messages, and access to various printer functions.

4. Maintenance

4.1 Ink Management and Replacement (LC501 Inks)

Monitor ink levels regularly through the printer's display or the Brother ControlCenter software. When an LC501 ink cartridge is low or empty, replace it promptly to maintain print quality and prevent damage. Use genuine Brother LC501 ink cartridges for optimal performance.

4.2 Print Head Cleaning

If print quality deteriorates (e.g., streaky prints, missing colors), perform a print head cleaning. This can be initiated from the printer's maintenance menu or through the printer driver software on your computer. Multiple cleaning cycles may be required.

4.3 Regular Cleaning

Wipe the exterior of the printer with a soft, lint-free cloth. Clean the scanner glass periodically with a non-abrasive glass cleaner to ensure clear scans and copies.

4.4 Accessing Maintenance Mode

The Brother J1360 has a hidden Maintenance Mode for advanced diagnostics and recovery functions. Accessing this mode typically involves a specific key combination on the control panel during power-on. Refer to the detailed service manual or Brother's official support for specific instructions and caution when using these functions.

5. Troubleshooting

5.1 Paper Jams

If a paper jam occurs, the printer display will show an error message. Carefully open the printer covers as indicated in the error message and gently remove any jammed paper. Ensure no small pieces of paper remain inside. Close all covers securely.

5.2 Print Quality Issues (Streaks, Fading)

- Perform a print head cleaning (refer to Section 4.2).
- Check ink levels and replace any low or empty LC501 cartridges.
- Ensure you are using appropriate paper for your print settings.
- Perform a print head alignment from the printer's maintenance menu.

5.3 Wireless Connection Problems

- Verify that the printer is within range of your Wi-Fi router.
- Restart your printer, computer, and Wi-Fi router.
- Check the Wi-Fi settings on the printer's display panel to ensure it's connected to the correct network.
- Run the network connection test from the printer's settings menu.

5.4 Error Messages

If an error message appears on the display, note the error code or message. Consult the Brother support website or the full electronic manual for specific solutions related to that error.

6. Specifications

Model	Brother Work Smart J1360
Printer Type	Color Inkjet All-in-One
Connectivity	Wireless (Wi-Fi)
Ink Type	LC501 Series Ink Cartridges
Functions	Print, Scan, Copy, Duplex Print
Dimensions (Approx.)	Refer to official Brother product page for exact dimensions.
Weight (Approx.)	Refer to official Brother product page for exact weight.

7. Warranty & Support

7.1 Product Warranty

The Brother Work Smart J1360 Wireless Printer comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, duration, and coverage, please refer to the warranty card included with your product or visit the official Brother support website.

7.2 Customer Support

For technical assistance, driver downloads, FAQs, or further troubleshooting, please visit the official Brother support website. You can also find contact information for customer service in your region on their website.
Official Brother Support Website: www.brother.com/support

© 2023 Brother International Corporation. All rights reserved. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G3XJ37YD

More documents and user manuals: **https://manuals.plus/**