Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Luqeeg Luqeegxr35nwh6fo-11

Luqeeg MP3 MP4 Player 5.0 Instruction Manual

Model: Luqeegxr35nwh6fo-11

1. Introduction

Thank you for purchasing the Luqeeg MP3 MP4 Player 5.0. This ultra-thin, portable device is designed for high-fidelity audio playback and offers a range of multimedia functions including FM radio, voice recording, e-book reading, picture browsing, and video playback. This manual provides essential information for setting up, operating, and maintaining your device.

2. Product Overview



Figure 2.1: Front view of the Luqeeg MP3 MP4 Player, showing the screen and control buttons.

2.1 Device Layout

- **Screen:** 1.77-inch display for navigation and content viewing.
- **Control Buttons:** M (Menu), Play/Pause, Skip Forward, Skip Backward, VOL (Volume).
- **Ports:** USB charging/data port, 3.5mm headphone jack.
- **Microphone:** For voice recording.



Figure 2.2: Close-up view of the USB port and 3.5mm headphone jack.

2.2 Dimensions



Figure 2.3: Device dimensions: approximately 90.5mm (length) x 39.5mm (width) x 10mm (thickness).

3. Setup

3.1 Initial Charging

Before first use, fully charge the device. Connect the included USB cable to the player's USB port and the other end to a USB power adapter (not included) or a computer's USB port. The charging time is approximately 1-2 hours.



Figure 3.1: The included USB cable for charging and data transfer.

3.2 Connecting to a Computer

To transfer files (music, videos, e-books, pictures), connect the player to your computer using the USB cable. The device will appear as a removable disk drive. Drag and drop your desired files into the appropriate folders on the player.

3.3 Inserting a Memory Card (Optional)

The player supports memory cards up to 128GB for expanded storage. Locate the memory card slot on the side of the device and gently insert a compatible memory card until it clicks into place. Ensure the card is inserted in the correct orientation.

3.4 Connecting Headphones/Speakers

Plug your 3.5mm wired headphones or external speakers into the headphone jack on the player. For wireless audio, the device features 5.0 connectivity. Navigate to the settings menu to pair with compatible wireless headphones or speakers.

4. Operating Instructions

4.1 Power On/Off

- **To Power On:** Press and hold the Play/Pause button for a few seconds.
- **To Power Off:** Press and hold the Play/Pause button for a few seconds until the screen turns off.

4.2 Basic Navigation

- **M (Menu) Button:** Press to enter the main menu or go back to the previous screen.
- **Play/Pause Button:** Confirms selections, plays/pauses media.
- **Skip Forward/Backward Buttons:** Navigate through menus, skip tracks, or fast forward/rewind.
- **VOL (Volume) Buttons:** Adjust the audio volume.

4.3 Music Playback

1. From the main menu, select 'Music'.
2. Browse your music library by artist, album, genre, or all songs.
3. Select a song and press the Play/Pause button to begin playback.
4. Supported formats include MP3, WAV, APE, FLAC, WMA, and AAC LC.

4.4 FM Radio

1. Connect wired headphones, as they act as the antenna.
2. From the main menu, select 'FM Radio'.
3. Use the navigation buttons to scan for stations or manually tune to a frequency.
4. The FM reception frequency range is 87.5 MHz-108 MHz.

4.5 Recording Function

1. From the main menu, select 'Record'.
2. Choose 'Start Voice Recording' to begin.
3. Press Play/Pause to stop and save the recording.
4. Recordings are saved in MP3 or WAV format.

4.6 E-Book Reader

1. Transfer TXT format e-books to the device.
2. From the main menu, select 'E-Book'.

3. Select your desired book to read.
4. The device supports TXT format.

4.7 Picture Viewer

1. Transfer BMP or JPG images to the device.
2. From the main menu, select 'Pictures'.
3. Browse and select an image to view.

4.8 Video Playback

1. Videos must be in MP4 format and may require conversion on a PC using specific tools before transfer.
2. From the main menu, select 'Video'.
3. Select a video file to play.

4.9 Language Settings

The device supports 9 national languages. Access the 'Settings' menu to change the display language.

4.10 Day and Night Mode

Toggle between Day and Night modes in the settings for optimal screen visibility in different lighting conditions.

5. Maintenance

5.1 Cleaning

- Wipe the device with a soft, dry, lint-free cloth.
- Do not use liquid cleaners, aerosols, or solvents.

5.2 Battery Care

- Avoid exposing the device to extreme temperatures (hot or cold).
- Charge the battery regularly, even if not in frequent use, to maintain battery health.
- Do not attempt to replace the built-in battery yourself.

5.3 Storage

Store the player in a cool, dry place away from direct sunlight and moisture when not in use.

6. Troubleshooting

Problem	Possible Solution
Device will not power on.	Ensure the battery is charged. Connect to a power source and try again.
No sound from headphones.	Check if headphones are properly plugged in. Verify volume level. Test with different headphones.
Files not recognized or playing.	Ensure files are in supported formats (e.g., MP3 for music, TXT for e-books, MP4 for video after conversion). Check if files are stored in the correct folders.

Problem	Possible Solution
Screen is unresponsive.	Try restarting the device by holding the power button. If unresponsive, allow the battery to drain completely and then recharge.
Cannot connect to device.	Ensure the device is in pairing mode. Check that the device is within range of the player.

7. Specifications

- **Model:** Luqeegxr35nwh6fo-11
- **Material:** ABS
- **Dimensions:** Approx. 90.5 x 39.5 x 10 mm (3.6 x 1.6 x 0.4 inches)
- **Screen:** 1.77 Inch LCD
- **Battery:** Built-in Lithium Ion, 250 MA capacity
- **Charging Time:** 1-2 hours
- **Music Playback Time:** Up to 7 hours
- **Connectivity:** 5.0, USB
- **Memory Card Support:** Up to 128GB (card not included)
- **FM Radio Frequency:** 87.5 MHz - 108 MHz
- **Supported Music Formats:** MP3, WAV, APE, FLAC, WMA, AAC LC
- **Supported Recording Formats:** MP3, WAV (FM MIC Recording)
- **Supported E-book Format:** TXT
- **Supported Image Formats:** BMP, JPG
- **Supported Video Format:** MP4 (requires PC conversion)
- **Languages:** Supports 9 national languages

8. Warranty Information

This Luqeeg MP3 MP4 Player is covered by a manufacturer's warranty for 90 days from the date of purchase. This warranty covers manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

9. Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact the seller or Luqeeg customer support through the platform where you purchased the product. Provide your model number (Luqeegxr35nwh6fo-11) and a detailed description of the problem for efficient support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G491QQLJ

More documents and user manuals: **https://manuals.plus/**