Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ULTRON FryFit 45S

Ultron Air Fryer Digital 4.5 L FryFit 45S

INSTRUCTION MANUAL

Introduction

Thank you for choosing the Ultron FryFit 45S Digital Air Fryer. This appliance utilizes rapid hot air circulation technology to cook your favorite foods with little to no oil, offering a healthier alternative to traditional frying. Please read this manual thoroughly before first use to ensure safe and optimal operation of your air fryer. Keep this manual for future reference.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before operating the appliance.
- Do not immerse the cord, plugs, or the appliance housing in water or other liquid to prevent electric shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use attachments not recommended by the appliance manufacturer, as this may cause injuries.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, heat-resistant surface.
- Do not block the air inlet or air outlet openings.
- The outer surfaces of the air fryer may become hot during use. Use oven mitts when handling hot components.

Product Overview

The Ultron FryFit 45S Air Fryer consists of the main unit, a digital touch control panel, and a removable non-stick food basket.



Image: Ultron FryFit 45S Digital Air Fryer, showing the main unit with its sleek design and digital display.

Components:

- **Main Unit:** Houses the heating element and fan.
- **Digital Touch Panel:** For controlling temperature, time, and selecting presets.
- **Removable Non-Stick Food Basket:** For holding food during cooking.
- **Handle:** For safely pulling out and inserting the food basket.
- **Air Inlet/Outlet:** For proper air circulation during operation.



Image: Close-up of the Ultron FryFit 45S Digital Air Fryer's smart touch display, showing various preset icons for different food types.

Setup

1. **Unpack:** Carefully remove the air fryer and all packaging materials from the box.
2. **Clean Components:** Wash the removable food basket and grill thoroughly with warm, soapy water. Rinse and dry completely. Wipe the exterior of the appliance with a damp cloth.
3. **Placement:** Place the air fryer on a stable, level, heat-resistant surface, away from walls or other appliances to allow for proper air circulation. Ensure there is at least 10 cm (4 inches) of free space on the back and sides, and 10 cm (4 inches) above the appliance.
4. **Power Connection:** Plug the power cord into a grounded wall outlet. The appliance is now ready for use.

Operating Instructions

Preheating (Optional but Recommended):

Preheating helps achieve optimal cooking results and crispiness.

1. Plug in the air fryer. The display will light up.
2. Press the power button to turn on the appliance.
3. Set your desired temperature (e.g., 180°C) and time (e.g., 3-5 minutes) manually using the temperature and timer controls.
4. Press the start button to begin preheating.

Cooking with the Air Fryer:

1. **Prepare Food:** Place your ingredients into the food basket. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the food basket back into the air fryer until it clicks into place.
3. **Power On:** Press the power button.
4. **Select Cooking Method:**
    - **Using Presets:** Press the 'Menu' button to cycle through the 8 preset cooking programs (Sweet Potato, Shrimp, Egg Tart, Chicken Wing, Steak, Chicken, Chips, Vegetables). Once a preset is selected, the air fryer will automatically set the optimal temperature and time.
    - **Manual Setting:** Use the temperature control buttons (up/down arrows) to set the desired temperature (60°C to 200°C) and the timer control buttons to set the cooking time.
5. **Start Cooking:** Press the start button to begin the cooking process.
6. **Shake Basket (Mid-Cycle):** For some foods, especially fries or smaller items, shaking the basket halfway through the cooking time helps ensure even browning. The air fryer may beep to remind you to shake. Carefully pull out the basket, shake the contents, and reinsert. The cooking will resume automatically.
7. **Completion:** The air fryer will beep when the cooking time is complete. Carefully pull out the basket and transfer the cooked food to a plate.



Image: The Ultron FryFit 45S Digital Air Fryer displaying its 8 cooking presets, including options for sweet potato, shrimp, egg tart, chicken wing, steak, chicken, chips, and vegetables.

Cooking Guide

The Ultron FryFit 45S is versatile and can be used for frying, grilling, roasting, and baking. Here are some general guidelines:

- **Oil Usage:** While the air fryer cooks with little to no oil, a small amount of oil (1-2 tablespoons) can be added to some foods for extra crispiness and flavor. Toss food with oil before placing it in the basket.
- **Food Size:** Cut food into uniform pieces for even cooking.
- **Batch Cooking:** For larger quantities, cook in smaller batches to avoid overcrowding the basket, which can lead to uneven cooking.
- **Checking Doneness:** Always ensure food is cooked to a safe internal temperature.



Image: The Ultron FryFit 45S Digital Air Fryer with its basket pulled out, showing cooked chicken and vegetables, highlighting its ability to cook with significantly less oil.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your air fryer.

1. **Unplug and Cool:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Food Basket and Grill:** Remove the food basket and grill. Wash them with warm, soapy water using a non-abrasive sponge. The non-stick coating allows for easy cleaning. Rinse thoroughly and dry completely. *Note: The basket and grill are not dishwasher safe.*
3. **Clean Interior:** Wipe the interior of the air fryer with a damp cloth. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
4. **Clean Exterior:** Wipe the exterior of the appliance with a damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer in a cool, dry place.



Image: The Ultron FryFit 45S Digital Air Fryer with its non-stick food basket removed, illustrating the ease of access for cleaning.

Troubleshooting

If you encounter any issues with your Ultron FryFit 45S Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on.	Appliance is not plugged in. Power outlet is not working.	Ensure the power cord is securely plugged into a working grounded outlet. Check the circuit breaker.
Food is not cooked evenly.	Basket is overcrowded. Food pieces are not uniform.	Cook food in smaller batches. Cut ingredients into similar sizes. Shake the basket halfway through cooking.

Problem	Possible Cause	Solution
White smoke comes from the appliance.	Grease residue from previous use. Fatty ingredients are being cooked.	Clean the basket and interior thoroughly after each use. For fatty foods, absorb excess oil with a paper towel before cooking.
Food is not crispy.	Not enough oil (for some foods). Temperature too low or time too short. Basket overcrowded.	Lightly brush or spray food with oil. Increase temperature or cooking time. Cook in smaller batches.

Specifications

Technical details for the Ultron FryFit 45S Digital Air Fryer:

Feature	Specification
Model Name	FryFit 45S
Capacity	4.5 litres
Output Wattage	1200 Watts
Voltage	240 Volts
Min Temperature Setting	60 Degrees Celsius
Max Temperature Setting	200 Degrees Celsius
Control Method	Touch
Product Dimensions (D x W x H)	28D x 28W x 30H Centimeters
Item Weight	3.1 Kilograms
Material	Acrylonitrile Butadiene Styrene (ABS)
Inner Material	Non-stick
Special Features	Overheat protection, Programmable, Temperature Control
Air Frying Technology	Rapid Air Circulation
Dishwasher Safe	No



Image: Diagram showing the dimensions of the Ultron FryFit 45S Digital Air Fryer: 28 cm (depth) x 28 cm (width) x 30 cm (height).

Warranty

The Ultron FryFit 45S Digital Air Fryer comes with a**1 Year Service Warranty** from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty covers manufacturing defects and faulty workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.

Customer Support

For any questions, assistance, or warranty claims regarding your Ultron FryFit 45S Digital Air Fryer, please contact Ultron Home Appliances private Limited.

Manufacturer/Importer Contact Information:

Ultron Home Appliances private Limited

THULSINGHAM STREET, CHENNAI-79

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G4LYWHW7

More documents and user manuals: **https://manuals.plus/**