Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OMOTON B0G52FLMD5

OMOTON AZERTY Wireless Keyboard and Mouse User Manual

Model: B0G52FLMD5

Introduction

Thank you for choosing the OMOTON AZERTY Wireless Keyboard and Mouse Set. This ergonomic and rechargeable combo is designed to enhance your productivity and comfort. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure you get the most out of your device.

Package Contents

- 1 x OMOTON AZERTY Wireless Keyboard
- 1 x OMOTON Wireless Mouse
- 1 x 2.4GHz USB Receiver
- 1 x Type-C Charging Cable
- 1 x User Manual (this document)

Product Overview

Keyboard Features

- **AZERTY Layout:** Standard French keyboard layout.
- **Ergonomic Design:** Integrated wrist rest and adjustable tilt feet for comfortable typing.
- **7-Color Backlight:** Dimmable backlight with 7 color options for improved visibility.
- **Built-in Phone Holder:** Convenient slot for holding smartphones or small tablets.
- **Quiet Scissor-Structure Keys:** Provides a silent and comfortable typing experience.
- **Rechargeable Battery:** 500mAh built-in lithium battery.



Image: The OMOTON AZERTY Wireless Keyboard showcasing its ergonomic design, including the integrated wrist rest and adjustable tilt angle for comfortable use. A comparison is shown between the ergonomic posture provided by this keyboard and a standard flat keyboard.



Image: The OMOTON AZERTY Wireless Keyboard featuring its built-in phone holder, designed to keep your smartphone or small tablet upright for easy viewing and improved workflow.



Image: Detailed dimensions of the OMOTON AZERTY Wireless Keyboard and Mouse, illustrating the full-size keyboard with numeric keypad and the compact ergonomic mouse.

Mouse Features

- **Ergonomic Design:** Contours to the hand for comfortable use.
- **Adjustable DPI:** 800/1200/1600/2400 DPI settings for precise control.
- **7-Color Backlight:** Automatic cycling 7-color backlight.
- **Rechargeable Battery:** 300mAh built-in lithium battery.



Image: The OMOTON Wireless Mouse, highlighting its ergonomic shape and labeled buttons including left click, right click, scroll wheel, DPI adjustment button, forward button, and back button.

Setup

1. **Charge the Devices:** Before first use, fully charge both the keyboard and mouse using the provided Type-C charging cable. The keyboard has a 500mAh battery and the mouse has a 300mAh battery.
2. **Locate the USB Receiver:** The 2.4GHz USB receiver is typically stored in a compartment on the mouse or keyboard. Remove it carefully.
3. **Connect the Receiver:** Plug the 2.4GHz USB receiver into an available USB port on your computer (Windows or Linux PC).
4. **Power On:** Turn on the keyboard and mouse using their respective power switches. The devices should automatically connect to your computer.
5. **Configure AZERTY Layout (Important for French Users):**

For optimal use with the AZERTY layout, you must configure your computer's virtual keyboard to French. Follow these general steps:

- Go to your computer's **Settings**.
- Navigate to **Physical Keyboard** settings (or similar, depending on OS).
- Select **AZERTY** layout.

Refer to your operating system's documentation for specific instructions on changing keyboard layouts.



Image: Illustration of the OMOTON AZERTY Wireless Keyboard and Mouse establishing a stable 2.4GHz wireless connection using a single USB receiver, demonstrating a clutter-free workspace.

Operating Instructions

Keyboard Operation

- **Backlight Control:** Use the dedicated backlight key (often marked with a light bulb icon or similar) to cycle through

7 colors and 3 brightness levels. You can also turn off the backlight to conserve battery.

- **Function Keys:** The top row of keys includes multimedia and function keys. These may require pressing the `Fn` key simultaneously for their secondary functions.
- **Wrist Rest:** Utilize the integrated wrist rest for ergonomic support during long typing sessions. The keyboard's tilt feet can be adjusted for preferred angle.
- **Phone Holder:** Place your smartphone or small tablet in the integrated slot for convenient viewing.

Mouse Operation

- **DPI Adjustment:** Press the DPI button (usually located behind the scroll wheel) to cycle through DPI settings: 800, 1200, 1600, and 2400. Choose a setting that suits your precision needs.
- **Back/Forward Buttons:** Use the side buttons for quick navigation in web browsers or file explorers.
- **Automatic Backlight:** The mouse features an automatic 7-color backlight that cycles through colors.

Charging Instructions

Both the keyboard and mouse are equipped with rechargeable lithium batteries.

- **Keyboard Battery:** 500mAh. Battery life is approximately 15 days with backlight off, and 10 hours with backlight on.
- **Mouse Battery:** 300mAh.
- **Charging:** Connect the provided Type-C charging cable to the charging port on the device and a USB power source (e.g., computer USB port, USB wall adapter).
- **Charging Indicator:** Refer to the device's LED indicator for charging status. Typically, a light will indicate charging and turn off or change color when fully charged.
- **Power Saving:** The backlight brightness is adjustable and can be turned off to extend battery life. Devices may enter sleep mode after a period of inactivity.



Image: The OMOTON AZERTY Wireless Keyboard and Mouse connected via Type-C cables for recharging, illustrating their built-in rechargeable batteries and power-saving features.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution. Avoid excessive moisture.
- **Storage:** When not in use for extended periods, turn off the devices to conserve battery. Store them in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** Avoid fully discharging the batteries frequently. Recharge them when the low battery indicator appears.

Troubleshooting

Problem	Solution
Devices not connecting / No response	◦ Ensure both keyboard and mouse are powered on. ◦ Check if the 2.4GHz USB receiver is securely plugged into a working USB port. ◦ Recharge the keyboard and mouse to ensure sufficient battery. ◦ Try plugging the USB receiver into a different USB port. ◦ Restart your computer.
Keyboard backlight not working	◦ Press the backlight key to turn it on or adjust brightness. ◦ Ensure the keyboard has sufficient battery charge.
Mouse cursor erratic or unresponsive	◦ Clean the mouse sensor with a soft cloth. ◦ Ensure you are using the mouse on a suitable surface (not highly reflective or transparent). ◦ Recharge the mouse. ◦ Adjust the DPI setting using the DPI button.
Incorrect characters typed (AZERTY issue)	◦ Verify that your computer's operating system is configured to the AZERTY keyboard layout. Refer to the "Configure AZERTY Layout" step in the Setup section.

SPECIFICATIONS

Feature	Detail
Brand	OMOTON
Model	B0G52FLMD5
Connectivity Technology	2.4 GHz Wireless
Keyboard Layout	AZERTY
Keyboard Backlight	7 Colour RGB, Dimmable
Mouse Backlight	7 Colour Automatic Cycle
Keyboard Battery	500mAh Lithium (Rechargeable)
Mouse Battery	300mAh Lithium (Rechargeable)
Mouse DPI Settings	800/1200/1600/2400
Compatible Operating Systems	Windows 11/10/8/7/Vista/XP, Linux
Operating Range	Up to 10m

Feature	Detail
Color	Sidereal Grey

Warranty and Support

OMOTON products come with a standard warranty. For detailed warranty information, technical support, or customer service inquiries, please refer to the official OMOTON website or contact their customer support directly. Please have your product model number (B0G52FLMD5) ready when contacting support.
OMOTON Official Website: www.omoton.com (This is a placeholder, please verify the actual support URL)

© 2026 OMOTON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G52FLMD5

More documents and user manuals: **https://manuals.plus/**