Marsail MSESD75B-US

Marsail Electric Standing Desk Instruction Manual

Model: MSESD75B-US

Introduction

Thank you for choosing the Marsail Electric Standing Desk. This desk features a one-piece desktop, adjustable height, and four memory presets, designed to enhance productivity and comfort in your office or gaming setup. This manual provides essential information for safe assembly, operation, and maintenance of your new standing desk.

Image: The Marsail Electric Standing Desk, showcasing its spacious black desktop and sturdy black legs, set up in a modern office environment with dual monitors and a laptop.

Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Always assemble the desk on a stable, level surface.
- Do not exceed the maximum weight limit of**176 lbs (80 kg)**.
- Ensure the desk is properly anchored to the floor if required by local regulations, to prevent tipping.
- Always follow the included assembly instructions carefully to avoid injury.
- Keep children and pets away from the desk during operation to prevent accidents.
- Ensure there are no obstructions in the desk's path during height adjustment.

Package Contents

Your Marsail Electric Standing Desk is shipped in two separate packages: one for the tabletop and one for the frame. These packages may arrive on different days. Please verify all components are present before beginning assembly.

Image: Two brown cardboard boxes, indicating that the desk components are shipped in separate packages.

Setup and Assembly

The Marsail Electric Standing Desk is designed for hassle-free installation with a one-piece desktop. Detailed instructions and labeled hardware are included in the packaging. It is recommended that **two people** assemble the desk.

1. **Unpack Components:** Carefully remove all parts from the two packages and lay them out on a clean, soft surface to prevent scratches. Verify all parts against the included parts list.
2. **Assemble Frame:** Follow the step-by-step instructions in the assembly manual to connect the desk legs, crossbar, and motor components. Ensure all screws are tightened securely.
3. **Attach Desktop:** Carefully place the one-piece desktop onto the assembled frame. Align the pre-drilled holes and secure the desktop using the provided screws.
4. **Install Control Panel:** Mount the control panel to the underside of the desktop in the designated location. Connect all necessary cables to the motor and control unit as per the manual.
5. **Cable Management:** Use the included cable ties or management accessories to organize power cords and other cables for a tidy workspace.
6. **Initial Power-Up:** Plug the desk into a grounded power outlet. Perform an initial reset if instructed by the assembly manual (usually by holding a specific button until the desk reaches its lowest point and slightly rises).

For detailed visual guidance, refer to the assembly instructions included in your package. U.S.-based product support is available for any assembly questions.

Image: Illustration highlighting the seamless one-piece desktop design of the Marsail desk compared to desks with visible joints.

Operating Instructions

Your Marsail Electric Standing Desk offers smooth and quiet height adjustment with convenient memory presets.

Height Adjustment

- **Adjusting Up/Down:** Use the **Up** and **Down** arrow buttons on the control panel to raise or lower the desk to your desired height. The desk operates quietly at approximately 50 dB.
- The desk's height can be adjusted from a minimum of **28.3 inches (71.9 cm)** to a maximum of **46.5 inches (118.1 cm)**.

Image: Demonstrates the wide height adjustment range of the Marsail standing desk, showing a user comfortably seated at the lowest setting and another user standing at the highest setting.

Memory Presets

The control panel features **four memory presets** to save your preferred sitting and standing heights.

1. **Setting a Preset:** Adjust the desk to your desired height using the Up/Down buttons. Press the **"M"** button, then press one of the numbered preset buttons (**1, 2, 3, or 4**) within 3 seconds. The display will show "S-" followed by the number, indicating the height is saved.
2. **Recalling a Preset:** Press the corresponding numbered preset button (**1, 2, 3, or 4**). The desk will automatically move to the saved height.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Marsail Electric Standing Desk.

- **Cleaning the Tabletop:** Clean the tabletop with a damp cloth. For stubborn marks, use a mild, non-abrasive cleaner. Avoid harsh chemicals that may damage the laminated finish.
- **Cleaning the Frame:** Wipe the steel frame with a dry cloth to remove dust. If necessary, a slightly damp cloth can be used, followed by immediate drying.
- **Regular Checks:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary.
- **Cable Management:** Ensure cables are not pinched or tangled, especially during height adjustments.

Troubleshooting

If you encounter issues with your Marsail Electric Standing Desk, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Desk does not move or respond.	Power cable disconnected; overload; motor error.	Check if the power cable is securely plugged into the wall outlet and the desk control box. Remove some weight from the desk if it exceeds 176 lbs. Perform a reset: Unplug the desk for 10 seconds, then plug it back in. Hold the Down button until the desk reaches its lowest point and slightly rises.
Uneven height adjustment.	Loose connections; uneven weight distribution.	Check all frame connections and tighten any loose screws. Ensure weight is evenly distributed on the desktop. Perform a reset as described above.
Error code displayed.	Specific motor or sensor issue.	Refer to the detailed troubleshooting section in your assembly manual for specific error code meanings and solutions. If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	Marsail
Model Number	MSESD75B-US
Desktop Dimensions (L x W)	55.12" x 29.53" (140 cm x 75 cm)
Height Adjustment Range	28.3" - 46.5" (71.9 cm - 118.1 cm)
Maximum Weight Capacity	176 lbs (80 kg)
Desktop Material	Wood (Laminated Finish)
Frame Material	Carbon Steel / Alloy Steel
Color	Black

Feature	Detail
Motor Lift Cycles Tested	50,000+
Noise Level	< 50 dB
Memory Presets	4
Assembly Required	Yes (Recommended 2 people)
Included Components	Headphone Hook

Image: Detailed product dimensions of the desk, including width, depth, and height range.

Image: An overhead view illustrating the deeper desktop, providing an extra 6 inches of space for enhanced productivity.

Image: Visual representation of the desk's 176 lbs weight capacity and the motor's durability, tested for over 50,000 lift cycles.

Warranty

The Marsail Electric Standing Desk comes with a**Limited Warranty**. This warranty covers manufacturing defects in materials and workmanship under normal use. The specific terms and duration of the warranty are detailed in the warranty card included with your product. Please retain your proof of purchase for warranty claims.
For detailed information regarding your limited warranty, including coverage and exclusions, please refer to the documentation provided in your product packaging or contact Marsail customer support.

Support

For any questions regarding assembly, product selection, troubleshooting, or warranty claims, please contact Marsail customer support. Our U.S.-based support team is ready to assist you.
Please visit the official Marsail website for contact information and additional resources:Marsail Official Store

© 2023 Marsail. All rights reserved.
Marsail is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question