ROCKPOINT HX2025-58

ROCKPOINT 58-inch Fireplace TV Stand with Sliding Barn Doors and Electric Fireplace

Model: HX2025-58

Introduction

Thank you for purchasing the ROCKPOINT 58-inch Fireplace TV Stand. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read these instructions thoroughly before beginning assembly or use, and retain them for future reference.

Important Safety Information

- Keep away from naked flame or direct heat sources.
- Ensure all components are securely fastened before use.
- Do not overload the TV stand; adhere to the maximum weight capacity of 150 lbs.
- Place the unit on a flat, stable surface to prevent tipping.
- Keep children and pets away from the electric fireplace when in operation.
- Do not block the air vents of the electric fireplace.

Package Contents

Your ROCKPOINT Fireplace TV Stand is shipped in two separate boxes. Please ensure you have received both packages and all parts are present before beginning assembly.

- TV Stand Cabinet components
- 23-inch Electric Fireplace Heater
- Hardware kit (screws, dowels, bolts, etc.)
- Instruction Manual
- Remote control for electric fireplace



Image: Overview of the TV stand dimensions (58" W x 16" D x 32" H) and a warning that the item ships in two packages which may arrive separately. It also indicates a weight capacity of 150 lbs.

Setup and Assembly

Assembly is required for this product. It is recommended to have two people for assembly. Please follow the steps below carefully.

1. Attach legs with screws. Tighten using the provided tool.
2. Insert dowels into pre-drilled holes.
3. Align panels and secure with bolts.
4. Assemble the electric fireplace unit according to the manufacturer's guidelines provided with the fireplace.
5. Install the fireplace into the designated space on the TV stand.
6. Attach the sliding barn doors to the tracks.
7. Organize and store items in the designated compartments and shelves.



Image: Detailed view of the 23-inch electric fireplace unit, highlighting its touch screen controls, remote, 3D flame effects, 0.5H-9H timer, and temperature range of 64°F-84°F.



Image: Illustration of the unique slide rail mechanism for the barn doors and the adjustable shelves inside the storage sections of the TV stand.

Operating Instructions

Electric Fireplace Operation

The 23-inch electric fireplace can be operated independently for flame ambiance without heat, or with heating functionality. Control is available via the unit's touch screen panel or the included remote control.

- **Power:** Turn the fireplace ON/OFF.
- **Flame Brightness:** Adjust the intensity of the 3D flame effects (3 levels).
- **Temperature Control:** Set the desired room temperature between 60°F and 84°F. The heater can warm areas up to 375 sq ft.
- **Timer Function:** Set an automatic shut-off timer from 0.5 hours to 9 hours for energy efficiency.
- **Memory Function:** The fireplace retains your last settings (e.g., power-on state to standby state).



Image: The ROCKPOINT Fireplace TV Stand in a living room setting, demonstrating the electric fireplace in operation with heat radiating outwards, and the remote control for easy adjustments.

Sliding Barn Doors and Storage

The TV stand features two sliding barn doors that move smoothly on tracks, providing access to hidden storage compartments. Two open shelves are also available for media devices or decor.

- Slide the barn doors left or right to reveal or conceal the storage areas.
- Utilize the two hidden compartments for daily essentials.
- Use the two open shelves for DVDs, game consoles, or other media equipment.
- Rear pre-punched cord holes help manage cables and keep electronics neat.



Image: Close-up details of the TV stand, showcasing its stable and solid base, large cable management holes, comfortable handles on the barn doors, and the overall large storage capacity.

Maintenance

To ensure the longevity and appearance of your ROCKPOINT Fireplace TV Stand, follow these simple maintenance guidelines:

- For general cleaning, wipe surfaces with a damp cloth.
- Immediately follow with a dry cloth to prevent moisture damage.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- Regularly check all screws and bolts to ensure they remain tight. Retighten if necessary.
- Keep the electric fireplace vents clear of dust and debris to maintain proper airflow and prevent overheating.

Troubleshooting

This section addresses common issues you might encounter with your Fireplace TV Stand. For problems not listed here, please contact customer support.

Problem	Possible Cause	Solution
Electric fireplace does not turn on.	Power cord not fully plugged in; power outlet not functioning; main power switch off.	Ensure power cord is securely plugged into a working outlet. Check the main power switch on the fireplace unit.
No heat from fireplace, but flames are visible.	Heater function is turned off; temperature setting is too low.	Activate the heater function using the remote or control panel. Increase the temperature setting.
Sliding barn doors are stiff or do not move smoothly.	Tracks are obstructed; doors are not properly aligned on the tracks.	Clear any debris from the tracks. Re-align the doors on the tracks as per assembly instructions.
Unit feels unstable.	Screws or bolts are loose; unit is on an uneven surface.	Check and tighten all assembly hardware. Move the unit to a flat, level surface.

Specifications

Feature	Detail
Brand	ROCKPOINT
Model Number	HX2025-58
Style	Highboy Sliding Barn Doors Fireplace TV Stand
Color	White
Overall Dimensions (L x W x H)	58 x 16 x 32 inches
Item Weight	109.5 Pounds
Material Type	Engineered Wood
Number of Shelves	6 (including open and hidden)
Electric Fireplace Size	23 Inch
Heat Coverage	Up to 375 sq ft
Temperature Options	60°F-84°F (14 options)
Timer Settings	0.5H-9H (11 settings)
Maximum TV Size Supported	Up to 65 inches
Weight Capacity	150 lbs

Product Videos

ROCKPOINT 58" Fireplace TV Stand Farmhouse Sliding Barn Door

Your browser does not support the video tag.

Video: An official product video from ROCKPOINT showcasing the 58-inch Fireplace TV Stand with its farmhouse sliding barn doors and overall design. This video demonstrates the product's features and aesthetic.

Warranty and Support

Specific warranty details are not provided in the product information. For any questions, concerns, or to report missing/damaged parts, please contact ROCKPOINT customer support through the retailer where you purchased the product. Refer to your purchase receipt for contact information.

© 2026 ROCKPOINT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question