Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SoBuy FSR209-WN

SoBuy FSR209-WN Narrow Shoe Rack Instruction Manual

Model: FSR209-WN

1. Product Overview

The SoBuy FSR209-WN is a narrow shoe rack designed for entryways and small spaces. It features a combination of enclosed tilting compartments and open shelves, providing versatile storage for various footwear and accessories. Its slim design, measuring only 19 cm deep, makes it suitable for tight areas.



Image 1.1: The SoBuy FSR209-WN shoe rack installed in an entryway, showcasing its design and storage capabilities.

The unit includes four tilting compartments with eight inner shelves, allowing for organized storage of shoes. The height of these compartments can be adjusted by removing shelves to accommodate taller footwear. An open shelving section provides additional space for frequently used items, bags, or decorative elements. Constructed from E1 class eco-friendly MDF and carbonized bamboo, the shoe rack is designed for durability and stability.

2. Safety Information

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Anti-Tipping Device:** For safety, it is crucial to fix the shoe rack to the wall using the provided anti-tipping accessories. This prevents the unit from tipping over, especially in households with children or pets.
- **Weight Distribution:** Avoid placing heavy objects on the upper shelves or the top plate of the unit. Distribute weight evenly across all compartments and shelves.
- **Stable Placement:** Ensure the furniture is placed on a stable, level surface to prevent wobbling or instability.

- **Assembly:** Assemble the product strictly according to the instructions. Do not modify the product or use parts not supplied by the manufacturer.



Image 2.1: Detail of the sturdy metal legs and base, highlighting the importance of stable placement and anti-tipping device installation.

3. Setup and Assembly

The SoBuy FSR209-WN shoe rack is delivered flat-packed and requires assembly. All necessary hardware and detailed assembly instructions are included in the package. Please follow the step-by-step guide provided with your product for proper installation.

1. **Unpack Components:** Carefully unpack all parts and hardware. Verify that all components listed in the assembly instructions are present and undamaged.
2. **Prepare Workspace:** Choose a clean, flat, and spacious area for assembly. Lay down a soft cloth or cardboard to protect the furniture parts and your floor.
3. **Follow Instructions:** Refer to the included assembly manual for detailed, illustrated steps. Pay close attention to the order of assembly and the correct orientation of parts.

4. **Secure Anti-Tipping Device:** Once assembled, securely attach the anti-tipping device to the wall as instructed. This is a critical safety step.

Note: Assembly typically requires basic household tools (e.g., screwdriver, hammer), which are usually not included.

4. Operating Instructions

The SoBuy FSR209-WN shoe rack offers efficient storage through its tilting compartments and open shelves.

4.1 Tilting Shoe Compartments

- **Opening:** Gently pull the handle of each compartment to tilt it open.
- **Shoe Placement:** Each tilting compartment contains two inner shelves. Place shoes with the toes facing inwards.
- **Adjusting Shelf Height:** The inner shelves are removable. For taller shoes like boots or high heels, remove one or both inner shelves to create more vertical space.
- **Closing:** Push the compartment back until it clicks securely into place.



Image 4.1: The shoe rack with its tilting compartments open, demonstrating how shoes are stored.



Image 4.2: A detailed view of the tilting mechanism and inner shelves within a compartment.

4.2 Open Shelving Section

- **Storage:** Use the open shelves for items requiring quick access, such as frequently worn shoes, bags, hats, or decorative items.
- **Organization:** Utilize storage boxes or baskets on these shelves to maintain tidiness.



Image 4.3: The open shelving area, suitable for various items including storage boxes.



Image 4.4: The open side shelf providing space for taller items like boots.

5. Maintenance and Care

Proper care will ensure the longevity and appearance of your SoBuy FSR209-WN shoe rack.

- **Cleaning:** The surface is scratch-resistant and easy to clean. Simply wipe with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust the unit with a soft, dry cloth to prevent dust buildup.
- **Spills:** Wipe up any spills immediately to prevent staining or damage to the wood.
- **Inspection:** Periodically check all screws and fittings to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.

6. Troubleshooting

If you encounter any issues with your shoe rack, refer to the following common solutions:

Problem	Possible Cause	Solution
Unit feels unstable or wobbly.	Anti-tipping device not installed or improperly secured. Screws or fittings are loose. Uneven floor surface.	Ensure the anti-tipping device is correctly installed and anchored to a solid wall. Check and tighten all assembly screws and fittings. Move the unit to a level surface or use shims under the legs to stabilize.
Tilting compartments do not close smoothly.	Shoes are obstructing the mechanism. Mechanism is dirty or stiff.	Rearrange shoes to ensure they do not interfere with the closing mechanism. Clean the mechanism area. If stiff, apply a small amount of silicone spray (avoiding contact with wood surfaces).
Scratches or marks on the surface.	Impact from sharp objects. Abrasive cleaning.	Handle with care. Use only soft cloths and mild cleaners as recommended in the maintenance section.

7. Specifications

Key specifications for the SoBuy FSR209-WN shoe rack:



Image 7.1: Dimensional drawing of the SoBuy FSR209-WN shoe rack, with measurements in centimeters.

Feature	Detail
Model Number	FSR209-WN
Brand	SoBuy
Color	White + Wood

Feature	Detail
Material	E1 class eco-friendly MDF, Carbonized Bamboo
Product Dimensions (D x W x H)	19 cm x 90 cm x 129 cm (approx. 7.48"D x 35.43"W x 50.98"H)
Item Weight	24.2 Kilograms
Weight Capacity (Maximum)	38 Kilograms
Number of Levels	4 (tilting compartments) + open shelves
Assembly Required	Yes
Mounting Type	Floor Mount (with wall-fixing anti-tipping device)

8. Warranty and Support

For specific warranty information regarding your SoBuy FSR209-WN shoe rack, please refer to the documentation included with your purchase or contact SoBuy customer service directly. Warranty terms typically cover manufacturing defects and material flaws for a specified period from the date of purchase.

If you require assistance with assembly, have questions about product functionality, or need to report a missing/damaged part, please contact SoBuy customer support. Have your model number (FSR209-WN) and proof of purchase ready when contacting support.

Contact Information: Please refer to the manufacturer's official website or the packaging for the most current customer service contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G5YSDVFQ

More documents and user manuals: **https://manuals.plus/**