qrcamule goodBRD04873

Instruction Manual

QRCAMULE TRANE RELAY OUTPUT BOARD MODULE

Model: goodBRD04873

1. Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of the qrcamule Trane Relay Output Board Module. This module is designed to replace specific Trane relay output boards, ensuring proper functionality within compatible HVAC systems. Please read this manual thoroughly before attempting any installation or service.

2. Safety Information

WARNING: Electrical Shock Hazard

- Always disconnect power to the HVAC system at the main breaker before attempting any installation, removal, or servicing of the relay output board.
- Installation and servicing should only be performed by a qualified and licensed HVAC technician.
- Wear appropriate personal protective equipment (PPE), including safety glasses and insulated gloves.
- Refer to the HVAC system's main service manual for additional safety guidelines and wiring diagrams.
- Incorrect installation or wiring can lead to equipment damage, fire, serious personal injury, or death.

3. Package Contents

Verify that all items are present and undamaged upon opening the package.

- 1 x qrcamule Trane Relay Output Board Module (BRD02942 X13650728-05 BRD04873)



Image 1: The qrcamule Trane Relay Output Board Module, showing its various connectors and components.

4. Setup and Installation

This section outlines the general procedure for replacing an existing relay output board. Always consult the specific wiring diagrams and service instructions for your Trane HVAC unit.

1. **Preparation:** Ensure the HVAC system is completely powered off at the main electrical panel. Confirm power is off using a voltage tester. Locate the existing relay output board within the HVAC unit's control panel.
2. **Documentation:** Before disconnecting any wires, take clear photographs of the existing wiring connections. Label each wire with its corresponding terminal on the old board to ensure correct re-connection.
3. **Removal of Old Board:** Carefully disconnect all wiring from the old board. Remove any mounting screws or clips securing the old board in place. Gently remove the old board from the unit.
4. **Installation of New Board:** Position the new qrcamule relay output board in the same location as the old board. Secure it using the original mounting hardware.
5. **Wiring:** Reconnect all wires to the new board according to your documented connections and the HVAC system's wiring diagram. Ensure all connections are secure and properly seated. Double-check all wiring for correctness before proceeding.
6. **Verification:** Once all wiring is complete and secure, restore power to the HVAC system at the main electrical panel. Observe the system's operation to ensure the new board functions correctly and the HVAC unit operates as expected.

5. Operating Instructions

The qrcamule Trane Relay Output Board Module functions as a critical component within the Trane HVAC system, controlling various outputs based on system demands. Its operation is automatic and integrated with the main control system of the HVAC unit. No direct user interaction is required for its operation.
The board receives low-voltage control signals from the main control unit and, in response, activates or deactivates connected higher-voltage components such as fans, compressors, heating elements, or other relays. Proper functioning of this board is essential for the overall operation of the HVAC system.

6. Maintenance

The relay output board is designed for long-term, maintenance-free operation under normal conditions. However, periodic inspection during routine HVAC system maintenance is recommended.

- **Visual Inspection:** During annual HVAC servicing, visually inspect the board and its connections for any signs of wear, corrosion, discoloration, or loose wiring.
- **Cleaning:** Keep the area around the board clean and free from excessive dust and debris. A soft brush or compressed air can be used to gently remove dust, ensuring proper heat dissipation.
- **Connection Check:** Ensure all wire connections remain tight and secure.

Do not attempt to repair the board yourself. If damage is observed, replacement by a qualified technician is recommended.

7. Troubleshooting

If your HVAC system experiences issues after the installation of this module, consider the following troubleshooting steps. Always ensure power is disconnected before inspecting the board or wiring.

- **System Not Responding:**
  - Verify that all wiring connections to the board are correct and secure.
  - Ensure the board is receiving proper power from the HVAC system's transformer.
  - Consult the main HVAC system's diagnostic codes or indicator lights for specific error messages.
- **Intermittent Operation:**
  - Check for any loose or corroded wire connections.
  - Inspect the board for any visible damage, such as burnt components or cracked solder joints.
- **Specific Component Failure (e.g., fan not turning on):**
  - If a specific component controlled by the board is not activating, test the component directly if possible to rule out its failure.
  - If the component is functional, the issue may lie with the corresponding relay on the board or the signal from the main control unit.

For complex issues or if troubleshooting steps do not resolve the problem, professional diagnosis and repair by a qualified HVAC technician are strongly recommended.

8. Specifications

Manufacturer	qrcamule
Part Number	goodBRD04873
ASIN	B0G6CVDYWQ
Date First Available	December 11, 2025
Compatibility	Direct replacement for Trane BRD02942, X13650728-05, BRD04873

9. Warranty and Support

For detailed warranty information, terms, and conditions, please refer to the official qrcamule manufacturer's website or the documentation provided with your purchase. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical support, installation assistance, or to report a defective product, please contact qrcamule customer service through their official channels. Contact information can typically be found on the product packaging or the manufacturer's website.

© 2025 qrcamule. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question