Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

saschedross USB-C 5V AC DC Adapter

saschedross USB-C 5V AC DC Adapter Instruction Manual

For Geuuap YF-01 and Momcozy Sound Machines

1. Introduction

This manual provides instructions for the safe and effective use of your saschedross USB-C 5V AC DC Adapter. This power supply is designed to charge compatible electronic devices, specifically Geuuap YF-01 Sunrise White Noise Sound Speakers and various Momcozy sound machines and alarm clocks. Please read this manual thoroughly before use and retain it for future reference.

2. Product Overview

The saschedross USB-C 5V AC DC Adapter provides a reliable power source for your compatible devices. It includes a USB charger and a USB-C cable for convenient connection.

What's Included:

- 1 x USB Charger (AC DC Adapter)
- 1 x USB-C Charging Cable (3 Feet Length)



Image 1: The saschedross USB-C 5V AC DC Adapter and its accompanying USB-C charging cable. The adapter is black with a USB port, and the cable is black with a USB-A connector on one end and a USB-C connector on the other.

3. Setup

Follow these steps to set up your AC DC adapter:

1. **Unpack:** Carefully remove the USB-C AC DC adapter and cable from its packaging.
2. **Connect Cable:** Insert the USB-A end of the charging cable into the USB port on the AC DC adapter.
3. **Connect to Device:** Insert the USB-C end of the charging cable into the USB-C charging port of your compatible device (e.g., Geuuap YF-01, Momcozy sound machine).
4. **Plug into Power:** Plug the AC DC adapter into a standard 100V AC wall outlet.
5. **Verify Connection:** Ensure all connections are secure. Your device should indicate that it is charging.

4. Operating Instructions

Once properly set up, the adapter operates automatically to provide power to your device. No further user interaction is required for basic charging functionality.

- The adapter is designed for continuous use when connected to a power source and a compatible device.
- Always ensure the adapter is plugged into a functional wall outlet.
- Disconnect the adapter from the power outlet when not in use for extended periods.

5. Compatibility

This USB-C 5V AC DC Adapter is specifically designed and tested for compatibility with the following devices:

- **Geuuap YF-01** / **YF01** Sunrise Alarm Clocks Wake Up Light White Noise Sound Machine Speaker
- **Momcozy Model MCWDB03** / **M21FWDB03** Li-ion Battery Portable Sound White Noise Machine Routine Alarm Clock
- **Momcozy Model WN03** 1000mAh Portable Sound Machine White Noise
- **Momcozy Model WN005** / **WN01** / **MWN01** 3.7V Li-ion Battery Portable Sound White Noise Machine

Using this adapter with incompatible devices may result in improper charging or damage to the device or adapter.

6. Maintenance

Proper care and maintenance will ensure the longevity of your adapter:

- **Cleaning:** Disconnect the adapter from the power outlet and device before cleaning. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the adapter and cable in a cool, dry place away from direct sunlight and extreme temperatures. Avoid tightly winding the cable to prevent damage.
- **Handling:** Do not drop, disassemble, or attempt to repair the adapter yourself. Avoid exposing it to water or high humidity.
- **Cable Care:** Regularly inspect the cable for any signs of wear, fraying, or damage. Replace the cable if any damage is observed.

7. Troubleshooting

If you encounter issues with your adapter, refer to the following common solutions:

- **Device Not Charging:**
  - Ensure the adapter is securely plugged into a working wall outlet.
  - Verify that the USB-C cable is firmly connected to both the adapter and your device.
  - Check if the wall outlet is functional by plugging in another device.
  - Confirm that your device is listed under the "Compatibility" section.
  - Try using a different USB-C cable (if available) to rule out a faulty cable.
- **Adapter Feels Warm:**
  - It is normal for the adapter to feel slightly warm during operation. If it becomes excessively hot or emits a burning smell, immediately unplug it from the wall outlet and discontinue use.

If the problem persists after trying these steps, please contact customer support.

8. Specifications

Brand	saschedross
Connector Type	USB-C (Output), USB-A (Adapter Port)
Input Voltage	100 Volts (AC)
Output Voltage	5V DC (Standard for USB-C charging)
Power Source	Corded Electric
Cable Length	3 Feet
Color	Black
Manufacturer	Shenzhen Waweis Technology Co., Ltd

9. Warranty and Support

For any questions, technical assistance, or support regarding your saschedross USB-C 5V AC DC Adapter, please refer to the seller's contact information provided at the point of purchase. Specific warranty details may vary by retailer.

© 2023 saschedross. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G6RPCFZX

More documents and user manuals: **https://manuals.plus/**