Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OMOTON B0G7FDKMKS

OMOTON Foldable Wireless Bluetooth Keyboard and Mouse Combo User Manual

Model: B0G7FDKMKS

1. Introduction

Thank you for choosing the OMOTON Foldable Wireless Bluetooth Keyboard and Mouse Combo. This device is designed for portability and multi-device connectivity, offering a full-size typing experience and an ergonomic mouse for various operating systems. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

2. Product Overview

2.1 Package Contents

- OMOTON Foldable Keyboard
- OMOTON Wireless Mouse
- USB-C Charging Cable
- 2.4G USB Receiver (stored in the mouse)
- User Manual (this document)

2.2 Key Features

- **Tri-Fold Design:** Compact and portable for travel.
- **Multi-Device Connectivity:** Connects to up to 3 devices via 2.4G wireless and dual Bluetooth channels.
- **Universal Compatibility:** Supports macOS, Windows, iOS, and Android.
- **Rechargeable:** Both keyboard and mouse feature USB-C rechargeable batteries.
- **Silent Click Mouse:** Ergonomic design with adjustable DPI (800/1200/1600).
- **Full-Size Keyboard:** Includes a numeric keypad for enhanced productivity.



Image: The OMOTON foldable keyboard and mouse combo connected to a laptop, tablet, and smartphone, illustrating its multi-device 2.4G wireless and Bluetooth connectivity. The USB receiver is shown stored in the mouse.

3. Setup Instructions

3.1 Charging the Devices

Both the keyboard and mouse are equipped with rechargeable batteries. Use the provided USB-C cable to charge them.

1. Connect the USB-C end of the cable to the charging port on the keyboard or mouse.
2. Connect the USB-A end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The indicator light will show charging status (refer to device for specific light behavior). A full charge typically takes 2-3 hours.



Image: The OMOTON foldable keyboard and mouse being charged simultaneously via USB-C cables, highlighting the rechargeable feature and long standby time.

3.2 Connecting via 2.4G Wireless (Keyboard & Mouse)

This mode is ideal for devices without Bluetooth or for a quick, stable connection.

1. Locate the 2.4G USB receiver, which is stored in the compartment on the underside of the mouse.
2. Insert the USB receiver into an available USB port on your computer or device.
3. **For Keyboard:** Turn on the keyboard's power switch. Press the 2.4G wireless key (often indicated by a wireless icon or '6' on the keyboard). The indicator light will flash, then become solid when connected.
4. **For Mouse:** Turn on the mouse's power switch. Press the pairing button on the underside of the mouse to switch to 2.4G mode (red light). The mouse should connect automatically.



Image: The underside of the OMOTON mouse showing the pairing button, power switch, and the compartment for the 2.4G USB receiver, with instructions for 2.4G and Bluetooth connection modes.

3.3 Connecting via Bluetooth (Keyboard & Mouse)

The combo supports two Bluetooth channels (BT1 and BT2) for connecting to multiple devices.

1. **For Keyboard:**
    - Turn on the keyboard's power switch.
    - Press the BT1 or BT2 key for 1 second to select the desired Bluetooth channel.
    - Press and hold the selected BT1 or BT2 key for 3 seconds until the indicator light flashes rapidly, indicating pairing mode.
    - On your device (tablet, phone, computer), go to Bluetooth settings and select "Bluetooth Keyboard" from the list of available devices.
    - Once paired, the indicator light will turn off.
2. **For Mouse:**
    - Turn on the mouse's power switch.

- Short press the pairing button on the underside of the mouse to switch between Bluetooth channels (Blue = Channel 1, Green = Channel 2).
- Press and hold the pairing button for 3 seconds until the light flashes rapidly.
- On your device, go to Bluetooth settings and select "BT5.0 Mouse" from the list of available devices.
- Once paired, the light will become solid or turn off.

3.4 Switching Operating Systems

The keyboard is compatible with multiple operating systems. Switch to the correct system for optimal key functionality.

- For **macOS**: Press **FN + Q**
- For **Windows**: Press **FN + W**
- For **iOS**: Press **FN + E**
- For **Android**: Press **FN + R**



Image: Visual guide on the OMOTON keyboard showing the key combinations (FN+Q/W/E/R) to switch between macOS, Windows, iOS, and Android operating systems.

4. Operating Instructions

4.1 Keyboard Usage

- **Folding/Unfolding:** Gently unfold the keyboard to its full size for use. Fold it back for portability.
- **Numeric Keypad:** The integrated numeric keypad functions like a standard desktop keyboard for data entry.
- **Function Keys:** Use the FN key in combination with the F1-F12 keys for multimedia controls and other shortcuts, depending on your operating system.
- **Switching Devices:** To switch between connected devices (2.4G, BT1, or BT2), simply press the corresponding key on the keyboard.



Image: The OMOTON foldable keyboard and mouse displayed with their dimensions, showing the full-size layout when unfolded and its compact size when folded.

4.2 Mouse Usage

- **DPI Adjustment:** Press the DPI switch button (usually located near the scroll wheel) to cycle through DPI settings

(800/1200/1600) to adjust cursor sensitivity.

- **Silent Clicks:** The mouse features silent click buttons, reducing noise in quiet environments.
- **Ergonomic Design:** The contoured shape is designed for comfortable use during extended periods.
- **Side Buttons:** The mouse may include side buttons for forward/backward navigation in browsers or other functions depending on the OS.
- **Switching Devices:** Short press the pairing button on the underside of the mouse to cycle between connected Bluetooth channels (BT1, BT2) or 2.4G mode.



Image: A detailed diagram of the OMOTON ergonomic mouse, highlighting its silent click feature, adjustable DPI switch (800-1200-1600), scroll wheel, left/right buttons, Type-C charging port, and side buttons for volume/navigation.

Your browser does not support the video tag.

Video: An official product video demonstrating the OMOTON Foldable Keyboard and Mouse, showcasing its quick Bluetooth connection, multi-device switching, and overall functionality.

5. Maintenance

5.1 Cleaning

- Turn off the devices before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- Avoid using harsh chemicals, abrasive cleaners, or spraying liquids directly onto the devices.
- For keyboard crevices, use compressed air or a soft brush to remove dust and debris.

5.2 Battery Care

- Charge the devices regularly, even if not in frequent use, to maintain battery health.
- Avoid extreme temperatures, as they can affect battery life and performance.
- Do not attempt to replace the internal batteries yourself. Contact support if battery issues arise.

6. Troubleshooting

6.1 Keyboard/Mouse Not Connecting

- **Check Power:** Ensure both devices are turned on and fully charged.
- **Re-pair Bluetooth:** If using Bluetooth, delete the device from your device's Bluetooth list and re-pair it following the instructions in Section 3.3.
- **2.4G Receiver:** For 2.4G connection, ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
- **Switch Channels:** Ensure you have selected the correct channel (2.4G, BT1, or BT2) on both the keyboard and mouse.
- **Interference:** Move the devices closer to your computer/device and away from other wireless devices that might cause interference.

6.2 Keyboard Typing Incorrect Characters

- **Operating System Mode:** Ensure you have switched the keyboard to the correct operating system mode (FN+Q/W/E/R) as described in Section 3.4.
- **Keyboard Layout:** Check your device's operating system settings to ensure the keyboard layout is set to QWERTY (or your preferred layout).

6.3 Mouse Cursor Jumps or is Unresponsive

- **Surface:** Ensure you are using the mouse on a suitable, non-reflective surface.
- **DPI Setting:** Adjust the DPI setting to see if it improves responsiveness.
- **Battery:** Recharge the mouse. Low battery can affect performance.

7. Specifications

Brand	OMOTON
Model	B0G7FDKMKS
Color	Space Grey
Connectivity Technology	2.4G Wireless, Dual Bluetooth
Compatible Devices	iOS, Android, Windows, macOS (iPad, iPhone, Samsung Tablets, PC, Laptop, Computer)

Keyboard Layout	QWERTY
Keyboard Description	Foldable
Mouse DPI Settings	800/1200/1600
Battery Type	Lithium Ion (included)
Charging Port	USB-C

8. Warranty Information

The OMOTON Foldable Wireless Bluetooth Keyboard and Mouse Combo comes with a**12-month warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Please retain your proof of purchase for warranty claims.

9. Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact OMOTON customer support. You can typically find support contact information on the official OMOTON website or through your purchase platform.

For more information and product updates, visit theOMOTON Store on Amazon.

© 2023 OMOTON. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G7FDKMKS

More documents and user manuals: **https://manuals.plus/**