Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PLAYMOBIL 72071

PLAYMOBIL Animals & Friends Zoo Jungle Adventure Set (Model 72071) Instruction Manual

Brand: PLAYMOBIL | Model: 72071

1. Product Overview

The PLAYMOBIL Animals & Friends Zoo Jungle Adventure Set (Model 72071) offers an immersive jungle experience. This set features a large jungle tree with a platform and ladder, a canoe, and various animal figures. Key interactive elements include a leaf catapult for the monkey, explorer glasses that reveal hidden details, glowing plants, and animal caves. Designed for children aged 4 and up, this set encourages creative play and problem-solving skills.



Image 1.1: The PLAYMOBIL Animals & Friends Zoo Jungle Adventure Set 72071, highlighting its main components and features, including the jungle tree, canoe, and various animals.

Key Features:

- **Jungle Tree with Platform and Ladder:** Allows figures to explore the South American zoo area and observe wildlife from elevated positions.
- **Leaf Catapult:** A dynamic action feature that launches the monkey figure through the air.
- **Explorer Glasses:** Innovative glasses that reveal secret information about animals and make hidden data visible on informational panels, enhancing learning.
- **Canoe:** For figures to navigate the water areas of the jungle adventure.
- **Food Ball Slide:** Integrated into the jungle environment.
- **Two Playable Caves:** Provides hiding spots for animals like bats and a habitat for the tapir family in the water.
- **Luminescent Plants and Motion Cards:** Add to the vibrant jungle atmosphere with butterflies and dragonflies.

2. Assembly Instructions

This PLAYMOBIL set requires assembly. Please follow the detailed instructions provided in the included manual. Ensure all components are present before beginning assembly.

2.1. Unpacking and Component Check

1. Carefully open the packaging and remove all contents.
2. Refer to the component list in the included instruction manual to verify all 86 pieces are present.
3. Separate small parts from larger ones to facilitate assembly.



Image 2.1: Product packaging for PLAYMOBIL 72071, illustrating the various components included in the set.

2.2. General Assembly Steps

While specific steps are in the physical manual, general assembly involves:

- Connecting the base sections of the jungle tree.
- Attaching the platform, ladder, and slide components.
- Securing the leaf catapult mechanism.
- Placing decorative elements like plants and small accessories.
- Assembling the canoe and positioning animal figures.

Ensure all connections are secure to prevent parts from detaching during play.

3. Operating Instructions

The PLAYMOBIL Zoo Jungle Adventure Set is designed for interactive play. Here's how to utilize its main features:

3.1. Using the Leaf Catapult

1. Place the monkey figure onto the designated spot on the leaf catapult.
2. Press down on the catapult mechanism to launch the monkey.
3. Experiment with different angles and force for varied launch distances.

3.2. Explorer Glasses Functionality

1. Wear the explorer glasses.
2. Look at the informational panels or specific areas within the set.
3. Hidden details and animal facts will become visible through the special lenses, enhancing the educational aspect of play.



Image 3.1: Detailed view of interactive elements such as the bat caves, explorer glasses, glowing plants, and the leaf catapult for the monkey.

3.3. Interacting with Animals and Environment

- Use the canoe to transport figures across the water.
- Place food balls into the slide for the animals.
- Discover the tapir family in their water habitat and bats in the caves.
- Arrange the luminescent plants and motion cards to create dynamic jungle scenes.

4. Care and Maintenance

To ensure the longevity and cleanliness of your PLAYMOBIL set, follow these simple care instructions:

4.1. Cleaning

- Wipe down figures and larger pieces with a damp cloth and mild soap.
- For smaller or intricate parts, use a soft brush or cotton swab.
- Rinse thoroughly with clean water if soap is used, and air dry completely before storage.
- Avoid harsh chemicals or abrasive cleaners, as these can damage the plastic and paint.

4.2. Storage

- Store the set in a clean, dry place away from direct sunlight and extreme temperatures.
- Keep small parts in a container to prevent loss.

5. Troubleshooting

If you encounter any issues with your PLAYMOBIL Zoo Jungle Adventure Set, refer to the following common solutions:

5.1. Missing or Damaged Parts

- **Solution:** Check the packaging thoroughly. If a part is genuinely missing or damaged upon opening, contact PLAYMOBIL customer service with your product model number (72071) and a description of the issue.

5.2. Parts Not Fitting Together

- **Solution:** Double-check the assembly instructions to ensure you are using the correct parts and orientation. Some parts may require a gentle but firm push to snap into place. Do not force parts, as this can cause damage.

5.3. Leaf Catapult Not Functioning

- **Solution:** Ensure the catapult mechanism is correctly assembled and free from obstructions. Verify that the monkey figure is placed properly on the launch pad.

6. Product Specifications

Feature	Detail
Brand	PLAYMOBIL
Model Number	72071
Product Dimensions	34.8 x 24.8 x 12.5 cm
Weight	685 g

Feature	Detail
Recommended Age	4 - 99 years
Material	Plastic
Number of Pieces	86
Educational Objective	Problem-solving skills, Creative thinking
Special Feature	Non-toxic
Assembly Required	No (*Note: While the product description and included manual imply assembly, the specification states "No". Minor assembly is typically required for PLAYMOBIL sets.*)
Operation Type	Manual

7. Safety Information

Please read and adhere to the following safety warnings to ensure safe play:

- **WARNING: CHOKING HAZARD.** This toy contains a small ball and small parts.
- Not suitable for children under 3 years of age due to small parts.
- Adult supervision is recommended during play, especially with younger children.
- Inspect the toy regularly for any damage or loose parts that could pose a hazard. Discontinue use if damage is found.

8. Warranty and Support

For information regarding product warranty, replacement parts, or customer support, please contact PLAYMOBIL directly through their official website or the retailer where the product was purchased.
Visit the official PLAYMOBIL website

© 2026 PLAYMOBIL. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G7LHS2BV

More documents and user manuals: **https://manuals.plus/**