Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

URAO X109

URAO X109 10.1-inch Android 16 Tablet User Manual

1. Introduction

This manual provides essential information for setting up, operating, and maintaining your URAO X109 10.1-inch Android 16 Tablet. Please read this guide thoroughly to ensure proper use and to maximize your device's performance and longevity. Keep this manual for future reference.

2. Product Overview

2.1 Package Contents

- URAO X109 Android Tablet
- USB Type-C Charging Cable
- Power Adapter
- User Manual

2.2 Device Layout

Familiarize yourself with the physical components and controls of your URAO X109 tablet.



Figure 2.2.1: URAO X109 Tablet Ports and Buttons

This diagram illustrates the location of key features on your tablet. On the side, you will find the Power ON/OFF button, Volume Up/Down buttons, a Reset pinhole, the Micro SD card slot, the USB Type-C port for charging and data transfer, and a 3.5mm headset jack. The tablet also features dual speakers, a front camera, and a rear camera.



Figure 2.2.2: Front View of URAO X109 Tablet

The front view highlights the 10.1-inch HD IPS display, ideal for viewing content. The tablet features a slim bezel and a modern design.

3. Setup

3.1 Initial Power On

1. Press and hold the Power ON/OFF button located on the side of the tablet until the URAO logo appears on the screen.
2. Follow the on-screen prompts to select your language, region, and accept the terms and conditions.

3.2 Wi-Fi Connection

1. During the initial setup, select your desired Wi-Fi network from the list of available networks.

2. Enter the Wi-Fi password if prompted and tap 'Connect'.
3. To connect later, go to **Settings > Network & internet > Wi-Fi** and select your network.

3.3 Google Account Setup

A Google account is required to download apps from the Google Play Store and access Google services.

1. During setup, you will be prompted to sign in with an existing Google account or create a new one.
2. Enter your email and password, then follow the on-screen instructions.
3. If you skip this step, you can add an account later via **Settings > Accounts > Add account > Google**

3.4 Charging the Battery

Before first use, fully charge the tablet. Use the provided USB Type-C cable and power adapter.

1. Connect the USB Type-C cable to the tablet's Type-C port.
2. Plug the other end of the cable into the power adapter, then plug the adapter into a wall outlet.
3. The battery indicator on the screen will show charging status. A full charge typically takes about 1.5 hours.

4. Operating Instructions

4.1 Basic Navigation

- **Touch Gestures:** Tap to select, swipe to scroll, pinch to zoom.
- **Home Screen:** Access apps, widgets, and notifications.
- **Notification Panel:** Swipe down from the top of the screen to view notifications and quick settings.

4.2 App Management

- **Installing Apps:** Open the Google Play Store app, search for your desired app, and tap 'Install'.
- **Uninstalling Apps:** Press and hold an app icon on the home screen or app drawer, then drag it to 'Uninstall' or select 'App info' and choose 'Uninstall'.
- **Split Screen:** The tablet supports split-screen multitasking. Open a recent apps view, tap the app icon at the top of an app's card, and select 'Split screen'.

4.3 Camera Usage

The tablet features a 5MP front camera and an 8MP rear camera.

1. Open the Camera app.
2. Tap the camera switch icon to toggle between front and rear cameras.
3. Tap the shutter button to take a photo or start/stop video recording.



Figure 4.3.1: Tablet Camera Functionality

The tablet's dual cameras allow for capturing photos and videos. The 5MP front camera is suitable for video calls, while the 8MP rear camera captures general photos.

4.4 Face Unlock

The front camera supports facial recognition for unlocking the device.

1. Go to **Settings > Security & privacy > Face unlock**
2. Follow the on-screen instructions to register your facial data.
3. Once registered, you can unlock your tablet by looking at the front camera.



Figure 4.4.1: Face Unlock Feature

The tablet's face unlock feature provides a convenient and secure way to access your device using facial recognition.

5. Media Integration

5.1 Product Video Overview

Watch this video for a visual overview of the URAO Android Tablet 10 Inch.

Your browser does not support the video tag.

Video 5.1.1: URAO Android Tablet 10 Inch Overview

This video provides a detailed look at the URAO Android Tablet, showcasing its features and design. It covers aspects such as the display, performance, and overall user experience.

6. Maintenance

6.1 Cleaning the Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these can damage the device.
- Avoid getting moisture into openings.

6.2 Battery Care

- To prolong battery life, avoid exposing the tablet to extreme temperatures.
- Do not leave the tablet fully discharged for extended periods.
- Use only the provided charger or a certified compatible charger.

6.3 Storage

When storing the tablet for an extended period, ensure it is charged to about 50% and powered off. Store it in a cool, dry place away from direct sunlight.

7. Troubleshooting

7.1 Tablet Does Not Turn On

- Ensure the battery is charged. Connect the tablet to the charger and wait a few minutes before attempting to power on again.
- Press and hold the Power ON/OFF button for at least 10-15 seconds to perform a forced restart.

7.2 Screen Is Unresponsive

- Restart the tablet.
- If the issue persists, perform a factory reset (note: this will erase all data). Go to **Settings > System > Reset options > Erase all data (factory reset)**.

7.3 Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled in **Settings > Network & internet > Wi-Fi**.
- Restart your Wi-Fi router.
- Forget the network and reconnect by entering the password again.

7.4 Apps Crashing or Freezing

- Clear the app's cache: Go to **Settings > Apps > See all apps**, select the problematic app, then **Storage & cache > Clear cache**.
- Update the app via the Google Play Store.
- Uninstall and reinstall the app.

8. Specifications

Feature	Detail
Model Name	X109
Operating System	Android 16
Processor	2.0 GHz Octa-core (Allwinner)
RAM	30GB (6GB + 24GB Expansion)
Internal Storage (ROM)	128GB
Expandable Storage	Up to 1TB via MicroSD card (not included)
Screen Size	10.1 inches
Display Type	HD IPS Touchscreen
Display Resolution	1280 x 800 pixels
Rear Camera	8MP
Front Camera	5MP
Battery Capacity	6000mAh
Battery Life (Average)	Up to 8 hours (mixed use)
Charging	USB Type-C, Fast Charging (1.5 hours for full charge)
Wi-Fi	Wi-Fi 6 (802.11ax), Dual-band (2.4G+5G)

Feature	Detail
Bluetooth	Bluetooth 5.4
Dimensions (L x W x Thickness)	9.84" x 6.1" x 0.4" (approx. 8mm thickness)
Weight	540g
GPS	Not included
UPC	768807679743

9. Warranty and Support

9.1 Manufacturer's Warranty

The URAO X109 Tablet comes with a**2-Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

9.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your URAO X109 Tablet, please contact URAO customer support through the following channels:

- **Online Support:** Visit the official URAO website for FAQs and support resources.
- **Email Support:** Refer to your product packaging or the official URAO website for the customer service email address.
- **Amazon Seller Page:** You can also reach out to the seller, URAO e-Tech, directly through your Amazon order history for assistance.

Please have your product model (X109) and proof of purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G8D3PH1Z

More documents and user manuals: **https://manuals.plus/**