Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Mattel JGB77-986C

Mattel Jurassic World Attack Pack Dinosaur Figures (JGB77-986C) Instruction Manual

Model: JGB77-986C | Brand: Mattel

1. Introduction and Overview

Welcome to the world of Jurassic! This instruction manual provides essential information for the Mattel Jurassic World Attack Pack Dinosaur Figures, model JGB77-986C. This set includes six action figures inspired by the dinosaurs from the Jurassic World series, known for their hunting and attacking behaviors. The figures feature thrilling action movements and are compatible with the free Jurassic World Play app for an enhanced interactive experience.

Included Figures:

- 1 x Dilophosaurus (JKL67)
- 2 x Dimorphodon (JKL68)
- 2 x Compsognathus (JKL69)
- 1 x Nanotyrannus (JKL70)

Recommended Age: 4 years and up



Image 1.1: The complete set of six Jurassic World Attack Pack dinosaur figures.

2. Setup

The Mattel Jurassic World Attack Pack Dinosaur Figures are ready for play directly out of the box. No assembly is required.

1. Carefully remove all figures and packaging materials from the box.
2. Inspect each figure to ensure all parts are intact and there is no damage.
3. Dispose of packaging materials responsibly.

3. Operating Instructions

Each dinosaur figure features unique action movements designed for interactive play. These figures do not require batteries.

3.1 Activating Figure Actions

- **Dimorphodon:** Press the button on its back to make its wings flap, simulating flight and attack.
- **Compsognathus:** Press the button on its back to activate a head-butting attack.
- **Dilophosaurus:** Press the button on its back to initiate a biting attack.
- **Nanotyrannus:** Move its tail to activate a biting attack.



Image 3.1: Demonstrating the Dimorphodon's wing-flapping action and Compsognathus's head attack.



Image 3.2: Demonstrating the Dilophosaurus's biting attack and Nanotyrannus's tail-activated biting action.

3.2 Jurassic World Play App Integration

Enhance your play experience by connecting your figures to the free Jurassic World Play app.

1. Download the official "Jurassic World Play" app from your device's app store.
2. Locate the unique tracking code (DNA code) on the foot of each dinosaur figure.
3. Use the app's scan feature to scan the tracking code. This will unlock the corresponding dinosaur within the app, allowing for digital collection and interactive features.



Image 3.3: Scanning the DNA code on a dinosaur figure's foot to integrate with the Jurassic World Play app.

4. Maintenance

Proper care will ensure the longevity of your dinosaur figures.

- **Cleaning:** To clean the figures, wipe them gently with a soft, damp cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the figures in water, as this may damage the paint or plastic.
- **Storage:** Store figures in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation or discoloration.

5. Troubleshooting

If you encounter any issues with your figures, please refer to the following common solutions:

- **Action Feature Not Working:** Ensure that the activation button or tail mechanism is not obstructed and is being

fully pressed or moved. Check for any visible damage to the mechanism.

- **App Not Recognizing Tracking Code:** Ensure the tracking code on the figure's foot is clean and free from debris. Scan the code in a well-lit area. Make sure your Jurassic World Play app is updated to the latest version.

6. Specifications

Feature	Detail
Product Model Number	JGB77-986C
Quantity	6 figures
Battery Use	No
Main Material	Plastic
Target Gender	Unisex
Manufacturer Recommended Age	4 years and up
Package Dimensions	36 x 21.5 x 19 cm
Package Weight	900 g
Country of Origin	Vietnam



Image 6.1: Dimorphodon (approx. 13.5cm x 5.3cm) and Compsognathus (approx. 17.9cm x 7.9cm) figures.



Image 6.2: Dilophosaurus (approx. 19cm x 8cm) and Nanotyrannus (approx. 18cm x 5.9cm) figures.

7. Warranty and Support

Mattel products are manufactured to high-quality standards. For any questions, concerns, or support regarding your Jurassic World Attack Pack Dinosaur Figures, please contact Mattel customer service. Specific warranty details may vary by region; please refer to the packaging or Mattel's official website for the most current information.

Online Support: Visit the official Mattel website for product information and support resources.

Contact Information: Refer to the product packaging for regional customer service contact details.

© Universal City Studios LLC and Amblin Entertainment, Inc. All Rights Reserved.
Mattel and associated trademarks and trade dress are owned by Mattel. ® and ™ designate U.S. trademarks of Mattel, except as noted.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GBSYS595

More documents and user manuals: **https://manuals.plus/**