Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Maraiss X90

Maraiss Electric Spin Scrubber (Model X90) - Instruction Manual

Your Partner in Effortless Cleaning

Introduction

Thank you for choosing the Maraiss Electric Spin Scrubber. This cordless cleaning tool is designed to simplify your cleaning tasks with its powerful motor, adjustable speeds, and versatile brush heads. Please read this manual thoroughly before use to ensure safe and optimal operation of your device.

Product Components

The Maraiss Electric Spin Scrubber package includes the following items:

- Main Scrubber Unit (Handle and Host)
- Extendable Handle (Stainless Steel)
- 10 Replaceable Brush Heads (various types for different surfaces)
- USB-C Charging Cable
- Instruction Manual



Figure 1: All included components of the Maraiss Electric Spin Scrubber.

Setup

1. Assembly

1. **Attach the Extendable Handle:** Align the main scrubber unit with the extendable handle. Push and twist clockwise until it clicks securely into place.
2. **Adjust Handle Length:** The handle features a push-button extension mechanism. Press the button and slide the handle to your desired length for comfortable reach.
3. **Attach a Brush Head:** Select the appropriate brush head for your cleaning task. Align the brush head with the rotating base of the scrubber unit and press firmly until it snaps into place.



Figure 2: The scrubber unit with the extendable handle attached, demonstrating adjustable length.

2. Charging the Battery

Before first use, fully charge the scrubber. The device is equipped with a 2000mAh high-capacity battery.

- Locate the USB-C charging port on the main scrubber unit.
- Open the rubber sealing plug to expose the port.
- Connect the provided USB-C charging cable to the port and plug the other end into a compatible USB power adapter (not included).
- The LED display will indicate the charging status. A full charge typically takes approximately 2 hours and provides up to 90 minutes of continuous runtime.
- Ensure the sealing plug is completely closed after charging to maintain IPX7 waterproof rating.



Figure 3: Charging the scrubber unit using the USB-C cable.

Operating Instructions

1. Power On/Off and Speed Settings

- **Power On:** Press the power button once to turn on the scrubber. It will start at the lowest speed (300 RPM).
- **Change Speed:** Press the power button again to cycle through the speeds: 300 RPM (Speed 1), 400 RPM (Speed 2), and 500 RPM (Speed 3).
- **Power Off:** Press the power button a fourth time to turn off the device.
- The LED display will show the current speed setting and remaining battery percentage.



Figure 4: The scrubber unit displaying its 3-speed power settings (300/400/500 RPM).

2. Using Replaceable Brush Heads

The Maraiss Electric Spin Scrubber comes with 10 different brush heads designed for various cleaning tasks:

- **Large Flat Brush:** Ideal for large flat surfaces like floors, walls, and shower doors.
- **Small Flat Brush:** Suitable for smaller flat areas, sinks, and countertops.
- **Corner Brush:** Designed to reach into tight corners, grout lines, and curved surfaces.
- **Scouring Pads:** For tough stains, soap scum, and mildew on durable surfaces.
- **Sponge Pads:** Gentle cleaning for delicate surfaces, glass, and polishing.
- **Wool-like Pads:** For buffing and polishing surfaces, such as mirrors or car exteriors.



Figure 5: Examples of the 10-in-1 replaceable brush heads and their applications.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the electric spin scrubber in use.

Your browser does not support the video tag.

Video 2: Official product video showcasing the Maraiss Electric Spin Scrubber's features.

Maintenance

1. Cleaning Brush Heads

After each use, remove the brush head from the scrubber unit. Rinse the brush head thoroughly under running water to remove any dirt, soap residue, or cleaning agents. For stubborn grime, a mild soap solution can be used. Allow brush heads to air dry completely before storing.

2. Cleaning the Scrubber Unit

Wipe the main scrubber unit and extendable handle with a damp cloth. Do not submerge the main unit in water, even though it is IPX7 waterproof, to prevent potential damage to internal components. Ensure the charging port's rubber plug is always sealed when not charging.



Figure 6: The scrubber unit is IPX7 waterproof, but avoid submerging the main unit for prolonged periods.

3. Storage

Store the scrubber and its accessories in a cool, dry place away from direct sunlight and extreme temperatures. Disassemble the handle for compact storage if needed.

Troubleshooting

- **Device Not Turning On:** Ensure the battery is fully charged. If the issue persists, check the charging cable and adapter.
- **Brush Head Not Spinning:** Verify that the brush head is correctly attached and clicked into place. Ensure no debris is obstructing the rotation.
- **Reduced Power/Speed:** This may indicate a low battery. Recharge the device. Applying excessive pressure during cleaning can also temporarily reduce speed.
- **Unusual Noise:** Check for any loose parts or obstructions around the brush head or motor area.

Specifications

Feature	Detail
Brand	Maraiss
Model Number	X90
Color	Black
Handle Material	Acrylonitrile Butadiene Styrene, Stainless Steel
Product Dimensions	3.15"L x 3.15"W x 51.97"H (extended)
Item Weight	2.72 pounds (1.24 Kilograms)
Special Feature	Extendable, IPX7-rated waterproof, Long Handle
Battery	2000mAh (90 minutes runtime on full charge)
Charging Time	Approx. 2 hours
Speed Settings	3-Speed (300/400/500 RPM)
Waterproof Rating	Full-Body IPX7
Included Components	Main Unit, Extendable Handle, 10 Replaceable Brush Heads, USB-C Charging Cable, Instruction Manual

Safety Information

- Keep the device out of reach of children.
- Do not use the device for purposes other than cleaning.
- Ensure the charging port's rubber plug is securely closed when using the device in wet environments.
- Do not attempt to disassemble or repair the device yourself. Contact customer support for assistance.
- Avoid using abrasive or corrosive cleaning agents that may damage the device or surfaces.
- Do not apply excessive force to the brush head, as this may slow down the motor or damage the device.

Warranty and Support

For warranty information, technical support, or any questions regarding your Maraiss Electric Spin Scrubber, please refer to the contact details provided on the product packaging or visit the official Maraiss website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GC5RZBN7

More documents and user manuals: **https://manuals.plus/**