Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Carlington CT 8140

Carlington Velocity Series Analog-Digital Sports Watch CT 8140 User Manual

Model: CT 8140

Introduction

Thank you for choosing the Carlington Velocity Series Analog-Digital Sports Watch CT 8140. This manual provides detailed instructions for setting up, operating, and maintaining your watch. Please read it carefully to ensure proper use and to maximize the lifespan of your timepiece.
This watch combines analog and digital displays, offering features such as an alarm, stopwatch, backlit display, and dual time functionality. It is designed for durability with water and shock resistance.

Product Overview

Familiarize yourself with the main components and buttons of your Carlington Velocity Series watch.



Image: Front view of the Carlington Velocity Series Analog-Digital Sports Watch CT 8140, showcasing both analog hands and digital display.

Watch Components:

- **Analog Display:** Traditional hour and minute hands.
- **Digital Display:** Shows time, date, day, alarm, and stopwatch functions.
- **Buttons:** Typically four buttons for mode selection, setting adjustments, and backlight activation. (Specific button functions detailed in 'Setup' section).
- **Silicone Strap:** Durable and comfortable for active use.
- **Stainless Steel Back:** Provides protection and durability.

Setup and Initial Configuration

Before using your watch, please set the time, date, and other functions.

1. Setting Analog Time:

1. Pull out the crown (the small knob on the right side of the watch case) to the first click position.
2. Rotate the crown to adjust the hour and minute hands to the desired time.
3. Push the crown back in to secure the analog time setting.



Image: Side view of the watch, highlighting the crown and function buttons for setting adjustments.

2. Setting Digital Time and Date:

- **Mode Button:** Press to cycle through modes (Time, Alarm, Stopwatch).
- **Reset Button:** Used to select items during setting or reset stopwatch.
- **Start Button:** Used to adjust values during setting or start/stop stopwatch.
- **Light Button:** Activates the backlight.

1. From the Timekeeping mode, press the **Mode** button until the digital display shows the time setting screen (usually indicated by flashing digits).

2. Press the **Reset** button to select the digit or setting you wish to change (e.g., seconds, hours, minutes, year, month, day).
3. Use the **Start** button to increase the selected value. Hold down to rapidly advance.
4. Once all settings are correct, press the **Mode** button again to exit the setting mode.

3. Setting the Alarm:

1. Press the **Mode** button until you reach the Alarm mode (indicated by "AL" or an alarm icon).
2. Press the **Reset** button to select the hour or minute digits.
3. Use the **Start** button to adjust the hour and minute.
4. Press the **Mode** button to confirm and exit.
5. To turn the alarm on/off, press the **Start** button while in Alarm mode. An alarm icon will appear/disappear.

Operating Instructions

Using the Stopwatch:

1. Press the **Mode** button until you reach the Stopwatch mode (indicated by "ST" or "STOP").
2. Press the **Start** button to begin timing.
3. Press the **Start** button again to pause the timing.
4. Press the **Reset** button to clear the stopwatch to zero.
5. To resume timing after pausing, press the **Start** button.

Activating the Backlight:

Press the **Light** button (usually located on the top left) to illuminate the digital display for a few seconds, allowing visibility in low-light conditions.



Image: The watch display with its backlight activated, showing clear visibility in the dark.

Dual Time Display:

Your watch features both analog and digital time displays. The analog hands provide a quick glance at the current time, while the digital display offers precise time, date, and additional functions. Ensure both are synchronized during initial setup.

Care and Maintenance

- **Cleaning:** Wipe the watch case and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials.
- **Water Resistance:** The watch is water-resistant up to 10 meters. This means it can withstand splashes, rain, and brief immersion. Do not press any buttons while the watch is wet or submerged, as this can compromise the water seal. Avoid hot water, steam, and prolonged exposure to water.
- **Shock Resistance:** While designed to be shock-resistant, avoid severe impacts or dropping the watch from

significant heights to prevent internal damage.

- **Battery:** The watch is powered by a battery. When the display becomes dim or functions become erratic, it may be time for a battery replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is maintained.
- **Temperature:** Avoid exposing the watch to extreme temperatures (hot or cold) for extended periods, as this can affect battery life and watch accuracy.

Troubleshooting

Problem	Possible Cause	Solution
Analog hands not moving	Crown is pulled out; battery low/dead.	Push the crown back in. If still not working, battery replacement may be needed.
Digital display is blank or dim	Battery low/dead.	Replace the battery.
Time/Date incorrect	Not set correctly; accidental button press.	Refer to the "Setting Digital Time and Date" section to reset.
Alarm not sounding	Alarm not activated; alarm time not set.	Ensure alarm is turned ON (icon visible) and set to the correct time.

Specifications

- **Model:** CT 8140
- **Display Type:** Analog-Digital
- **Movement Type:** Quartz
- **Case Diameter:** 5 Centimetres
- **Case Thickness:** 1.8 Centimetres
- **Band Material:** Silicone
- **Band Width:** 2.2 Centimetres
- **Crystal Material:** Mineral Glass
- **Water Resistance Depth:** 10 Metres
- **Power Source:** Battery Powered
- **Item Weight:** 110 Grams
- **Product Dimensions:** 24 x 5.2 x 1.8 cm
- **Country of Origin:** Hong Kong

Warranty Information

The Carlington Velocity Series Analog-Digital Sports Watch CT 8140 comes with a**1-year warranty** from the date of purchase. This warranty covers any manufacturing defects, providing assurance in the quality of your product. Please retain your proof of purchase for warranty claims.
Note: The warranty does not cover damage caused by misuse, accidental damage, unauthorized repairs, or normal wear and tear.

Customer Support

For any queries, technical assistance, or warranty claims, please contact Carlington India customer support:

- **Phone:** 8100323453
- **Email:** support@carlington.in

Manufacturer and Importer: Carlington India

© 2026 Carlington. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GCNG7D88

More documents and user manuals: **https://manuals.plus/**