Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Carlington CT_8125

Carlington Velocity Series CT_8125 Analog-Digital Sports Watch User Manual

Model: CT_8125

Introduction

Thank you for choosing the Carlington Velocity Series CT_8125 Analog-Digital Sports Watch. This manual provides detailed instructions for setting up, operating, and maintaining your watch to ensure optimal performance and longevity. Please read this manual carefully before using your watch.



Image: Front view of the Carlington Velocity Series CT_8125 watch, showcasing its analog and digital display.

Watch Features

- **Analog-Digital Display:** Combines traditional analog hands with a clear digital readout.
- **Alarm Function:** Set daily alarms to keep you on schedule.
- **Stopwatch:** Precise timing for sports and activities.
- **Backlit Display:** Ensures visibility in low-light conditions.
- **Dual Time:** Track time in two different time zones simultaneously.
- **Calendar Display:** Shows date, day, and month.
- **Water Resistant:** Designed to withstand water exposure up to 10 meters.
- **Shock Resistant:** Built to endure accidental impacts and rough handling.
- **Durable Silicone Rubber Strap:** Comfortable and robust for active use.

Button Functions

The Carlington Velocity Series CT_8125 watch features four primary buttons for various functions. While specific labels may vary slightly, their general functions are as follows:

- **LIGHT Button (Top Left):** Activates the backlight for the digital display.
- **MODE Button (Bottom Left):** Cycles through different modes (Time, Alarm, Stopwatch, Dual Time).
- **START/RESET Button (Top Right):** Used to start/stop the stopwatch, adjust settings, or confirm selections.
- **ADJUST Button (Bottom Right):** Used to reset the stopwatch, move through settings options, or change values.



Image: Close-up of the watch face showing the digital display and button labels (LIGHT, MODE, START, ADJUST).

Setup

Setting Time and Date (Digital Display)

1. From the Timekeeping Mode, press the **MODE** button repeatedly until the seconds begin to flash, indicating setting

mode.

2. Press the **ADJUST** button to cycle through the settings: Seconds → Hour → Minute → Year → Month → Day.
3. Use the **START/RESET** button to increase the flashing value. Hold to rapidly advance.
4. Once all settings are correct, press the **MODE** button to exit the setting mode.

Setting Analog Time

The analog hands are typically synchronized with the digital time. If they are out of sync, follow these steps:

1. In Timekeeping Mode, press and hold the **ADJUST** button until the digital time starts flashing.
2. Press the **MODE** button to move the analog hands forward. Each press advances the hands slightly. Hold the button to move hands continuously.
3. Align the analog hands with the digital time.
4. Press the **ADJUST** button to exit the analog setting mode.

Setting the Alarm

1. From Timekeeping Mode, press the **MODE** button until you reach the Alarm Mode (indicated by "AL" or an alarm icon).
2. Press the **ADJUST** button to select the hour or minute setting.
3. Use the **START/RESET** button to set the desired alarm hour and minute.
4. Press the **MODE** button to confirm and exit.
5. To turn the alarm ON/OFF, press the **START/RESET** button in Alarm Mode. An alarm icon will appear/disappear.

Operating Instructions

Using the Backlight

Press the **LIGHT** button (top left) to illuminate the digital display. The backlight will remain active for a few seconds.



Image: The watch display illuminated by its backlight, showing clear visibility in low light.

Using the Stopwatch

1. Press the **MODE** button until you reach the Stopwatch Mode (indicated by "STW" or a stopwatch icon).
2. Press the **START/RESET** button to start the stopwatch.
3. Press the **START/RESET** button again to pause the stopwatch.
4. To resume, press **START/RESET**.
5. To reset the stopwatch to zero, press the **ADJUST** button while the stopwatch is paused.

Dual Time Function

The dual time function allows you to view a second time zone.

1. Press the **MODE** button until you reach the Dual Time Mode (indicated by "DT" or a dual time icon).
2. Press the **ADJUST** button to select the hour or minute setting for the second time zone.
3. Use the **START/RESET** button to set the desired hour and minute for the dual time.

4. Press the **MODE** button to confirm and exit.

Maintenance

Cleaning Your Watch

- Wipe the watch case and strap with a soft, damp cloth.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water.
- Ensure the watch is completely dry before wearing.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish and seals.

Water Resistance Guidelines

Your watch is water resistant up to 10 meters (1 ATM). This means it is suitable for splashes, rain, and brief immersion in water.

- **Do NOT** press any buttons while the watch is submerged in water.
- **Do NOT** use the watch for diving, snorkeling, or high-pressure water activities.
- After exposure to saltwater, rinse the watch with fresh water and dry it thoroughly.
- Avoid exposing the watch to extreme temperature changes, which can affect water resistance seals.



Image: The watch resting on a surface with water, illustrating its water-resistant design.

Battery Replacement

When the display becomes dim or functions become erratic, it may be time to replace the battery. Battery replacement should ideally be performed by a qualified watch technician to ensure proper sealing and maintain water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Digital display is blank or dim.	Low battery.	Replace the battery.
Analog hands do not match digital time.	Hands are out of sync.	Follow "Setting Analog Time" instructions in the Setup section.

Problem	Possible Cause	Solution
Buttons are unresponsive.	Watch may be in a locked mode or internal error.	Try pressing all buttons firmly. If issue persists, contact support.
Water inside the watch face.	Water resistance compromised (e.g., buttons pressed underwater, extreme temperature change).	Immediately take the watch to a qualified technician for inspection and repair to prevent further damage. Do not attempt to dry it yourself.

Specifications

Feature	Detail
Model Number	CT_8125
Display Type	Analog-Digital
Movement Type	Quartz
Water Resistance Depth	10 Metres (1 ATM)
Band Material	Silicone
Case Material	Alloy Steel
Crystal Material	Mineral Glass
Case Diameter	5 Centimetres
Case Thickness	1.8 Centimetres
Band Width	2.2 Centimetres
Item Weight	110 Grams
Special Features	Backlight, Alarm, Stopwatch, Dual Time, Calendar
Power Source	Battery Powered
Clasp Type	Tang Buckle
Country of Origin	Hong Kong



Image: Rear view of the watch, highlighting the stainless steel back and strap attachment.

Warranty Information

The Carlington Velocity Series CT_8125 watch comes with a**1-year warranty** from the date of purchase. This warranty covers any manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty does not cover damage resulting from improper use, accidents, unauthorized repairs, or normal wear and tear.

Customer Support

For any questions, technical assistance, or warranty claims, please contact Carlington India customer support:

Phone: 8100323453

Email: support@carlington.in



Image: The Carlington signature gift box, indicating product packaging.

© 2026 Carlington. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GCNP7MPR

More documents and user manuals: **https://manuals.plus/**