## TEFELE M15

# TEFELE Wireless Retro Game Console M15 Instruction Manual

Model: M15 | Brand: TEFELE

## 1. Product Overview

The TEFELE Wireless Retro Game Console M15 offers a vast library of classic games with support for 23 game simulators and over 40,000 titles. Designed for ease of use, this plug-and-play system connects directly to your TV via HDMI, delivering 4K HD visuals and smooth performance. It includes two 2.4GHz wireless controllers for a responsive, untangled gaming experience, supporting two-player gameplay.

With its compact and portable design, the M15 console is suitable for all ages and occasions, making it an ideal choice for reliving nostalgic gaming moments.




The TEFELE M15 console supports 23 different game simulators, offering a wide range of classic titles.

## 2. What's Included

Your TEFELE Wireless Retro Game Console package includes the following components:

- Game Stick (Console)
- 2 x 2.4G Wireless Gamepads (Controllers)
- 128GB TF Card (pre-installed in Game Stick)
- Wireless Receiver (for controllers)
- USB Cable (for power)
- HDMI Cable (extension)
- User Manual
- Packing Box




All components included in the TEFELE M15 Wireless Retro Game Console package.

## 3. Setup Instructions

Follow these steps to set up your TEFELE Wireless Retro Game Console:

1. **Insert TF Card:** Ensure the 128GB TF card is properly inserted into the Game Stick.
2. **Connect HDMI:** Plug the Game Stick into an available HDMI port on your TV, projector, or monitor. If needed, use the included HDMI extension cable.
3. **Connect Power:** Connect the USB cable to the Game Stick's USB port and then to a TV's USB power supply or a separate USB power adapter (not included). The Game Stick will show a blue light when powered on.
4. **Insert Wireless Receiver:** Plug the small wireless receiver into the USB port on the Game Stick. This enables wireless communication with the controllers.
5. **Install Controller Batteries:** Open the battery compartment on each 2.4G wireless controller and insert two AA batteries (batteries not included).
6. **Select Input:** Using your TV remote, switch the TV input source to the corresponding HDMI channel where the Game

Stick is connected.

7. **Controller Connection:** The controllers should automatically connect to the Game Stick. If a controller's light is blinking, ensure the wireless receiver is properly inserted into the Game Stick.
8. **Start Gaming:** The game menu will appear on your screen, ready for instant game selection.




Visual guide for connecting the Game Stick and controllers to your display.




Simplified diagram of the Game Stick setup for quick reference.

### Video: Setup & Gameplay Demo

[redacted]

Watch this video for a visual demonstration of the Game Stick setup and initial gameplay.

## 4. Operating Instructions

### Controller Functions

Familiarize yourself with the functions of the wireless controllers:




Detailed layout of the wireless game controller buttons and their functions.

- **Direction Buttons:** Navigate menus and control in-game movement.
- **Coin Set Up:** Typically used to add credits in arcade-style games.
- **Start:** Pause games or confirm selections.
- **Function Buttons (A, B, X, Y):** Perform in-game actions (jump, attack, etc.).
- **Switch Left/Right:** Shoulder buttons for additional in-game functions.
- **Collect/Cancel Button:** Used for various actions, often to cancel or collect items.
- **Mode Button:** May be used for system-specific functions or to access game options.

### Game Selection and Play

1. From the main menu, use the directional buttons on your controller to navigate through the available game simulators or categories (e.g., All Games, Favorites, Arcade Classics).
2. Select a simulator or category to browse the game list.
3. Use the directional buttons to highlight your desired game and press the 'A' button (or equivalent function button) to launch it.
4. To exit a game and return to the menu, consult the in-game instructions or press a combination of buttons (e.g., SELECT + START simultaneously) as specified by the system.

## 5. Specifications

| Feature | Detail |
|---|---|
| Model | M15 |
| Memory Storage Capacity | 128 GB |
| Number of Emulators | 23 |
| Number of Games | 40,000+ |
| Output | 4K HDMI |
| Controllers | Dual 2.4G Wireless Controllers |
| Controller Power Source | 4 AA batteries required (2 per controller, not included) |
| Material | Plastic |
| Item Weight | 12.3 ounces |
| Package Dimensions | 6.65 x 4.84 x 4.37 inches |
| ASIN | B0GD137NP9 |
| UPC | 751753652205 |
| Release Date | January 1, 2026 |

## 6. Troubleshooting

If you encounter any issues with your TEFELE Wireless Retro Game Console, please refer to the following common troubleshooting tips:

- **No Display on TV:**
  - Ensure the Game Stick is securely plugged into the TV's HDMI port.
  - Verify that your TV input is set to the correct HDMI channel.
  - Check if the USB power cable is connected and the Game Stick's blue indicator light is on.
  - Try a different HDMI port on your TV.
- **Controllers Not Responding:**
  - Make sure fresh AA batteries are installed correctly in both controllers.
  - Ensure the wireless receiver is firmly plugged into the Game Stick's USB port.
  - If the controller light is blinking, it indicates it's not connected. Re-insert the wireless receiver or restart the Game Stick.
- **Game Performance Issues (Choppy/Laggy):**

- Ensure the Game Stick has adequate power supply.
- Some older emulated games may have minor performance variations depending on the game.

- **Game Not Loading:**
  - Verify the TF card is correctly inserted and not damaged.
  - Restart the Game Stick and try loading the game again.

## 7. Maintenance

To ensure the longevity and optimal performance of your TEFELE Wireless Retro Game Console, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the Game Stick and controllers. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the console and accessories in a cool, dry place away from direct sunlight and extreme temperatures.
- **Power Off:** When not in use, unplug the Game Stick from the power source to prevent overheating and conserve energy.
- **Battery Replacement:** Replace controller batteries when performance degrades. Always use new, good-quality AA batteries.
- **Handle with Care:** Avoid dropping or subjecting the Game Stick and controllers to strong impacts.

## 8. Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your purchase documentation or visit the official TEFELE website. Keep your proof of purchase for any warranty claims.