Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hupoaf H87

Hupoaf H87 Wireless Sport Earbuds Instruction Manual

Model: H87 | Brand: Hupoaf

Introduction

Thank you for choosing the Hupoaf H87 Wireless Sport Earbuds. These earbuds are designed to provide a stable and immersive audio experience for sports and daily use, featuring Bluetooth 5.4 connectivity, ENC noise-canceling microphones, and an IP7 waterproof rating. This manual will guide you through the setup, operation, and maintenance of your new earbuds.



Image: Hupoaf H87 Wireless Sport Earbuds shown inside their charging case.

Your browser does not support the video tag.

Video: An overview of the Hupoaf Wireless Earbuds Sports with Earhook, demonstrating key features and design.

What's in the Box

Verify that all items are present in your package:

- 1 x Fast Charging Case
- 2 x Wireless Sport Earbuds (Left and Right)
- 3 x Pairs of Earplugs (Sizes S, M, L)
- 1 x USB-C Charging Cable
- 1 x Instruction Manual (this document)



Image: The Hupoaf H87 earbuds, charging case, USB-C cable, and various ear tip sizes.

Product Overview

Familiarize yourself with the components of your Hupoaf H87 earbuds.



Image: Exploded view of an earbud, illustrating the 14.2mm dynamic driver for stereo sound and the Bluetooth 5.4 chip.



Image: A pair of Hupoaf H87 wireless sport earbuds, showcasing their over-ear hook design.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB-C charging cable to the charging port on the case and to a USB power source.
3. The LED display on the charging case will show the battery percentage of the case and individual earbud charging status.
4. A full charge takes approximately 1.5 hours. The earbuds provide up to 10 hours of playback on a single charge, with the charging case extending total battery life to 50 hours.



Image: The charging case displaying its battery percentage and the charging status of the left and right earbuds.

2. Pairing with Your Device

The earbuds will automatically enter pairing mode when removed from the charging case.

1. Open the charging case and remove both earbuds. They will automatically power on and attempt to pair with each other.
2. On your device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "H87" from the list.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. The earbuds feature Bluetooth 5.4 for stable and fast connections with wide compatibility across iOS, Android, and Windows devices.



Image: A visual guide to pairing, showing the "H87" device name in a Bluetooth pairing menu.



Image: An illustration highlighting the advantages of Bluetooth 5.4, including improved power efficiency and connection stability.

Operating Instructions

1. Wearing the Earbuds

For optimal sound quality and comfort, ensure a proper fit.

1. Choose the correct size ear tips (S, M, L) for your ears. A snug fit enhances bass and noise isolation.
2. Place the earbud into your ear canal and gently rotate it until the ear hook rests comfortably and securely over your ear.
3. The ergonomic ear hook design provides stability, especially during physical activity.



Image: A user demonstrating the secure fit of the earbuds with earhooks, alongside an illustration of the flexible earhook and various ear tip sizes.

Wide Compatibility
Automatic Pairing



Image: A size guide chart providing details for selecting the appropriate ear tip size for optimal fit and comfort.

2. Touch Controls

The Hupoaf H87 earbuds feature smart touch controls for easy management of music and calls.

Touch Control Functions

Action	Left Earbud (L)	Right Earbud (R)
Play/Pause Music	Click x1	Click x1
Next Track	Hold for 2s	N/A
Previous Track	N/A	Hold for 2s
Volume Up	N/A	Click x1
Volume Down	Click x1	N/A
Answer/End Call	Click x1	Click x1
Reject Call	Hold for 2s	Hold for 2s
Activate Voice Assistant	Click x3	Click x3



Image: A visual representation of the touch control functions on the earbuds, showing gestures for various commands.

3. Call Functions with ENC Noise Cancellation

The H87 earbuds are equipped with 4 ENC (Environmental Noise Cancellation) microphones to ensure clear calls by reducing background noise.

- **Answering/Ending Calls:** Single tap either earbud.
- **Rejecting Calls:** Press and hold either earbud for 2 seconds.
- The ENC technology actively filters out ambient noise, making your voice clearer to the person on the other end.



Image: A user making a call in a noisy environment, demonstrating the effectiveness of ENC noise cancellation.

Maintenance

1. Cleaning and Storage

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners or solvents.
- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid extreme temperatures and direct sunlight.

2. Water Resistance (IP7 Rating)

The Hupoaf H87 earbuds are IP7 waterproof, meaning they are protected against temporary immersion in water up to 1 meter for 30 minutes. This makes them suitable for sports and outdoor activities, resisting sweat and rain.

- Do not intentionally submerge the earbuds for extended periods or use them for swimming.

- Ensure the earbuds are dry before placing them back into the charging case to prevent damage to the charging contacts.



Image: An illustration of the earbuds highlighting their IP7 waterproof rating, suitable for various weather conditions and intense workouts.

Troubleshooting

Common Issues and Solutions

Problem	Solution
Earbuds not pairing with device.	• Ensure earbuds are charged. • Turn off Bluetooth on your device and turn it back on. • Forget "H87" in your device's Bluetooth settings and re-pair. • Place earbuds back in the case, close, then reopen and try again.
Only one earbud is playing sound.	• Ensure both earbuds are charged. • Place both earbuds back into the charging case, close the lid for 5 seconds, then open and remove them simultaneously. • If the issue persists, try resetting the earbuds (refer to the full manual for specific reset instructions if available, or contact support).
Low volume or poor sound quality.	• Adjust the volume on both your device and the earbuds. • Ensure ear tips are the correct size and provide a snug seal. • Clean any debris from the earbud mesh.
Charging case not charging.	• Ensure the USB-C cable is securely connected to both the case and the power source. • Try a different USB-C cable or power adapter.

Specifications

Technical Specifications

Feature	Detail
Model	H87
Bluetooth Version	5.4
Bluetooth Range	Up to 20 meters (66 feet)
Earbud Battery Life (Single Charge)	Up to 10 hours
Total Battery Life (with Charging Case)	Up to 50 hours
Charging Time (Earbuds & Case)	Approx. 1.5 hours (USB-C)
Water Resistance Rating	IP7 (Waterproof)
Noise Control	ENC Noise Cancellation (4 Mics)
Control Type	Touch Control
Driver Type	Dynamic Driver (14.2mm speakers)
Impedance	32 Ohms
Sensitivity	92 dB
Material	Plastic

Warranty and Support

Hupoaf provides a one-month return policy for quality problems and a 2-year warranty for the H87 Wireless Sport Earbuds.

For any questions, technical support, or warranty claims, please contact Hupoaf customer service. Refer to the contact information provided on the product packaging or the official Hupoaf website.

Your satisfaction is our priority. Our dedicated customer service team is available to assist you.

© 2026 Hupoaf. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GFCH5W1L

More documents and user manuals: **https://manuals.plus/**