Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VIKICON Groomer FK-8609

VIKICON Groomer 6D Back Shaver for Men

MODEL: FK-8609

Instruction Manual

INTRODUCTION

Thank you for choosing the VIKICON Groomer 6D Back Shaver. This electric shaver is designed for efficient and comfortable hair removal across various body areas, including the back, chest, head, and face. Its innovative 6D floating head and ergonomic long handle provide a smooth and irritation-free grooming experience. Please read this manual thoroughly before first use to ensure proper operation and maintenance.

SAFETY INFORMATION

- Keep this product out of reach of children.
- Do not disassemble or attempt to repair the device yourself. Contact customer support for assistance.
- Ensure the charging port is dry before connecting the charging cable.
- Avoid using the shaver on irritated, damaged, or infected skin.
- Do not immerse the entire unit in water for extended periods, despite its waterproof rating.

WHAT'S INCLUDED

Your VIKICON Groomer Back Shaver kit includes the following components:

- 6D Floating Shaver Head
- Foldable Ergonomic Handle
- Trimmer Head
- Type-C Charge Cable
- Cleaning Brush
- 3/5/7mm Guide Combs (3 pieces)



Image: All components included in the VIKICON Groomer Back Shaver kit.

Setup

Before first use, ensure the shaver is fully charged and assembled correctly.

1. **Charging the Shaver:** Connect the Type-C charge cable to the shaver and a suitable USB power adapter. The LED display will indicate the battery level. A full charge takes approximately 90 minutes and provides up to 60 minutes of work time.



Image: The shaver charging, showing the LED battery indicator.

2. **Attaching the Long Handle:** Align the shaver head unit with the port on the foldable handle and insert it firmly until it clicks into place. To remove, pull the shaver head unit upward.

Your browser does not support the video tag.

Video: A demonstration of how to attach and detach the shaver head from the long handle, and how to fold the handle for storage or different reach.

3. **Adjusting the Handle:** The handle features a 180° adjustable foldable design. Press the hinge buckle to unfold and adjust the handle to your desired angle for optimal reach.



Image: Illustration of the 180-degree adjustable handle for extended reach.

4. **Activating Travel Lock:** To prevent accidental activation during travel, press and hold the power button for 3 seconds to lock or unlock the device.

Operating Instructions

The VIKICON Groomer 6D Back Shaver is designed for versatile use on various body parts. Follow these steps for effective and comfortable grooming.

1. **Preparation:** For best results, especially with thick hair, it is recommended to first trim longer hair using the trimmer head with an appropriate guide comb. This reduces pulling and ensures a smoother shave with the main shaver head.



Image: Demonstrates the effectiveness of the shaver on heavy back hair, showing a smooth result.

2. **Shaving Technique:** Turn on the shaver. Gently press the 6D floating head against your skin and move it in circular or linear motions. The flexible head adapts to your body's contours for a close shave.



Image: The 6D floating head design, engineered to adapt to body curves for an efficient shave.

3. **Wet & Dry Use:** The shaver is IPX6 waterproof, allowing for both wet and dry shaving. You can use it in the shower with shaving cream or gel for added comfort, or dry for quick touch-ups.



Image: The shaver being used in a wet environment, highlighting its IPX6 waterproof feature.

4. **Using the Long Handle for Back Shaving:**Attach the long handle to reach your entire back effortlessly. Adjust the handle's angle to comfortably access all areas, including shoulders and lower back.

Your browser does not support the video tag.

Video: A demonstration of using the VIKICON Groomer back shaver with its long handle to reach and shave the entire back.

5. **Multi-Use Functionality:** The shaver is suitable for various body parts. Use it for your head, face (beard), chest, arms, and legs.



Image: The shaver's versatility for use on head, face, chest, arms, and legs.

Your browser does not support the video tag.

Video: A demonstration highlighting the shaver's design for use on the head, face, and body.

Maintenance

Regular cleaning and proper care will extend the life of your shaver and ensure optimal performance.

1. **Cleaning the Shaver Head:** After each use, gently remove the lower head from the upper head. Rinse the blades under running water to remove hair clippings. Use the provided cleaning brush to clear any stubborn hair from the hair chamber. Reattach the shaver head firmly.



Image: Step-by-step guide for cleaning the shaver head.

2. **Battery Care:** To maintain battery health, avoid completely draining the battery frequently. Recharge the shaver when the LED display indicates a low battery level.
3. **Storage:** Store the shaver in a cool, dry place. Ensure it is clean and dry before storing.

Troubleshooting

If you encounter any issues with your VIKICON Groomer Back Shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the battery is charged. Check if the travel lock is activated (press and hold the power button for 3 seconds to unlock).
- **Poor shaving performance:** Clean the shaver head thoroughly. If hair is very long, use the trimmer head first. The blades may need replacement after extended use.
- **Irritation after shaving:** Ensure your skin is clean before shaving. Consider using shaving cream or gel for wet shaving. Shave in the direction of hair growth initially, then against it for a closer shave if your skin tolerates it.
- **Charging issues:** Verify the Type-C cable is securely connected to both the shaver and the power source. Try a different USB power adapter.

Specifications

Item Model Number	FK-8609
Manufacturer	VIKICON Groomer
Batteries	1 C battery required (included)
Waterproof Rating	IPX6
Charging Time	Approx. 90 minutes
Operating Time	Up to 60 minutes

Warranty & Support

Your VIKICON Groomer Back Shaver comes with a 1-year warranty, ensuring reliable support and free replacement for manufacturing defects. For any inquiries or assistance, please contact our customer support team.

- 1-Year Free Replacement
- 24/7 Customer Support
- Premium Quality Assurance

© 2026 VIKICON Groomer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GFCSNTLS

More documents and user manuals: **https://manuals.plus/**