Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Turbo Jet TJHYXP-CB4

Turbo Jet® HydroX5™ Pro+ Cordless Pressure Washer Instruction Manual

Model: TJHYXP-CB4

Introduction | What's in the Box | Setup | Operation | Maintenance | Troubleshooting | Specifications | Warranty & Support

1. Introduction

The Turbo Jet® HydroX5™ Pro+ is a portable, cordless pressure washer designed for efficient cleaning of various outdoor surfaces. This device provides up to 380 PSI of cleaning power, making it suitable for tasks such as washing cars, patios, decks, siding, and outdoor furniture. Its cordless design, powered by a 21V 5000mAh lithium-ion battery, offers enhanced mobility. The unit supports dual water sources, allowing connection to a standard garden hose or drawing water from any container using its siphon system. Multiple spray patterns are available through quick-connect nozzles to adapt to different cleaning needs.



Figure 1.1: The Turbo Jet HydroX5 Pro+ Cordless Pressure Washer demonstrating its versatility across different cleaning tasks.

2. What's in the Box

Carefully unpack all components and ensure all items are present before beginning assembly. Refer to the image below for a visual representation of the included parts.

- Turbo Jet HydroX5 Pro+ Pressure Washer Unit
- 21V 5000mAh Lithium-Ion Battery
- Battery Charger
- 6-in-1 Multi-Function Power Nozzle
- Set of 3 Quick-Connect Spray Tips (0°, 15°, 40°)
- Soap Foam Cannon Attachment
- Water Siphon Hose with Filter
- Quick Connect Garden Hose Adapter
- Storage Case



Figure 2.1: Complete contents of the Turbo Jet HydroX5 Pro+ package.

3. Setup

3.1 Charging the Battery

1. Insert the 21V 5000mAh lithium-ion battery into the provided charger.
2. Plug the charger into a standard electrical outlet.
3. Allow the battery to charge fully before first use. The indicator light on the charger will change to confirm full charge.



Figure 3.1: The 21V 5000mAh Lithium-Ion Battery.

3.2 Connecting the Water Source

The HydroX5 Pro+ offers two methods for water supply:

1. **Garden Hose Connection:**
    - Attach the quick-connect garden hose adapter to your standard garden hose.
    - Connect the other end of the adapter to the water inlet on the pressure washer unit.
    - Ensure a secure connection to prevent leaks.
2. **Water Siphon System:**
    - Attach the water siphon hose with the filter to the water inlet on the pressure washer unit.
    - Place the filter end of the siphon hose into any water container (e.g., bucket, lake, pool).
    - Ensure the filter is fully submerged in water.



Figure 3.2: Dual water source compatibility: garden hose or siphon from a bucket.



Figure 3.3: Quick connect hose adapter for easy garden hose attachment.

3.3 Attaching the Nozzle

Select the appropriate nozzle for your cleaning task and attach it to the spray wand. The unit includes a 6-in-1 multi-function nozzle and a set of 3 quick-connect spray tips.

- **6-in-1 Multi-Function Nozzle:** Rotate the nozzle head to select desired spray pattern (0°, 15°, 25°, 40°, Fan, Shower).
- **Quick-Connect Spray Tips:** Insert the desired colored tip (Red for 0°, Yellow for 15°, White for 40°) into the quick-connect fitting on the spray wand until it clicks securely.



Figure 3.4: Quick-connect spray tips for various applications.

4. Operating Instructions

4.1 General Operation

1. Ensure the battery is fully charged and securely inserted into the pressure washer.
2. Connect your chosen water source (garden hose or siphon system) and ensure water flow is available.
3. Select the appropriate spray nozzle for your task.
4. Point the nozzle away from yourself and others.
5. Press the trigger to begin spraying. Release the trigger to stop.
6. Always test the spray pattern and pressure on an inconspicuous area first to avoid damage to the surface.



Figure 4.1: Available spray patterns from the 6-in-1 power nozzle.

4.2 Using the Soap Foam Cannon

1. Fill the soap foam cannon reservoir with appropriate pressure washer detergent.
2. Attach the foam cannon to the pressure washer unit.
3. Spray the detergent onto the desired surface.
4. Allow the detergent to dwell for the recommended time (refer to detergent instructions).
5. Remove the foam cannon and re-attach a rinse nozzle (e.g., 25° or 40° tip) to rinse the surface thoroughly.



Figure 4.2: Using the soap foam cannon for effective cleaning.



Figure 4.3: Applying soap to a car using the soap attachment.

5. Maintenance

5.1 Cleaning and Storage

- After each use, disconnect the water source and run the pressure washer for a few seconds to clear any remaining water from the pump and hose.
- Remove the battery and store it in a cool, dry place.
- Clean the exterior of the unit with a damp cloth. Do not use harsh chemicals.
- Ensure all nozzles and filters are free from debris. Rinse the siphon filter if used.
- Store the pressure washer and all accessories in the provided storage case in a dry, protected area, away from direct sunlight and extreme temperatures.

5.2 Battery Care

- Do not store the battery in a fully discharged state for extended periods. Recharge it periodically if not in use.

- Avoid exposing the battery to extreme heat or cold.
- If the battery shows signs of damage or malfunction, discontinue use and replace it.

6. Troubleshooting

Problem	Possible Cause	Solution
Unit does not start	Battery not charged or improperly inserted.	Ensure battery is fully charged and securely clicked into place.
Low water pressure	Insufficient water supply, clogged nozzle, or air in the system.	Check water source connection and supply. Clean nozzle. Prime the pump by running without a nozzle until water flows steadily.
Water leaks	Loose connections or damaged O-rings.	Tighten all connections. Inspect and replace any damaged O-rings.
Motor runs but no water sprays	No water supply, air in the pump, or clogged inlet filter.	Ensure water supply is connected and turned on. Prime the pump. Clean the inlet filter on the siphon hose or garden hose adapter.

7. Specifications

Feature	Detail
Brand	Turbo Jet
Model Number	TJHYXP-CB4
Maximum Pressure	380 PSI
Power Source	Battery Powered
Battery Type	21V 5000mAh Lithium-Ion
Hose Length	16 Feet (Siphon Hose)
Product Dimensions (L x W x H)	4.96" x 16.14" x 12.4"
Tank Volume (Soap Cannon)	5000 Milliliters (approx. 1.3 Gallons)



Figure 7.1: Key specifications and included components.

8. Warranty & Support

For warranty information and customer support, please refer to the documentation included with your product or visit the official Turbo Jet website. Keep your purchase receipt as proof of purchase for any warranty claims.

Return Policy: The product typically includes a 30-day return policy from the seller. Please check your specific purchase details for exact terms.

© 2023 Turbo Jet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GFWX48VS

More documents and user manuals: **https://manuals.plus/**