Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nonbliep B0GG49T37D

Nonbliep Wired Arcade Stick Instruction Manual

Model: B0GG49T37D

Introduction

This manual provides instructions for the Nonbliep Wired Arcade Stick, designed for use with PlayStation 5, PlayStation 4, and PC. It features programmable buttons, turbo functions, and a durable build, optimized for fighting game genres.



Image: Nonbliep Wired Arcade Stick with PS5 and PC compatibility.

Setup Instructions

Connecting to PlayStation 5

Before connecting to a PlayStation 5 console, ensure the console's communication method is set to 'Use USB Cable'. Follow these steps:

1. Go to **Settings** on your PS5.
2. Select **Accessories**.
3. Choose **Controller (General)**.

4. Select **Communication Method**.
5. Choose **Use USB Cable**.

General Connection

Connect the arcade stick to your PlayStation 4, PC, or Android device using the integrated 9.8-foot braided USB cable. Ensure the connection is secure.

Operating Instructions

Turbo Functions

The arcade stick is equipped with both standard Turbo and Auto-Turbo modes. These functions enable rapid-fire inputs for buttons, which can reduce finger fatigue during gameplay and assist with executing quick sequences.

- **Standard Turbo:** Activates rapid-fire for a button while it is held down.
- **Auto-Turbo:** Maintains rapid-fire for a button without needing to hold it down.



Image: Turbo buttons on the arcade stick.

Macro Programming

The arcade stick features three programmable trigger buttons (M1, M2, M3). Each button can store up to 16 key commands, allowing users to map complex combo sequences to a single press for enhanced precision in gameplay.



Image: Macro and programmable buttons.

Mode Switching (DP, LS, RS)

A dedicated switch allows users to select between different control modes, adapting the joystick's input interpretation to various game types:

- **DP Mode (Directional Pad):** Ideal for precise combos in fighting games.
- **LS Mode (Left Stick):** Suitable for precise control in racing games or other genres requiring analog stick input.
- **RS Mode (Right Stick):** Provides free movement control, useful in games that utilize the right analog stick for camera or other functions.



Image: Mode selection switch.

Features

- **Stable, Heavy-Duty Build:** The arcade stick is crafted with a substantial weight to ensure it remains firmly planted during intense battles, preventing unwanted slippage.
- **Built-in Cable Management:** A dedicated hidden compartment is integrated into the design for neat and clutter-free storage of the braided USB cable. This allows for easy storage and retrieval, maintaining a tidy play space.



Image: Overall view of the arcade stick, demonstrating its build.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your Nonbliep Wired Arcade Stick.

- **Cleaning:** Use a soft, dry cloth to wipe the surfaces of the arcade stick. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and internal components.
- **Cable Care:** When not in use, store the USB cable neatly in its dedicated compartment to prevent tangling, kinking, or damage. Avoid pulling the cable forcefully from the device or the arcade stick.
- **Storage:** Store the arcade stick in a cool, dry place away from direct sunlight, extreme temperatures, and excessive moisture.

Troubleshooting

If you encounter issues with your arcade stick, refer to the following common solutions:

- **Not Responding on PS5:** Verify that the PS5's 'Communication Method' setting is correctly set to 'Use USB Cable' (Settings > Accessories > Controller (General) > Communication Method).
- **General Connectivity Issues:** Ensure the USB cable is securely plugged into both the arcade stick and your console/PC. Try connecting to a different USB port.
- **Buttons or Joystick Unresponsive:** Check for any physical obstructions or debris around the buttons or joystick. Ensure no buttons are stuck. If the issue persists, it may indicate a hardware problem.
- **Incorrect Input Mode:** If inputs are not registering as expected, check the DP/LS/RS mode switch and ensure it is set to the appropriate mode for your game.

If these steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Brand	Nonbliep
Model Number	B0GG49T37D
Compatible Devices	PlayStation 5, PlayStation 4, PC, Android
Connectivity Technology	USB
Additional Features	Wired, Turbo Function, Macro Programming
Hardware Platform	PlayStation 5
Compatible Video Game Console Models	Sony PlayStation 4, Sony PlayStation 5
Color	White
Cable Length	9.8 feet (braided)

Warranty and Support

For detailed warranty information, technical support, or customer service inquiries, please refer to the official Nonbliep website or contact the retailer where the product was purchased. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GG49T37D

More documents and user manuals: **https://manuals.plus/**