Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Shintenchi DGNG10840

Shintenchi Modern Farmhouse 3-Door Sideboard Buffet Cabinet

Model: DGNG10840

Introduction

Thank you for choosing the Shintenchi Modern Farmhouse 3-Door Sideboard Buffet Cabinet. This manual provides essential information for the safe assembly, proper use, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.

Safety Information

- Always assemble the cabinet according to the instructions provided.
- Secure the cabinet to the wall using the included anti-tipping device to prevent tipping and potential injuries. This is a critical safety measure, especially in households with children or pets.
- Do not overload the cabinet shelves or tabletop. Refer to the 'Specifications' section for weight capacity limits.
- Keep small parts and packaging materials away from children during assembly.
- Ensure all screws and fasteners are tightened securely before use. Periodically check and re-tighten as necessary.

Package Contents

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (top, bottom, sides, back, shelves, drawer fronts, door panels)
- Hardware Pack (screws, dowels, cam locks, handles, drawer slides, magnetic door holders, anti-tipping kit)
- Assembly Tools (basic screwdriver may be included, but a power drill with appropriate bits is recommended for efficiency)

Setup and Assembly Instructions

Assembly requires at least two people. Clear a spacious area for assembly and lay out all parts on a soft, clean surface to prevent scratches.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Refer to the parts list (usually found in the included paper manual) to identify each piece.

2. **Assemble the Base Frame:** Connect the bottom panel to the side panels using the provided hardware (e.g., dowels and cam locks). Ensure connections are secure.
3. **Install Drawer Slides:** Attach the drawer slides to the inner side panels of the cabinet frame according to the pre-drilled holes.
4. **Assemble Drawers:** Construct the three drawers by connecting the front, back, and side panels. Insert the drawer bottom and attach the metal handles. Install the corresponding drawer slides onto the assembled drawers.
5. **Attach Back Panel:** Secure the back panel to the main frame using small nails or screws. Ensure the cabinet is square before fastening.
6. **Install Shelves:** Insert the adjustable shelf pins into the desired holes within the cabinet compartments. Place the two adjustable shelves onto the pins.
7. **Attach Doors:** Mount the three barn-style doors to the cabinet frame using the provided hinges. Adjust hinges as needed to ensure proper door alignment and smooth operation. Install the door handles.
8. **Install Magnetic Door Holders:** Attach the magnetic door holders to the inside of the cabinet frame and the corresponding doors to ensure they close securely.
9. **Attach Top Panel:** Secure the top panel to the assembled frame.
10. **Install Anti-Tipping Device:** Attach the anti-tipping strap to the back of the cabinet and secure it to a wall stud using appropriate wall anchors and screws. This step is crucial for stability and safety.

Visual Aid: Cabinet Dimensions and Features



Image: Detailed dimensions of the Shintenchi Modern Farmhouse 3-Door Sideboard Buffet Cabinet.



Image: Close-up views of the thickened tabletop, magnetic door holder, smooth metal slides, and high wooden base.

Operating Instructions

Using the Storage Compartments

- **Doors:** The cabinet features three doors with magnetic closures. Gently pull the handles to open and push to close.
- **Adjustable Shelves:** The two internal shelves are adjustable. To change shelf height, remove items from the shelf, lift the shelf, reposition the metal pins to the desired height, and then place the shelf back onto the pins. Ensure the shelf is level and stable before placing items on it.

Visual Aid: Adjustable Shelf Feature



Image: Illustration of the adjustable shelf mechanism, showing height increments.

Using the Drawers

- The three drawers operate on smooth metal slides. Pull the handles to open and push to close. Avoid forcing drawers open or closed.
- Distribute weight evenly within the drawers to prevent strain on the slides.

Visual Aid: Cabinet with Open Doors and Drawers



Image: The cabinet with doors and drawers open, showcasing its ample storage capacity.

Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the wood.
- **Hardware:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Placement:** Avoid placing the cabinet in direct sunlight or near heat sources, as this can cause fading or warping. Maintain a stable room temperature and humidity.

Troubleshooting

Issue: Cabinet feels wobbly or unstable.

Solution: Ensure all assembly hardware is securely tightened. Verify that the cabinet is placed on a level surface. Re-check the installation of the anti-tipping device to the wall.

Issue: Doors do not close properly or are misaligned.

Solution: Check the hinge adjustments. Most hinges allow for minor adjustments to align doors. Ensure the magnetic door holders are correctly installed and aligned.

Issue: Drawers stick or do not slide smoothly.

Solution: Ensure the drawer slides are correctly installed and free from obstructions. Verify that the drawer is not overloaded. A small amount of silicone lubricant can be applied to the slides if necessary.

Issue: Missing or damaged parts.

Solution: Do not proceed with assembly. Contact Shintenchi customer support immediately for replacement parts.

Specifications

Attribute	Detail
Brand	Shintenchi
Model Number	DGNG10840
Product Dimensions (D x W x H)	39.9D x 81.5W x 107.9H Centimetres
Item Weight	18 Kilograms
Material	Manufactured Wood
Color	White
Number of Doors	3 (Barn Doors style)
Number of Drawers	3
Number of Shelves	2 (Adjustable)
Tabletop Weight Capacity	Up to 80 Kilograms
Assembly Required	Yes
Mounting Type	Floor Mount (with anti-tipping device for wall attachment)

Warranty and Support

For warranty information, missing parts, or technical support, please contact Shintenchi customer service directly. Refer to your purchase documentation or the retailer's website for specific contact details.
Please have your model number (DGNG10840) and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0GG8YD7WB

More documents and user manuals: **https://manuals.plus/**